

# Ruijie Reyee RG-EG210G-E Router

## Installation Guide



Document Version: V1.2

Date: July 22, 2024

Copyright © 2024 Ruijie Networks

## Copyright

Copyright © 2024 Ruijie Networks

All rights are reserved in this document and this statement.

Without the prior written consent of Ruijie Networks, any organization or individual shall not reproduce, extract, back up, modify, or propagate the content of this document in any manner or in any form, or translate it into other languages or use some or all parts of the document for commercial purposes.



and other Ruijie networks logos are trademarks of Ruijie Networks.

All other trademarks or registered trademarks mentioned in this document are owned by their respective owners.

## Disclaimer

The products, services, or features you purchase are subject to commercial contracts and terms, and some or all of the products, services, or features described in this document may not be available for you to purchase or use. Except for the agreement in the contract, Ruijie Networks makes no explicit or implicit statements or warranties with respect to the content of this document.

The names, links, descriptions, screenshots, and any other information regarding third-party software mentioned in this document are provided for your reference only. Ruijie Networks does not explicitly or implicitly endorse or recommend the use of any third-party software and does not make any assurances or guarantees concerning the applicability, security, or legality of such software. You should choose and use third-party software based on your business requirements and obtain proper authorization. Ruijie Networks assumes no liability for any risks or damages arising from your use of third-party software.

The content of this document will be updated from time to time due to product version upgrades or other reasons. Ruijie Networks reserves the right to modify the content of the document without any notice or prompt.

This manual is designed merely as a user guide. Ruijie Networks has tried its best to ensure the accuracy and reliability of the content when compiling this manual, but it does not guarantee that the content of the manual is completely free of errors or omissions, and all the information in this manual does not constitute any explicit or implicit warranties.

# Preface

## Intended Audience

This document is intended for:

- Network engineers
- Technical support and servicing engineers
- Network administrators

## Technical Support

- The official website of Ruijie Reyee: <https://reyee.ruijie.com>
- Technical Support Website: <https://reyee.ruijie.com/en-global/support>
- Case Portal: <https://www.ruijienetworks.com/support/caseportal>
- Community: <https://community.ruijienetworks.com>
- Technical Support Email: [service\\_rj@ruijienetworks.com](mailto:service_rj@ruijienetworks.com)
- Online Robot/Live Chat: <https://reyee.ruijie.com/en-global/rita>

## Conventions

### 1. Signs

The signs used in this document are described as below:

---

#### **Danger**

An alert that calls attention to safety operation instructions that if not understood or followed when operating the device can result in physical injury.

---

#### **Warning**

An alert that calls attention to important rules and information that if not understood or followed can result in data loss or equipment damage.

---

#### **Caution**

An alert that calls attention to essential information that if not understood or followed can result in function failure or performance degradation.

---

#### **Note**

An alert that contains additional or supplementary information that if not understood or followed will not lead to serious consequences.

---

#### **Specification**

An alert that contains a description of product or version support.

---

## **2. Note**

This manual provides installation steps, troubleshooting, technical specifications, and usage guidelines for cables and connectors. It is intended for users who want to understand the above and have extensive experience in network deployment and management, and assume that users are familiar with related terms and concepts.

# Contents

|                                                |    |
|------------------------------------------------|----|
| Preface .....                                  | I  |
| 1 Product Overview .....                       | 1  |
| 1.1 Specifications .....                       | 1  |
| 1.2 Appearance .....                           | 2  |
| 1.3 Power Supply .....                         | 3  |
| 1.4 Heat Dissipation .....                     | 3  |
| 1.5 Port .....                                 | 3  |
| 1.6 LED Indicator .....                        | 4  |
| 2 Preparation before Installation .....        | 5  |
| 2.1 Safety Suggestions .....                   | 5  |
| 2.1.1 Installation .....                       | 5  |
| 2.1.2 Movement .....                           | 5  |
| 2.1.3 Electricity .....                        | 5  |
| 2.1.4 Static Discharge Damage Prevention ..... | 6  |
| 2.2 Installation Site Requirements .....       | 6  |
| 2.2.1 Installation Site .....                  | 6  |
| 2.2.2 Ventilation .....                        | 7  |
| 2.2.3 Temperature and Humidity .....           | 7  |
| 2.2.4 Cleanness .....                          | 7  |
| 2.2.5 Grounding .....                          | 8  |
| 2.2.6 EMI .....                                | 9  |
| 2.3 Installation Tool Requirements .....       | 9  |
| 3 Installing the Router .....                  | 10 |

|                                                              |    |
|--------------------------------------------------------------|----|
| 3.1 Installation Flowchart .....                             | 10 |
| 3.2 Confirmations before Installation .....                  | 10 |
| 3.3 Mounting the Router .....                                | 11 |
| 3.3.1 Mounting the Router to a Standard 19-inch Cabinet..... | 11 |
| 3.3.2 Mounting the Router to a Workbench.....                | 11 |
| 3.4 Grounding the Router .....                               | 11 |
| 3.5 Installing Power Cables .....                            | 12 |
| 3.6 Connecting the External Port Cables .....                | 12 |
| 3.7 Installation Verification.....                           | 12 |
| 4 System Debugging.....                                      | 13 |
| 4.1 Establishing the Debugging Environment .....             | 13 |
| 4.2 Startup Check .....                                      | 13 |
| 4.2.1 Checking before the Device is Powered on .....         | 13 |
| 4.2.2 Checking after Program Startup (Recommended).....      | 13 |
| 4.3 Log In to the Web Interface .....                        | 14 |
| 4.4 Configuring Router.....                                  | 14 |
| 5 Maintenance and Troubleshooting.....                       | 15 |
| 5.1 General Troubleshooting Procedure .....                  | 15 |
| 5.2 Troubleshooting Common Faults .....                      | 15 |
| Appendix A Connectors and Connection Media .....             | 16 |
| Appendix B: Cabling Recommendations in Installation .....    | 18 |

# 1 Product Overview

Featured with global-leading semiconductor technologies and communication control technologies, Ruijie RG-EG210G-E series router is a data communication product developed by Ruijie Networks with independent intellectual property right. The RG-EG210G-E series router is designed according to international standards, similar to the mainstream router products in the international market. By reading this manual, a network administrator familiar with mainstream router configuration commands can use this device without training.

## 1.1 Specifications

|                              |                                                                                                                                    |
|------------------------------|------------------------------------------------------------------------------------------------------------------------------------|
| <b>Model</b>                 | RG-EG210G-E                                                                                                                        |
| <b>CPU</b>                   | Dual-core CPU with the clock speed of 1.35GHz                                                                                      |
| <b>Flash Memory</b>          | 16MB                                                                                                                               |
| <b>SDRAM</b>                 | DDRIII 256MB                                                                                                                       |
| <b>Power Module</b>          | AC input:<br>Rated voltage range: 100V to 240V<br>Maximum voltage range: 90V to 264V<br>Frequency: 50/60 Hz<br>Rated current: 0.6A |
| <b>Earth Leakage Current</b> | ≤3.5mA                                                                                                                             |
| <b>EEE</b>                   | Not supported                                                                                                                      |
| <b>PoE</b>                   | Not supported                                                                                                                      |
| <b>Power Consumption</b>     | < 15W                                                                                                                              |
| <b>Working Temperature</b>   | 0°C to 40°C (32°F to 104°F)                                                                                                        |
| <b>Storage Temperature</b>   | -40°C to 70°C (-40°F to 158°F)                                                                                                     |
| <b>Working Humidity</b>      | 10% to 90% RH                                                                                                                      |
| <b>Storage Humidity</b>      | 5% to 95% RH                                                                                                                       |
| <b>Fan</b>                   | N/A                                                                                                                                |

|                     |                                                                    |
|---------------------|--------------------------------------------------------------------|
| Temperature Warning | Not supported                                                      |
| Certification       | CE                                                                 |
| Dimensions          | Width: 440mm<br>Depth: 201.5mm (including panel)<br>Height: 43.6mm |
| Weight              | 2.35kg                                                             |

 **Warning**

Operation of this equipment in a residential environment could cause radio interference.

1.2 Appearance

Figure 1-1 Appearance of RG-EG210G-E






Figure 1-2 Front Panel of RG-EG210G-E



**Caution**

Reset button: Press the button for less than 2 seconds, the system will restart; press for more than 5 seconds until the system status LED blinks, the system will restore the factory settings and restart. After the device restores the factory settings, the default management address is <http://192.168.110.1>.

Figure 1-3 Back Panel of RG-EG210G-E



## 1.3 Power Supply

The RG-EG210G-E router adopts AC power input.

- AC input:

Rated voltage range: 100V to 240V, 50Hz/60Hz

Maximum voltage range: 90V to 264V, 47Hz to 63Hz

Frequency: 50Hz/60Hz

Rated current: 0.6A

Power cord: 10A power cord

## 1.4 Heat Dissipation

The RG-EG210G-E adopts natural heat dissipation, thereby ensuring normal function of the device in the specified environment. 10 cm distance space should be reserved at both sides and the back plane of the cabinet to allow air circulation. It is recommended to clean the device once every 3 months to avoid dust from blocking vents.

## 1.5 Port

| Port | Description                                                             |
|------|-------------------------------------------------------------------------|
| WAN  | 1 WAN port, used to connect to the DSL/Cable modem for Internet access. |
| LAN  | 9 LAN ports, used to connect to the computer, switch or AP.             |

## 1.6 LED Indicator

| LED Indicator | Description                                                                                                                                                                                                                                                                                              |
|---------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Status        | <ul style="list-style-type: none"><li>● Blinking green (0.5Hz): The device is not connected to Ruijie Cloud.</li><li>● Solid green: The device has started up, and is connected to Ruijie Cloud.</li><li>● Blinking green (10Hz): The device is restoring the factory settings or starting up.</li></ul> |
| Link/ACT      | <ul style="list-style-type: none"><li>● Solid green: The port is up.</li><li>● Blinking green: Data are being forwarded on the port.</li></ul>                                                                                                                                                           |

# 2 Preparation before Installation

## 2.1 Safety Suggestions

---

### Note

- To avoid personal injury and equipment damage, please carefully read the safety suggestions before you install the RG-EG210G-E router.
  - The following safety suggestions do not cover all possible dangers.
- 

### 2.1.1 Installation

- Keep the chassis clean and free from any dust.
- Do not place the equipment in a walking area.
- Do not wear loose clothes or accessories that may be hooked or caught by the device during installation and maintenance.

### 2.1.2 Movement

- Do not frequently move the device.
- When moving the device, note the balance and avoid hurting legs and feet or straining the back.
- Before moving the device, turn off all power supplies and dismantle all power modules.

### 2.1.3 Electricity

- Observe local regulations and specifications when performing electric operations. Relevant operators must be qualified.
- Before installing the device, carefully check any potential danger in the surroundings, such as ungrounded power supply, and damp/wet ground or floor.
- Before installing the device, find out the location of the emergency power supply switch in the room. First cut off the power supply in the case of an accident.
- Try to avoid maintaining the switch that is powered-on alone.
- Be sure to make a careful check before you shut down the power supply.
- Do not place the equipment in a damp location. Do not let any liquid enter the chassis.

---

### Caution

- Any non-standard and inappropriate electric operations may cause an accident such as a fire or electrical shock, thus causing severe even fatal damage to human bodies and equipment.
  - Direct or indirect touch through a wet object on high-voltage and commercial electricity may bring a fatal danger.
-

- If a power supply system is equipped with a leakage protector (also referred to as "leakage current switch" or "leakage current breaker"), the rated leakage action current of each leakage protector is greater than twice of the theoretical maximum leakage current of all the power supplies in the system. For example, if a system is equipped with eight identical power supplies, the leakage current of each power supply is equal to or less than 3.5 mA, and the leakage current of the system totals 56 mA. A leakage protector with 30 mA rated action current supports less than five power supplies (that is, Action current of the leakage protector/2/Maximum leakage current of each power supply =  $30/2/3.5 = 4.28$ ). In other words, the leakage protector with 30 mA rated action current supports no more than four power supplies. In this case, the sixteen power supplies in the system require at least four leakage protectors with 30 mA rated action current and each leakage protector supports four power supplies. If power supplies in a system differ in models, the rated leakage action current of each leakage protector divided by two is greater than the sum of maximum leakage currents of all the power supplies. The rated leakage non-action current of a leakage protector shall be 50% of the leakage action current. Take a leakage protector with 30 mA rated leakage action current as an example. The rated leakage non-action current shall be 15 mA. When the leakage current is below 15 mA, the protector shall not act. Otherwise, misoperation may easily occur due to high sensitivity and thus the leakage protector trips, devices are powered off, and services are interrupted.
  - To guarantee personal safety, the rated leakage action current of each leakage protector in the system must be equal to or less than 30 mA (human body safety current is 30 mA). When twice of the total leakage current of the system is greater than 30 mA, the system must be equipped with two or more leakage protectors.
  - For the leakage current value of each power supply model, see the power supply model parameter table in Chapter 1.
- 

### 2.1.4 Static Discharge Damage Prevention

To prevent damage from static electricity, pay attention to the following:

- Proper grounding of grounding screws on the back panel of the device.
- Indoor dust prevention
- Proper humidity conditions

## 2.2 Installation Site Requirements

To ensure the normal working and a prolonged durable life of the equipment, the installation site must meet the following requirements.

### 2.2.1 Installation Site

If the router is installed in the cabinet, the following requirements shall be met:

- Make sure sufficient room has been reserved for the air intake and air vent of router to facilitate the heat elimination of the router chassis.
- Make sure the cabinet is equipped with a good ventilation and cooling system.
- Make sure the cabinet and workbench is steady enough and capable of withstanding the weight of the router and its accessories.
- Make sure the cabinet is properly grounded.

## 2.2.2 Ventilation

For the RG-EG210G-E router, a sufficient space (at least 10 cm distances from both sides and the back plane of the cabinet) should be reserved at the ventilation openings to ensure the normal ventilation. After various cables have been connected, they should be arranged into bundles or placed on the cabling rack to avoid blocking the air inlets. It is recommended to clean the router at regular intervals (like once every 3 months). Especially, avoid dust from blocking the screen mesh on the back of the cabinet.

## 2.2.3 Temperature and Humidity

To ensure the normal operation and prolong the service life of router, you should keep proper temperature and humidity in the equipment room.

If the equipment room has temperature and humidity that do not meet the requirements for a long time, the equipment may be damaged.

- In an environment with high relative humidity, the insulating material may have bad insulation or even leak electricity. Sometimes the materials may suffer from mechanical performance change and metallic parts may get rusted.
- In an environment with low relative humidity, however, the insulating strip may dry and shrink. Static electricity may occur easily and endanger the circuit on the equipment.
- In an environment with high temperature, the equipment is subject to even greater harm, as its performance may degrade significantly and various hardware faults may occur.

**Table 2-1 Temperature and Humidity Requirements of the RG-EG210G-E Series Router**

| Temperature                  | Relative Humidity           |
|------------------------------|-----------------------------|
| 0 °C to 40°C (32°F to 104°F) | 10% to 90% (-40°F to 158°F) |

### Note

The ambient temperature and humidity of the device are measured at the point that is 1.5 m (59.06 in.) above the floor and 0.4 m (15.75 in.) before the device rack when there is no protective plate in front or at the back of the rack.

## 2.2.4 Cleanness

Dust poses a severe threat to the running of the equipment. The indoor dust falling on the equipment may be adhered by the static electricity, causing bad contact of the metallic joint. Such electrostatic adherence may occur more easily when the relative humidity is low, not only affecting the useful life of the equipment, but also causing communication faults.

**Table 2-2 Requirements for the Dust Content and Granularity in the Equipment Room**

| Dust                        | Unit                         | Density                |
|-----------------------------|------------------------------|------------------------|
| Diameter $\geq$ 0.5 $\mu$ m | Particles/<br>m <sup>3</sup> | $\leq 3.5 \times 10^6$ |
| Diameter $\geq$ 5 $\mu$ m   | Particles/<br>m <sup>3</sup> | $\leq 3 \times 10^4$   |

Apart from dust, the salt, acid and sulfide in the air in the equipment room must also meet strict requirements, as such poisonous substances may accelerate the corrosion of the metal and the aging of some parts. The equipment room should be protected from the intrusion of harmful gases such as sulfur dioxide, sulfured hydrogen, nitrogen dioxide, and chlorine.

**Table 2-3 Requirements for Harmful Gases in the Equipment Room**

| Gas              | Average (mg/m3) | Maximum (mg/m3) |
|------------------|-----------------|-----------------|
| SO <sub>2</sub>  | 0.3             | 1.0             |
| H <sub>2</sub> S | 0.1             | 0.5             |
| NO <sub>2</sub>  | 0.5             | 1.0             |
| Cl <sub>2</sub>  | 0.1             | 0.3             |

## 2.2.5 Grounding

A good grounding system is the basis for the stable and reliable operation of the RG-EG210G-E series router. It is the chief condition to prevent lightning stroke and resist interference. Please carefully check the grounding conditions on the installation site according to the grounding requirements, and perform grounding operations properly as required.

### Safety Grounding

The equipment using AC power supply must be grounded by using the yellow/green safety grounding cable. Otherwise, when the insulating resistance decreases the power supply and the enclosure in the equipment, electric shock may occur.



### Caution

- The building must provide protective grounding connection to ensure that the device is connected to the protection location.
- CE warning: Operation of this equipment in a residential environment could cause radio interference..

### Lightning Grounding

The lightning protection system of a facility is an independent system that consists of the lightning rod, downlead conductor and the connector to the grounding system, which usually shares the power reference ground and yellow/green safety cable ground. The lightning discharge ground is for the facility only, irrelevant to the equipment.

### EMC Grounding

The grounding required for EMC design includes shielding ground, filter ground, noise and interference suppression, and level reference. All the above constitute the comprehensive grounding requirements. The resistance of earth wires should be less than 1Ω. The RG-EG210G-E series router's back plane is reserved with one grounding pole.

### 2.2.6 EMI

Electro-Magnetic Interference (EMI), from either outside or inside the equipment or application system, affects the system in the conductive ways such as capacitive coupling, inductive coupling, and electromagnetic radiation.

There are two types of electromagnetic interference: radiated interference and conducted interference, depending on the type of the transmission path.

When the energy, often RF energy, from a component arrives at a sensitive component via the space, the energy is known as radiated interference. The interference source can be either a part of the interfered system or a completely electrically isolated unit. Conducted interference results from the electromagnetic wire or signal cable connection between the source and the sensitive component, along which cable the interference conducts from one unit to another. Conducted interference often affects the power supply of the equipment, but can be controlled by a filter. Radiated interference may affect any signal path in the equipment and is difficult to shield.

- For the AC power supply system TN, single-phase three-core power socket with protective earthing conductors (PE) should be adopted to effectively filter out interference from the power grid through the filtering circuit.
- The grounding device of the router must not be used as the grounding device of the electrical equipment or anti-lightning grounding device. In addition, the grounding device of the router must be deployed far away from the grounding device of the electrical equipment and anti-lightning grounding device.
- Keep the equipment away from high-power radio transmitter, radar transmitting station, and high-frequency large-current device.
- Measures must be taken to shield static electricity.

## 2.3 Installation Tool Requirements

Table 2-4 List of Installation Tools

|                      |                                                                                           |
|----------------------|-------------------------------------------------------------------------------------------|
| <b>Common Tools</b>  | Phillips screwdriver, related copper and fiber cables, bolts, diagonal pliers, cable ties |
| <b>Special Tools</b> | Wire stripper, crimping pliers, RJ-45 crimping pliers, punch down tool                    |
| <b>Meter</b>         | Multimeter                                                                                |



#### Note


The tool kit is customer-supplied.

# 3 Installing the Router

## 3.1 Installation Flowchart

Please take the following steps:

**Figure 3-1 Installation Flowchart**



## 3.2 Confirmations before Installation

Before installation, please confirm the following points:

- Whether ventilation requirements are met for the device
- Whether the requirements of temperature and humidity are met for the device
- Whether power cables are already laid out and whether the requirements of electrical current are met
- Whether related network adaption lines are already laid out


## 3.3 Mounting the Router

### 3.3.1 Mounting the Router to a Standard 19-inch Cabinet

The RG-EG210G-E series routers follow the EIA standard dimensions and can be installed in 19-inch cabinet.

Step 1: Attach the mounting brackets to the router with the supplied screws, as shown in Figure 3-1.

**Figure 3-2 Attaching the Mounting Bracket to RG-EG210G-E**



Step 2: Use the supplied M6 screws and cage nuts to securely attach the mounting brackets to the cabinet.

#### Installation Steps

Reserve sufficient space for front and back doors of the cabinet for maintenance.

Mount the cabinet at the designed location as planned.

Install the appropriate cable management bracket and cables.

Install the tray and wiring layer on the cabinet according to the configuration of one cabinet with one device installed or one cabinet with multiple devices installed.

### 3.3.2 Mounting the Router to a Workbench

In some cases, users do not have the 19-inch standard cabinet. The common solution is to place the router on a clean workbench. The operation is simple as follows:

Step 1: Attach the four rubber pads to the four corners on the bottom.

Step 2: Place the router on the workbench and ensure good ventilation condition around the router.

## 3.4 Grounding the Router

RG-EG210G-E has a PGND on the back panel. First connect the PGND to the grounding lug of the rack and then connect the grounding lug to the grounding bar of the equipment room.

#### Precautions

- The sectional area of the grounding wire should be determined according to the possible maximum current. Cables of good conductor should be used.
- Do not use bare wire.
- The grounding electric resistance should be less than 1Ω.

---

**⚠ Caution**

- To guarantee the security of the body and the device, the router must be well-grounded. The grounding resistance for combined grounding should be less than  $1\Omega$ .
  - The maintenance personnel shall check whether or not the AC socket powering the router is well connected to the building protective earth (PE). If not, the personnel shall connect the grounding lug of the AC socket with the PE by using a grounding connector.
  - The AC socket shall be installed near the equipment and shall be easily used.
  - When installing the router, make sure the grounding is connected first and disconnected last.
  - The cross-sectional area of PE conductor shall be at least  $2.5\text{ mm}^2$  (12AWG).
- 

### 3.5 Installing Power Cables

RG-EG210G-E series router uses 3-conductor power cables. You are suggested to use a single-phase 3-conductor outlet or a multifunction microcomputer outlet with neutral connector. The neutral point of the power supply shall be securely grounded in the building. In most buildings, the neutral point of a power supply has been grounded during the construction. You need to make sure the power supply is properly grounded.

Please take the following steps:

- Plug one end of the power cable into the power socket on the backpanel of the router, and plug the other end into the AC power supply outlet.
- Check whether the power LED on the front panel of the router lights up or not. The LED indicator will light up if the power supply is properly connected.

### 3.6 Connecting the External Port Cables

Step 1: Connect one end of the RJ45 connector to the Ethernet interface of the device board, and the other end to the NMS or a control terminal.

Step 2: Insert the twisted pair with the RJ45 port into the appropriate interface according to the identification on the panel of the module. Distinguish the crossover cable and straight-through cable.

### 3.7 Installation Verification

#### Verifying the Cabinet

- Verify if the external power supply matches the distribution panel of the cabinet.
- After equipment is installed, verify if the front/back cabinet doors can be closed.
- Verify that the cabinet has been fastened completely, and does not move or tilt.
- Verify that the equipment has been installed in the cabinet, and all the cables have been fastened to the cabinet.

#### Verifying the Cables

- Verify that the fibers and twisted pairs match the ports.
- Verify that the cables have been bound properly.

# 4 System Debugging


## 4.1 Establishing the Debugging Environment

### Establishing the Debugging Environment

Connect the PC to the LAN port of the router, and configure the PC to obtain an IP address automatically.

Or connect the cable of AP to the LAN port of the router. After the AP is powered on, it will broadcast the SSID starting with @Ruijie-m. You can connect to the SSID for configuration.

Figure 4-1 Schematic Diagram of the Configuration Environment



## 4.2 Startup Check

### 4.2.1 Checking before the Device is Powered on

- The router is fully grounded.
- The power cable is correctly connected.
- The power supply voltage complies with the requirement of the router.
- The cable of the PC is properly connected to the LAN port of the router. The parameter settings are correct.


### 4.2.2 Checking after Program Startup (Recommended)

After power-on, you are recommended to perform the following checks to ensure the normal operation of follow-up configurations.

- Check whether the status of the device indicator is normal.

## 4.3 Log In to the Web Interface

- (1) Start up the PC and configure the local connection attribute on the PC. Change the static IP address of the PC to 192.168.110.XXX (1–255, excluding 1).



- (2) Open a browser, enter 192.168.110.1 into the address bar of the browser, and press **Enter**.

---

### Caution

Use the default password "admin" to log in to the switch for the first time. To ensure security, you are advised to change the password after login, and update the password regularly.


---

## 4.4 Configuring Router

To use the router, more configuration should be made on the device. Please refer to the corresponding configuration guide.

# 5 Maintenance and Troubleshooting

## 5.1 General Troubleshooting Procedure



## 5.2 Troubleshooting Common Faults

| Symptom                                                     | Possible Causes                                        | Solution                                                                                                                     |
|-------------------------------------------------------------|--------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------|
| Forgetting the login password                               | A password is manually configured but it is forgotten. | Press the Reset Button for more than 5 seconds to restore the default password.                                              |
| The status indicator is not on after the device is started. | The power supply module does not supply power.         | Check whether the power socket at the equipment room is normal and whether the power cable of the device is in good contact. |

## Appendix A Connectors and Connection Media


### 1000BASE-T/100BASE-TX/10BASE-T Ports

The 1000BASE-T/100BASE-TX/10BASE-T is a port that supports adaptation of three rates, and automatic MDI/MDIX Crossover at these three rates.

The 1000BASE-T complies with IEEE 802.3ab, and uses the cable of 100-ohm Category-5 or Supper Category-5 UTP or STP, which can be up to 100 m.

The 1000BASE-T port uses four pairs of wires for transmission, all of which must be connected. Figure A-1 shows the connections of the twisted pairs used by the 1000BASE-T port.

Figure A-1 Four Twisted Pairs of the 1000BASE-T




In addition to the above cables, the 100BASE-TX/10BASE-T can also use 100-ohm Category-3, 4, 5 cables for 10 Mbps, and 100-ohm Category-5 cables for 100 Mbps, both of which can be up to 100 m. Figure A-2 shows the pinouts of the 100BASE-TX/10BASE-T.

Figure A-2 Pinouts of the 100BASE-TX/10BASE-T

| Pin     | Socket                | Plug                  |
|---------|-----------------------|-----------------------|
| 1       | Input Receive Data+   | Output Transmit Data+ |
| 2       | Input Receive Data-   | Output Transmit Data- |
| 3       | Output Transmit Data+ | Input Receive Data+   |
| 6       | Output Transmit Data- | Input Receive Data-   |
| 4,5,7,8 | Not used              | Not used              |

Figure A-3 shows the straight-through and crossover cable connections for the 100BASE-TX/10BASE-T.


Figure A-3 Connections of the Twisted Pairs of the 100BASE-TX/10BASE-T



### Optical Fiber Connection

For the optical fiber ports, select single-mode or multiple-mode optical fibers for connection according to the fiber module connected. The connection schematic diagram is shown in Figure A-4:

**Figure A-4 Optical Fiber Connections**



## Appendix B: Cabling Recommendations in Installation

When the device is installed in standard 19-inch cabinets, the cables are tied in the binding rack on the cabinet by the cabling rack, and top cabling or bottom cabling is adopted according to the actual situation in the equipment room. All cable connectors should be placed at the bottom of the cabinet in an orderly manner instead of outside the cabinet easy to touch. Power cables are routed beside the cabinet, and top cabling or bottom cabling is adopted according to the actual situation in the equipment room, such as the position of the DC power distribution box, AC socket, or lightning protection box.

### Requirement for the minimum cable bend radius

- The bend radius of a power cord, communication cable, and flat cable should be greater than five times their respective diameters. The bend radius of these cables that often bend or suffer removal/insertion should be greater than seven times their respective diameters.
- The bend radius of a common coaxial cable should be greater than seven times its diameter. The bend radius of this type of cables that often bend or suffer removal/insertion should be greater than 10 times its diameter.
- The bend radius of a high-speed cable (SFP cable, for example) should be greater than five times its diameter. The bend radius of this type of cables that often bend or suffer removal/insertion should be greater than 10 times its diameter.


### Requirement for the minimum fiber bend radius

- The diameter of a fiber tray to hold fibers cannot be less than 25 times the diameter of the fiber.
- When moving an optical fiber, the bend radius of the fiber should be equal to or greater than 20 times the diameter of the fiber.
- During cabling of an optical fiber, the bend radius of the fiber should be equal to or greater than 10 times the diameter of the fiber.

### Precautions for Bundling up Cables


- Before bundling cables, correctly mark labels and stick the labels to cables where appropriate.
- Cables should be neatly and properly bundled, as shown in Figure D-1.

Figure B-1 Bundling Up Cables (1)




- Cables of different types (such as power cords, signal cables, and grounding cables) should be separated in cabling and bundling. When they are close, crossover cabling can be adopted. In the case of parallel cabling, power cords and signal cables should maintain a space equal to or greater than 30 mm.
- The binding rack and cabling slot inside and outside the cabinet should be smooth, without sharp corners.
- The metal hole traversed by cables should have a smooth and fully rounding surface or an insulated lining.
- Proper buckles should be selected to bundle up cables. It is forbidden to connect two or more buckles to bundle up cables.
- After bundling up cables with buckles, you should cut off the remaining part. The cut should be smooth and trim, without sharp corners, as shown in Figure D-2.

**Figure B-2 Bundling Up Cables (2)**



- When cables need to bend, you should first bundle them up. However, the buckle cannot be bundled within the bend area. Otherwise, significant stress may be generated in cables, breaking cable cores. As shown in Figure D-3.

**Figure B-3 Bundling Up Cables (3)**




- Cables not to be assembled or remaining parts of cables should be folded and placed in a proper position of

the cabinet or cabling slot. The proper position indicates a position that will not affect device running or cause device damage or cable damage during commissioning.

- The power cords cannot be bundled on the guide rails of moving parts.
- The power cables connecting moving parts such as door grounding wires should be reserved with some access after assembled. When the moving part reaches the installation position, the remaining part should not touch heat sources, sharp corners, or sharp edges. If heat sources cannot be avoided, high-temperature cables should be used.
- When using screw threads to fasten cable terminals, the bolt or screw must be tightly fastened, and anti-loosening measures should be taken, as shown in Figure D-4.

**Figure B-4 Cable Fastening**



- The hard power cable should be fastened by the terminal connection area to prevent stress.
- Do not use self-tapping screws to fasten terminals.
- Power cables of the same type and in the same cabling direction should be bundled up into cable bunches, with cables in cable bunches clean and straight.
- Binding by using buckles should be performed according to Table B-1.

| Cable Bunch Diameter (mm) | Binding Space (mm) |
|---------------------------|--------------------|
| 10                        | 80-150             |
| 10-30                     | 150-200            |
| 30                        | 200-300            |

- No knot is allowed in cabling or bundling.
- For solder-less terminal blocks (such as air switches) of the cold pressing terminal type, the metal part of the cold pressing terminal should not be exposed outside the terminal block when assemble