



OPEN Industry Standard, Flexible Architecture

GREEN Less Heat, Less Power Consumption

STABLE Robust Design, Quality Parts

Stable and
Reliable Solution

Server/Workstation
Motherboard

E3C246D4M-4L
E3C242D4M-4L

User Manual

English



Version 1.0

Published January 2019

Copyright©2019 ASRock Rack Inc. All rights reserved.

Copyright Notice:

No part of this documentation may be reproduced, transcribed, transmitted, or translated in any language, in any form or by any means, except duplication of documentation by the purchaser for backup purpose, without written consent of ASRock Rack Inc.

Products and corporate names appearing in this documentation may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

Disclaimer:

Specifications and information contained in this documentation are furnished for informational use only and subject to change without notice, and should not be constructed as a commitment by ASRock Rack. ASRock Rack assumes no responsibility for any errors or omissions that may appear in this documentation.

With respect to the contents of this documentation, ASRock Rack does not provide warranty of any kind, either expressed or implied, including but not limited to the implied warranties or conditions of merchantability or fitness for a particular purpose.

In no event shall ASRock Rack, its directors, officers, employees, or agents be liable for any indirect, special, incidental, or consequential damages (including damages for loss of profits, loss of business, loss of data, interruption of business and the like), even if ASRock Rack has been advised of the possibility of such damages arising from any defect or error in the documentation or product.



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

CALIFORNIA, USA ONLY

The Lithium battery adopted on this motherboard contains Perchlorate, a toxic substance controlled in Perchlorate Best Management Practices (BMP) regulations passed by the California Legislature. When you discard the Lithium battery in California, USA, please follow the related regulations in advance.

“Perchlorate Material-special handling may apply, see www.dtsc.ca.gov/hazardouswaste/perchlorate”

ASRock Rack's Website: www.ASRockRack.com

Contact Information

If you need to contact ASRock Rack or want to know more about ASRock Rack, you're welcome to visit ASRock Rack's website at www.ASRockRack.com; or you may contact your dealer for further information.

ASRock Rack Incorporation

6F., No.37, Sec. 2, Jhongyang S. Rd., Beitou District,

Taipei City 112, Taiwan (R.O.C.)

Contents

Chapter 1 Introduction	1
1.1 Package Contents	1
1.2 Specifications	2
1.3 Unique Features	6
1.4 Motherboard Layout	7
1.5 Onboard LED Indicators	13
1.6 I/O Panel	15
1.7 Block Diagram	17
Chapter 2 Installation	18
2.1 Screw Holes	18
2.2 Pre-installation Precautions	18
2.3 Installing the CPU	19
2.4 Installing the CPU Fan and Heatsink	21
2.5 Installation of Memory Modules (DIMM)	22
2.6 Expansion Slots (PCI Express Slots)	24
2.7 Jumper Setup	25
2.8 Onboard Headers and Connectors	27
2.9 Dr. Debug	34
2.10 Unit Identification purpose LED/Switch	35
2.11 Driver Installation Guide	35
2.12 Dual LAN and Teaming Operation Guide	36
2.13 M.2_SSD (NGFF) Module Installation Guide	37

Chapter 3 UEFI Setup Utility	40
3.1 Introduction	40
3.1.1 UEFI Menu Bar	40
3.1.2 Navigation Keys	41
3.2 Main Screen	42
3.3 Advanced Screen	43
3.3.1 CPU Configuration	44
3.3.2 DRAM Configuration	47
3.3.3 Chipset Configuration	48
3.3.4 Storage Configuration	50
3.3.5 ACPI Configuration	51
3.3.6 USB Configuration	52
3.3.7 Super IO Configuration	53
3.3.8 Serial Port Console Redirection	54
3.3.9 H/W Monitor	57
3.3.10 Runtime Error Logging	59
3.3.11 Intel SPS Configuration	60
3.3.12 Intel(R) Bios Guard Technology	61
3.3.13 Instant Flash	62
3.4 Server Mgmt	63
3.4.1 System Event Log	64
3.4.2 BMC Network Configuration	65
3.5 Security	67
3.5.1 Key Management	68

3.6	Boot Screen	72
3.6.1	CSM Parameters	74
3.7	Event Logs	76
3.8	Exit Screen	77
Chapter 4 Software Support		78
4.1	Install Operating System	78
4.2	Support CD Information	78
4.2.1	Running The Support CD	78
4.2.2	Drivers Menu	78
4.2.3	Utilities Menu	78
4.2.4	Contact Information	78
Chapter 5 Troubleshooting		79
5.1	Troubleshooting Procedures	79
5.2	Technical Support Procedures	81
5.3	Returning Merchandise for Service	81

Chapter 1 Introduction

Thank you for purchasing ASRock Rack **E3C246D4M-4L / E3C242D4M-4L** motherboard, a reliable motherboard produced under ASRock Rack's consistently stringent quality control. It delivers excellent performance with robust design conforming to ASRock Rack's commitment to quality and endurance.

In this manual, chapter 1 and 2 contains introduction of the motherboard and step-by-step guide to the hardware installation. Chapter 3 and 4 contains the configuration guide to BIOS setup and information of the Support CD.



Because the motherboard specifications and the BIOS software might be updated, the content of this manual will be subject to change without notice. In case any modifications of this manual occur, the updated version will be available on ASRock Rack website without further notice. You may find the latest memory and CPU support lists on ASRock Rack website as well. ASRock Rack's Website: www.ASRockRack.com

*If you require technical support related to this motherboard, please visit our website for specific information about the model you are using.
<http://www.asrockrack.com/support/>*

1.1 Package Contents

- ASRock Rack E3C246D4M-4L / E3C242D4M-4L Motherboard
(ATX Form Factor: 12-in x 9.6-in, 30.5 cm x 24.4 cm)
- Quick Installation Guide
- 1 x SATA3 Cable (60cm)
- 1 x I/O Shield
- 1 x Screw for M.2 Socket



If any items are missing or appear damaged, contact your authorized dealer.

1.2 Specifications

E3C246D4M-4L / E3C242D4M-4L	
MB Physical Status	
Form Factor	ATX
Dimension	12" x 9.6" (30.5 cm x 24.4 cm)
Processor System	
CPU	Supports Intel® Xeon® E-2100 Processors
Chipset	E3C246D4M-4L: Intel® C246
	E3C242D4M-4L: Intel® C242
System Memory	
Capacity	- 4 x 288-pin DDR4 DIMM slots - Support up to 64GB DDR4 ECC/non-ECC UDIMM
Type	- Dual Channel DDR4 memory technology - Supports DDR4 2666/2400 ECC/non-ECC U DIMM
DIMM Size Per DIMM	ECC and non-EDD UDIMM : 64GB, 32GB, 16GB, 8GB, 4GB
DIMM Frequency	- ECC UDIMM: 2666/2400/2133 MHz - Non-ECC UDIMM: 2666/2400/2133 MHz
Voltage	1.2V
Expansion Slot	
PCIe 3.0 x16	SLOT6: Gen3 x16 link (when Mezz slot used, Slot6 Gen3 x8)
PCIe 3.0 x8	SLOT2: Gen3 x8 link (ME), Gen3 x4 link(EE)
PCIe 3.0 x1	E3C246D4M-4L: - SLOT5: Gen3 x1 link - SLOT4: Gen3 x1 link - SLOT3: Gen3 x1 link
	E3C242D4M-4L: N/A
Mezz Slot	1 (shared with Slot6), supports M350, M540, M599, M710
Storage	
SATA Controller	E3C246D4M-4L: -C246: 8x SATA3 6Gb/s (SATA0-7, SATA0 support SATA DOM, and are shared with M.2(PCIE3.0(X4)))/ SATA3 6Gb/s), support RAID 0, 1, 5, 10
	E3C242D4M-4L: -C242: 6x SATA3 6Gb/s (SATA0-5, SATA0 support SATA DOM, and are shared with M.2(PCIE3.0(X2)))/ SATA3 6Gb/s), support RAID 0, 1, 5, 10

Ethernet	
Interface	1000 /100 /10 Mbps
LAN	- 3 x RJ45 GLAN by Intel® i210 - 1 x RJ45 GLAN by Intel® i219 - Supports Wake-On-LAN - Supports Energy Efficient Ethernet 802.3az - Supports Dual LAN with Teaming function(TBD) - Supports PXE - LAN2 supports NCSI
Management	
BMC Controller	ASPEED AST2500
IPMI Dedicated GLAN	1 x Realtek RTL8211E for dedicated management GLAN
Features	- Watch Dog - NMI
Graphics	
Controller	ASPEED AST2500
VRAM	DDR4 16MB
Rear Panel I/O	
VGA Port	1 x D-Sub
USB 3.1 Port	E3C246D4M-4L: 4(GEN2) E3C242D4M-4L: 2(GEN2), 2(GEN1)
LAN Port	- 4 +1 RJ45 Gigabit Ethernet LAN ports - LAN Ports with LED (ACT/LINK LED and SPEED LED)
UID Button/LED	1
Serial port	1
Internal Connector	
Auxiliary Panel Header	1 (include chassis intrusion , location button & LED, front LAN LED, event log LED, and FSMB)
SATA DOM	1 (SATA 0, share with M.2)
TPM Header	1
IPMB Header	1
80 debug port LED	1
Front Panel	1 (RST, PWRBTN, HDDLED, PWRLED)
Fan Header	6 (1xCPU/4xFront/1xRear)
ATX Power	1x (24-pin) + 1x (8-pin)
Speaker	1(4pin)
TR1	1

Buzzer	1
SGPIO	2
BMC_SMB1	1
PSU_SMB1	1
Smbus from BMC	1
PWR_SMB	1
USB 3.0 Type A	1 (by bom option for USB3.0 or USB2.0) * when USB 2.0 Type Ax1, USB 3.0 header x 2 port * when USB 3.0 Type Ax1, USB 3.0header x1 port
USB 3.0 Header	1 (support 2 USB 3.0, by bom option for 2 port USB3.0 or 1 port USB3.0) * when 2 port USB 3.0, 1port USB 2.0 Type A * when 1 port USB 3.0, 1port USB 3.0 Type A
USB 2.0 Header	2 (support 4 USB 2.0)
M.2	E3C246D4M-4L: 1 (2230/2242/2260/2280, Supports PCIE3.0(X4)/SATA3) E3C242D4M-4L: 1 (2230/2242/2260/2280, Supports PCIE3.0(X2)/SATA3)
NMI Button	1 (Header)
ME/SPS recovery	1
ClearCMOS	1 (short pin)
OH/FanFail LED	6 (only Fan Fail LED)
System BIOS	
BIOS Type	256Mb AMI UEFI Legal BIOS
BIOS Features	-Plug and Play (PnP) -ACPI 2.0 Compliance Wake Up Events -SMBIOS 2.8.0 Support -ASRock Rack Instant Flash
Hardware Monitor	
Temperature	-CPU Temperature Sensing -System Temperature Sensing -MB / Card Side Temperature Sensing -TR1 Temperature Sensing
Fan	-CPU/Rear/Front Fan Tachometer -CPU Quiet Fan (Allow Chassis Fan Speed Auto-Adjust by CPU Temperature) -CPU/Rear/Front Fan Multi-Speed Control
Voltage	Voltage Monitoring: +12V, +5V, +3.3V, CPU Vcore, VCCM, VCCIO, VCCSA, VCCST_SFR,V1.0M, 3VSB, 5VSB, VBAT

Support OS	
OS	Microsoft® Windows® - Server 2012 R2 (64 bit) - Server 2016 (64 bit) - Server 2019 (64 bit) Linux® - RedHat Enterprise Linux Server 6.9 (64 bit) / 7.4 (64 bit) - SUSE Enterprise Linux Server 11 SP4 (64 bit) / 12 SP3 (64 bit) - Ubuntu 16.04 (64 bit) / 18.04 (64 bit) Virtual - VMWare® ESXi 6.5 u1 - Win hyper-V Server 2016 <i>*Please refer to our website for the latest OS support list.</i>
Environment	
Temperature	Operation temperature: 10°C ~ 35°C / Non operation temperature: -40°C ~ 70°C



This motherboard supports Wake from on Board LAN. To use this function, please make sure that the "Wake on Magic Packet from power off state" is enabled in Device Manager > Intel® Ethernet Connection > Power Management. And the "PCI Devices Power On" is enabled in UEFI SETUP UTILITY > Advanced > ACPI Configuration. After that, onboard LAN1&2 can wake up S5 under OS.




If you install Intel® LAN utility or Marvell SATA utility, this motherboard may fail Windows® Hardware Quality Lab (WHQL) certification tests. If you install the drivers only, it will pass the WHQL tests.

1.3 Unique Features

ASRock Rack Instant Flash is a BIOS flash utility embedded in Flash ROM. This convenient BIOS update tool allows you to update system BIOS without entering operating systems first like MS-DOS or Windows®. With this utility, you can press the <F6> key during the POST or the <F2> key to enter into the BIOS setup menu to access ASRock Rack Instant Flash. Just launch this tool and save the new BIOS file to your USB flash drive, floppy disk or hard drive, then you can update your BIOS only in a few clicks without preparing an additional floppy diskette or other complicated flash utility. Please be noted that the USB flash drive or hard drive must use FAT32/16/12 file system.

1.4 Motherboard Layout

E3C246D4M-4L



No.	Description
1	BMC SMBus Header (BMC_SMB_1)
2	ATX 12V Power Connector (ATX12V1)
3	Intelligent Platform Management Bus Header (IPMB_1)
4	ME Recovery Jumper (ME_RECOVERY1)
5	PWM Configuration Header (PWM_CFG1)
6	Rear Fan Connector (REAR_FAN1)
7	PSU SMBus (PSU_SMB1)
8	ATX Power Connector (ATXPWR1)
9	2 x 288-pin DDR4 DIMM Slots (DDR4_A1, DDR4_B1, Blue)
10	2 x 288-pin DDR4 DIMM Slots (DDR4_A2, DDR4_B2, White)
11	CPU Fan Connector (CPU_FAN1)
12	Front Fan Connector (FRNT_FAN1)
13	Front Fan Connector (FRNT_FAN2)
14	Front Fan Connector (FRNT_FAN3)
15	SATA3 DOM Connector (SATA_0), Red
16	SATA3 Connector (SATA_1)
17	SATA SGPIO Connector (SATA_SGPIO1)
18	SATA SGPIO Connector (SATA_SGPIO2)
19	SATA DOM Power Jumper (SATAPWR1)
20	CPU PECI Mode Jumper (PECI1)
21	SATA DOM Power Header (SATA_PWR1)
22	Front Fan Connector (FRNT_FAN4)
23	SATA3 Connector (SATA_2)
24	SATA3 Connector (SATA_3)
25	SATA3 Connector (SATA_4)
26	SATA3 Connector (SATA_5)
27	SATA3 Connector (SATA_6)
28	SATA3 Connector (SATA_7)
29	Chassis Speaker Header (SPEAKER1)
30	System Panel Header (PANEL1)
31	Auxiliary Panel Header (AUX_PANEL1)
32	USB 2.0 Header (USB_1_2)
33	Flash Descriptor Security Override Jumper (SEC_OR1)

No.	Description
34	USB 2.0 Header (USB_3_4)
35	Vertical Type A USB 3.1 Gen1 Connector (USB31_7)
36	USB 3.1 Gen1 Header (USB31_5_6)
37	TPM Header (TPM1)
38	PCIE Card Slot 2 (PCIE2) (ME x8, EE x4, from PCH)
39	PCIE Card Slot 3 (PCIE3) (x1, from PCH)
40	Clear CMOS Pad (CLRMOS1)
41	PCIE Card Slot 4 (PCIE4) (x1, from PCH)
42	PCIE Card Slot 5 (PCIE5) (x1, from PCH)
43	M.2 Socket (M2_1) (Type 2230/2242/2260/2280/22110)
44	PCIE Card Slot 6 (PCIE6) (x16, from CPU)
45	Mezzaine Card Slot (MEZZ_1)
46	NCSI Mode Jumper (NCSI_SEL1)
47	LAN LED Connector (LED_LAN_3_4)
48	LAN LED Connector (LED_LAN_5_6)

For DIMM installation and configuration instructions, please see p.22 (Installation of Memory Modules (DIMM)) for more details.

English




No.	Description
1	BMC SMBus Header (BMC_SMB_1)
2	ATX 12V Power Connector (ATX12V1)
3	Intelligent Platform Management Bus Header (IPMB_1)
4	ME Recovery Jumper (ME_RECOVERY1)
5	PWM Configuration Header (PWM_CFG1)
6	Rear Fan Connector (REAR_FAN1)
7	PSU SMBus (PSU_SMB1)
8	ATX Power Connector (ATXPWR1)
9	2 x 288-pin DDR4 DIMM Slots (DDR4_A1, DDR4_B1, Blue)
10	2 x 288-pin DDR4 DIMM Slots (DDR4_A2, DDR4_B2, White)
11	CPU Fan Connector (CPU_FAN1)
12	Front Fan Connector (FRNT_FAN1)
13	Front Fan Connector (FRNT_FAN2)
14	Front Fan Connector (FRNT_FAN3)
15	SATA3 DOM Connector (SATA_0), Red
16	SATA3 Connector (SATA_1)
17	SATA SGPIO Connector (SATA_SGPIO1)
18	SATA SGPIO Connector (SATA_SGPIO2)
19	SATA DOM Power Jumper (SATAPWR1)
20	CPU PECI Mode Jumper (PECI1)
21	SATA DOM Power Header (SATA_PWR1)
22	Front Fan Connector (FRNT_FAN4)
23	SATA3 Connector (SATA_2)
24	SATA3 Connector (SATA_3)
25	SATA3 Connector (SATA_4)
26	SATA3 Connector (SATA_5)
27	Chassis Speaker Header (SPEAKER1)
28	System Panel Header (PANEL1)
29	Auxiliary Panel Header (AUX_PANEL1)
30	USB 2.0 Header (USB_1_2)
31	Flash Descriptor Security Override Jumper (SEC_OR1)
32	USB 2.0 Header (USB_3_4)
33	Vertical Type A USB 3.1 Gen1 Connector (USB31_7)

No.	Description
34	USB 3.1 Gen1 Header (USB31_5_6)
35	TPM Header (TPM1)
36	PCIE Card Slot 2 (PCIE2) (ME x8, EE x4, from PCH)
37	Clear CMOS Pad (CLRMOS1)
38	M.2 Socket (M2_1) (Type 2230/2242/2260/2280/22110)
39	PCIE Card Slot 6 (PCIE6) (x16, from CPU)
40	Mezzaine Card Slot (MEZZ_1)
41	NCSI Mode Jumper (NCSI_SEL1)
42	LAN LED Connector (LED_LAN_3_4)
43	LAN LED Connector (LED_LAN_5_6)


For DIMM installation and configuration instructions, please see p.22 (Installation of Memory Modules (DIMM)) for more details.

1.5 Onboard LED Indicators



No.	Item	Status	Description
1	SB_PWR1	Green	STB PWR ready
2	FAN_LED1	Amber	CPU_FAN1 failed
3	FRNT_FAN1_LED1	Amber	Front_FAN1 failed
4	FRNT_FAN2_LED2	Amber	Front_FAN2 failed
5	FRNT_FAN3_LED3	Amber	Front_FAN3 failed
6	FRNT_FAN4_LED4	Amber	Front_FAN4 failed
7	BMC_LED1	Green	BMC heartbeat LED
8	REAR_FAN1_LED1	Amber	Rear_FAN1 failed

1.6 I/O Panel




No.	Description	No.	Description
1	VGA Port (VGA1)	6	LAN RJ-45 Port (LAN1)**
2	Serial Port (COM1)	7	LAN RJ-45 Port (LAN2)**
3	E3C246D4M-4L: USB 3.1 Gen2 Ports (USB31_1_2) E3C242D4M-4L: USB 3.1 Gen1 Ports (USB31_1_2)	8	LAN RJ-45 Port (LAN3)**
4	LAN RJ-45 Port (IPMI_LAN)*	9	LAN RJ-45 Port (LAN4)**
5	USB 3.1 Gen2 Ports (USB31_3_4)	10	UID Switch (UID1)

Note: LAN2 supports NCSI.

LAN Port LED Indications


*There are two LED next to the LAN port. Please refer to the table below for the LAN port LED indications.



Dedicated IPMI LAN Port LED Indications

Activity / Link LED		Speed LED	
Status	Description	Status	Description
Off	No Link	Off	10M bps connection or no link
Blinking Yellow	Data Activity	Yellow	100M bps connection
On	Link	Green	1Gbps connection


**There are two LEDs on each LAN port. Please refer to the table below for the LAN port LED indications.



LAN Port LED Indications

Activity / Link LED		Activity / Link LED	
Status	Description	Status	Description
Off	No Link	Off	10Mbps connection or no link
Blinking Green	Data Activity	Off	100Mbps connection
On	Link	Yellow	1Gbps connection

1.7 Block Diagram



Chapter 2 Installation

This is an ATX form factor (12" x 9.6", 30.5 cm x 24.4 cm) motherboard. Before you install the motherboard, study the configuration of your chassis to ensure that the motherboard fits into it.



Make sure to unplug the power cord before installing or removing the motherboard. Failure to do so may cause physical injuries to you and damages to motherboard components.

2.1 Screw Holes

Place screws into the holes indicated by circles to secure the motherboard to the chassis.



Do not over-tighten the screws! Doing so may damage the motherboard.

2.2 Pre-installation Precautions

Take note of the following precautions before you install motherboard components or change any motherboard settings.

1. Unplug the power cord from the wall socket before touching any components.
2. To avoid damaging the motherboard's components due to static electricity, NEVER place your motherboard directly on the carpet or the like. Also remember to use a grounded wrist strap or touch a safety grounded object before you handle the components.
3. Hold components by the edges and do not touch the ICs.
4. Whenever you uninstall any component, place it on a grounded anti-static pad or in the bag that comes with the component.
5. When placing screws into the screw holes to secure the motherboard to the chassis, please do not over-tighten the screws! Doing so may damage the motherboard.



Before you install or remove any component, ensure that the power is switched off or the power cord is detached from the power supply. Failure to do so may cause severe damage to the motherboard, peripherals, and/or components.

2.3 Installing the CPU




1. Before you insert the 1151-Pin CPU into the socket, please check if the PnP cap is on the socket, if the CPU surface is unclean, or if there are any bent pins in the socket. Do not force to insert the CPU into the socket if above situation is found. Otherwise, the CPU will be seriously damaged.
2. Unplug all power cables before installing the CPU.




Illustrations in this User Manual are provided for reference only and may slightly differ from actual product appearances.


1






2






3





Please save and replace the cover if the processor is removed. The cover must be placed if you wish to return the motherboard for after service.

2.4 Installing the CPU Fan and Heatsink



2.5 Installation of Memory Modules (DIMM)

This motherboard provides four 288-pin DDR4 (Double Data Rate 4) DIMM slots, and supports Dual Channel Memory Technology.



1. For dual channel configuration, you always need to install identical (the same brand, speed, size and chip-type) DDR4 DIMM pairs.
2. It is unable to activate Dual Channel Memory Technology with only one or three memory module installed.
3. It is not allowed to install a DDR, DDR2 or DDR3 memory module into a DDR4 slot; otherwise, this motherboard and DIMM may be damaged.


Dual Channel Memory Configuration

Priority	DDR4_A1	DDR4_A2	DDR4_B1	DDR4_B2
1		Populated		Populated
2	Populated		Populated	
3	Populated	Populated	Populated	Populated




The DIMM only fits in one correct orientation. It will cause permanent damage to the motherboard and the DIMM if you force the DIMM into the slot at incorrect orientation.


1



2



3



The DIMM only fits in one correct orientation. It will cause permanent damage to the motherboard and the DIMM if you force the DIMM into the slot at incorrect orientation.

2.6 Expansion Slots (PCI Express Slots)

There are 2 (E3C242D4M-4L) or 5 (E3C246D4M-4L) PCI Express slots on this motherboard.

PCIE slot:

E3C246D4M-4L / E3C242D4M-4L:

PCIE2 (PCIe 3.0 x8 slot) is used for PCI Express x4 lane width cards.

PCIE6 (PCIe 3.0 x16 slot) is used for PCI Express x16 lane width cards.

Slot	Generation	Mechanical	Electrical	Source
PCIE 6	3.0	x16	x16	CPU
PCIE 2	3.0	x8	x4	PCH

E3C246D4M-4L:

PCIE3, PCIE4 and PCIE5 (PCIe 3.0 x1 slot) are used for PCI Express x1 lane width cards.

Slot	Generation	Mechanical	Electrical	Source
PCIE 5	3.0	x1	x1	PCH
PCIE 4	3.0	x1	x1	PCH
PCIE 3	3.0	x1	x1	PCH

PCI Express Slot Configuration

The PCIE6 slot shares lanes with the mezzanine card slot (MEZZ_1). When MEZZ_1 is populated with a mezzanine card, the PCIE6 slot will operate at up to x8 mode.


PCIE6	
No mezzanine card	x16
MEZZ_1 is populated	x8

Installing an expansion card

- Step 1. Before installing an expansion card, please make sure that the power supply is switched off or the power cord is unplugged. Please read the documentation of the expansion card and make necessary hardware settings for the card before you start the installation.
- Step 2. Remove the system unit cover (if your motherboard is already installed in a chassis).
- Step 3. Remove the bracket facing the slot that you intend to use. Keep the screws for later use.
- Step 4. Align the card connector with the slot and press firmly until the card is completely seated on the slot.
- Step 5. Fasten the card to the chassis with screws.
- Step 6. Replace the system cover.

2.7 Jumper Setup

The illustration shows how jumpers are setup. When the jumper cap is placed on the pins, the jumper is “Short”. If no jumper cap is placed on the pins, the jumper is “Open”. The illustration shows a 3-pin jumper whose pin1 and pin2 are “Short” when a jumper cap is placed on these 2 pins.



ME Recovery Jumper
(3-pin ME_RECOVERY1)



Normal Mode (Default)



ME Recovery Mode

CPU PECI Mode Jumper
(3-pin PECI1)



CPU PECI connect to PCH



CPU PECI connect to BMC
(Default)

Flash Descriptor Security
Override Jumper
(3-pin SEC_OR1)



Descriptor Security Over-
ride



Normal Mode (Default)

NCSI Mode Jumper
(3-pin NCSI_SEL1)



NCSI is set to onboard
LAN1 (Default)



NCSI is set to Mezzanine
Card

SATA DOM Power Jumper
(3-pin SATAPWR1)



SATA DOM (SATA_0)
requires 5V power supply



SATA DOM (SATA_0) does
NOT require 5V power supply
(Default)



Consult the documentation that comes with your SATA DOM and check whether or not Pin 7 requires 5V power supply.

If the connected SATA DOM requires 5V power supply, move the jumper caps placed on the SATA DOM Power Jumper (SATAPWR1) from pins 2-3 (default) to pins 1-2.

If the connected SATA DOM does NOT require 5V power supply, connect the SATA DOM power cable to the SATA DOM power header (SATA_PWR1) and there is no need to change the default jumper setting of the SATA DOM Power Jumper (pins 2-3).


Warning! Incorrect setting of the SATA DOM Power Jumper (SATAPWR1) may cause damage to the motherboard or your SATA DOM.

2.8 Onboard Headers and Connectors



Onboard headers and connectors are NOT jumpers. Do NOT place jumper caps over these headers and connectors. Placing jumper caps over the headers and connectors will cause permanent damage to the motherboard.

System Panel Header (9-pin PANEL1)



Connect the power switch, reset switch and system status indicator on the chassis to this header according to the pin assignments. Particularly note the positive and negative pins before connecting the cables.



PWRBTN (Power Switch):

Connect to the power switch on the chassis front panel. You may configure the way to turn off your system using the power switch.

RESET (Reset Switch):

Connect to the reset switch on the chassis front panel. Press the reset switch to restart the computer if the computer freezes and fails to perform a normal restart.

PLED (System Power LED):


Connect to the power status indicator on the chassis front panel. The LED is on when the system is operating. The LED is off when the system is in S4 sleep state or powered off (S5).

HDLED (Hard Drive Activity LED):

Connect to the hard drive activity LED on the chassis front panel. The LED is on when the hard drive is reading or writing data.

The front panel design may differ by chassis. A front panel module mainly consists of power switch, reset switch, power LED, hard drive activity LED, speaker and etc. When connecting your chassis front panel module to this header, make sure the wire assignments and the pin assignments are matched correctly.

Auxiliary Panel Header
(18-pin AUX_PANEL_1)



This header supports multiple functions on the front panel, including the front panel SMB, internet status indicator and chassis intrusion pin.



- A. Front panel SMBus connecting pin (6-1 pin FPSMB)**
This header allows you to connect SMBus (System Management Bus) equipment. It can be used for communication between peripheral equipment in the system, which has slower transmission rates, and power management equipment.
- B. Internet status indicator (2-pin LAN1_LED, LAN2_LED)**
These two 2-pin headers allow you to use the Gigabit internet indicator cable to connect to the LAN status indicator. When this indicator flickers, it means that the internet is properly connected.
- C. Chassis intrusion pin (2-pin CHASSIS)**
This header is provided for host computer chassis with chassis intrusion detection designs. In addition, it must also work with external detection equipment, such as a chassis intrusion detection sensor or a microswitch. When this function is activated, if any chassis component movement occurs, the sensor will immediately detect it and send a signal to this header, and the system will then record this chassis intrusion event. The default setting is set to the CASEOPEN and GND pin; this function is off.
- D. Locator LED (4-pin LOCATOR)**
This header is for the locator switch and LED on the front panel.
- E. System Fault LED (2-pin LOCATOR)**
This header is for the Fault LED on the system.

Serial ATA3 Connectors

E3C246D4M-4L /**E3C242D4M-4L:**

(SATA_0)

(SATA_1)

(SATA_2)

(SATA_3)

(SATA_4)

(SATA_5)

E3C246D4M-4L:

(SATA_6)

(SATA_7)



These SATA3 connectors support SATA data cables for internal storage devices with up to 6.0 Gb/s data transfer rate.

Serial ATA3 DOM

Connector


(SATA_0)



The SATA3 DOM connector supports both a SATA DOM (Disk-On-Module) and a SATA data cable for internal storage device.

SATA Power Connector

(4-pin SATA_PWR1)




Please connect a SATA power cable to the SATA power connector.

USB 3.1 Gen1 Connector

(USB31_7)




USB 3.1 Gen1 Header
(19-pin USB31_5_6)




Besides four default USB 3.1 ports on the I/O panel, there is one USB 3.1 header on this motherboard. This USB 3.1 header can support two USB 3.1 ports.

USB 2.0 Headers
(9-pin USB_1_2)
(9-pin USB_3_4)



There are two USB 2.0 headers on this motherboard. Each USB 2.0 header can support two ports.

CPU Fan Connector
(4-pin CPU_FAN1)



This motherboard provides one 4-Pin CPU fan (Quiet Fan) connectors. If you plan to connect a 3-Pin CPU fan, please connect it to Pin 1-3.

**For more details, please refer to the Cooler QVL list on the ASRock Rack website.*


Front and Rear Fan Connectors

(4-pin FRNT_FAN1)


(4-pin FRNT_FAN2)

(4-pin FRNT_FAN3)


(4-pin FRNT_FAN4)




Please connect fan cables to the fan connectors and match the black wire to the ground pin. All fans support Fan Control.



(4-pin REAR_FAN1)




ATX Power Connector (24-pin ATXPWR1)




This motherboard provides a 24-pin ATX power connector. To use a 20-pin ATX power supply, please plug it along Pin 1 and Pin 13.

ATX 12V Power Connector (8-pin ATX12V1)




This motherboard provides one 8-pin ATX 12V power connector.

TPM Header
(17-pin TPM1)




This connector supports Trusted Platform Module (TPM) system, which can securely store keys, digital certificates, passwords, and data. A TPM system also helps enhance network security, protects digital identities, and ensures platform integrity.

Serial General Purpose
Input/Output Headers
(7-pin SATA_SGPIO1)
(7-pin SATA_SGPIO2)




The headers support Serial Link interface for onboard SATA connections.

PSU SMBus
(PSU_SMB1)




PSU SMBus monitors the status of the power supply, fan and system temperature.

Chassis Speaker Header
(4-pin SPEAKER1)




Please connect the chassis speaker to this header.

Intelligent Platform
Management Bus Header
(4-pin IPMB_1)




This 4-pin connector is used to provide a cabled base-board or front panel connection for value added features and 3rd-party add-in cards, such as Emergency Management cards, that provide management features using the IPMB.

Baseboard Management
Controller SMBus Header
(5-pin BMC_SMB_1)




The header is used for the
SMBUS devices.

LAN LED Connectors
(LED_LAN_3_4)




These 4-pin connectors are
used for the front LAN status
indicator.

(LED_LAN_5_6)



PWM Configuration
Header
(3-pin PWM_CFG1)



This header is used for PWM
configurations.

Clear CMOS Pad
(CLRMOS1)



This allows you to clear the
data in CMOS. To clear CMOS,
take out the CMOS battery and
short the Clear CMOS Pad.

2.9 Dr. Debug

Dr. Debug is used to provide code information, which makes troubleshooting even easier. Please see the diagrams below for reading the Dr. Debug codes.

Code	Description
00	Please check if the CPU is installed correctly and then clear CMOS.
0d	Problem related to memory, VGA card or other devices. Please clear CMOS, re-install the memory and VGA card, and remove other USB, PCI devices.
01 - 54 (except 0d), 5A- 60	Problem related to memory. Please re-install the CPU and memory then clear CMOS. If the problem still exists, please install only one memory module or try using other memory modules.
55	The Memory could not be detected. Please re-install the memory and CPU. If the problem still exists, please install only one memory module or try using other memory modules.
61 - 91	Chipset initialization error. Please press reset or clear CMOS.
92 - 99	Problem related to PCI-E devices. Please re-install PCI-E devices or try installing them in other slots. If the problem still exists, please remove all PCI-E devices or try using another VGA card.
A0 - A7	Problem related to IDE or SATA devices. Please re-install IDE and SATA devices. If the problem still exists, please clear CMOS and try removing all SATA devices.
b0	Problem related to memory. Please re-install the CPU and memory. If the problem still exists, please install only one memory module or try using other memory modules.
b4	Problem related to USB devices. Please try removing all USB devices.
b7	Problem related to memory. Please re-install the CPU and memory then clear CMOS. If the problem still exists, please install only one memory module or try using other memory modules.
d6	The VGA could not be recognized. Please clear CMOS and try re-installing the VGA card. If the problem still exists, please try installing the VGA card in other slots or use other VGA cards.
d7	The Keyboard and mouse could not be recognized. Please try re-installing the keyboard and mouse.
d8	Invalid Password.
FF	Please check if the CPU is installed correctly and then clear CMOS.

2.10 Unit Identification purpose LED/Switch

With the UID button, You are able to locate the server you're working on from behind a rack of servers.

Unit Identification
purpose LED/Switch
(UID)



When the UID button on the front or rear panel is pressed, the front/rear UID blue LED indicator will be turned on. Press the UID button again to turn off the indicator.

2.11 Driver Installation Guide

To install the drivers to your system, please insert the support CD to your optical drive first. Then, the drivers compatible to your system can be auto-detected and listed on the support CD driver page. Please follow the order from top to bottom to install those required drivers. Therefore, the drivers you install can work properly.

2.12 Dual LAN and Teaming Operation Guide

Dual LAN with Teaming enabled on this motherboard allows two single connections to act as one single connection(s) for twice the transmission bandwidth, making data transmission more effective and improving the quality of transmission of distant images. Fault tolerance on the dual LAN network prevents network downtime by transferring the workload from a failed port to a working port.



The speed of transmission is subject to the actual network environment or status even with Teaming enabled.

Before setting up Teaming, please make sure whether your Switch (or Router) supports Teaming (IEEE 802.3ad Link Aggregation). You can specify a preferred adapter in Intel PROSet. Under normal conditions, the Primary adapter handles all non-TCP/IP traffic. The Secondary adapter will receive fallback traffic if the primary fails. If the Preferred Primary adapter fails, but is later restored to an active status, control is automatically switched back to the Preferred Primary adapter.

Step 1

From **Device Manager**, open the properties of a team.

Step 2

Click the **Settings** tab.

Step 3

Click the **Modify Team** button.

Step 4

Select the adapter you want to be the primary adapter and click the **Set Primary** button.


If you do not specify a preferred primary adapter, the software will choose an adapter of the highest capability (model and speed) to act as the default primary. If a failover occurs, another adapter becomes the primary. The adapter will, however, rejoin the team as a non-primary.

2.13 M.2_SSD (NGFF) Module Installation Guide

The M.2, also known as the Next Generation Form Factor (NGFF), is a small size and versatile card edge connector that aims to replace mPCIe and mSATA. The M.2 Socket (M2_1) supports M.2 SATA3 6.0 Gb/s module and M.2 PCI Express module up to Gen3 x2 (16 Gb/s) (E3C242D4M-4L) or Gen3 x4 (32 Gb/s) (E3C246D4M-4L).


** If M2_1 is occupied by a SATA-type M.2 device, SATA_0 will be disabled.*

Installing the M.2_SSD (NGFF) Module



Step 1

Prepare a M.2_SSD (NGFF) module and the screw.





Step 2

Depending on the PCB type and length of your M.2_SSD (NGFF) module, find the corresponding nut location to be used.


No.	1	2	3	4	5
Nut Location	A	B	C	D	E
PCB Length	3cm	4.2cm	6cm	8cm	11cm
Module Type	Type2230	Type 2242	Type2260	Type 2280	Type 22110

Step 3



Move the standoff based on the module type and length. The standoff is placed at the nut location D by default. Skip Step 3 and 4 and go straight to Step 5 if you are going to use the default nut. Otherwise, release the standoff by hand.

Step 4




Peel off the yellow protective film on the nut to be used. Hand tighten the standoff into the desired nut location on the motherboard.

Step 5




Gently insert the M.2 (NGFF) SSD module into the M.2 slot. Please be aware that the M.2 (NGFF) SSD module only fits in one orientation.



Step 6

Tighten the screw with a screwdriver to secure the module into place.
Please do not overtighten the screw as this might damage the module.



Chapter 3 UEFI Setup Utility

3.1 Introduction

This section explains how to use the UEFI SETUP UTILITY to configure your system. The UEFI chip on the motherboard stores the UEFI SETUP UTILITY. You may run the UEFI SETUP UTILITY when you start up the computer. Please press <F2> or during the Power-On-Self-Test (POST) to enter the UEFI SETUP UTILITY; otherwise, POST will continue with its test routines.

If you wish to enter the UEFI SETUP UTILITY after POST, restart the system by pressing <Ctrl> + <Alt> + <Delete>, or by pressing the reset button on the system chassis. You may also restart by turning the system off and then back on.



Because the UEFI software is constantly being updated, the following UEFI setup screens and descriptions are for reference purpose only, and they may not exactly match what you see on your screen.

3.1.1 UEFI Menu Bar

The top of the screen has a menu bar with the following selections:

Item	Description
Main	To set up the system time/date information
Advanced	To set up the advanced UEFI features
Boot	To set up the default system device to locate and load the Operating System
Security	To set up the security features
Event Logs	For event log configuration
Server Mgmt	To manage the server
Exit	To exit the current screen or the UEFI SETUP UTILITY

Use <←→> key or <→> key to choose among the selections on the menu bar, and then press <Enter> to get into the sub screen.


3.1.2 Navigation Keys

Please check the following table for the function description of each navigation key.

Navigation Key(s)	Function Description
← / →	Moves cursor left or right to select Screens
↑ / ↓	Moves cursor up or down to select items
+ / -	To change option for the selected items
<Tab>	Switch to next function
<Enter>	To bring up the selected screen
<PGUP>	Go to the previous page
<PGDN>	Go to the next page
<HOME>	Go to the top of the screen
<END>	Go to the bottom of the screen
<F1>	To display the General Help Screen
<F7>	Discard changes and exit the UEFI SETUP UTILITY
<F9>	Load optimal default values for all the settings
<F10>	Save changes and exit the UEFI SETUP UTILITY
<F12>	Print screen
<ESC>	Jump to the Exit Screen or exit the current screen

3.2 Main Screen


Once you enter the UEFI SETUP UTILITY, the Main screen will appear and display the system overview. The Main screen provides system overview information and allows you to set the system time and date.



Note: The screenshots in this user manual are examples and for references only. The actual images may slightly vary depending on the model and the version you use.


3.3 Advanced Screen

In this section, you may set the configurations for the following items: CPU Configuration, DRAM Configuration, Chipset Configuration, Storage Configuration, ACPI Configuration, USB Configuration, Super IO Configuration, Serial Port Console Redirection, H/W Monitor, Runtime Error Logging, Intel SPS Configuration, Intel(R) Bios Guard Technology and Instant Flash.



Setting wrong values in this section may cause the system to malfunction.

3.3.1 CPU Configuration



Software Guard Extensions (SGX)

Use this item to enable or disable Software Controlled Software Guard Extensions (SGX).

SGX Launch Control Policy

Software Guard Extensions (SGX) Launch Control Policy. Options are:

Intel Locked - Select Intel's Launch Enclave.

Unlocked - Enable OS/VMM configuration of Launch Enclave.

Locked - Allow owner to configure Launch Enclave.

Intel Hyper Threading Technology

Intel Hyper Threading Technology allows multiple threads to run on each core, so that the overall performance on threaded software is improved.

Active Processor Cores

Select the number of cores to enable in each processor package.

CPU C States Support

Enable CPU C States Support for power saving. It is recommended to keep C3, C6 and C7 all enabled for better power saving.

Enhanced Halt State (C1E)

Enable Enhanced Halt State (C1E) for lower power consumption.

CPU C3 State Support

Enable C3 sleep state for lower power consumption.

CPU C6 State Support

Enable C6 deep sleep state for lower power consumption.

CPU C7 State Support

Enable C7 deep sleep state for lower power consumption.

Package C State Support

Enable CPU, PCIe, Memory, Graphics C State Support for power saving.

Intel Virtualization Technology

Intel Virtualization Technology allows a platform to run multiple operating systems and applications in independent partitions, so that one computer system can function as multiple virtual systems.

VT-d

Intel® Virtualization Technology for Directed I/O helps your virtual machine monitor better utilize hardware by improving application compatibility and reliability, and providing additional levels of manageability, security, isolation, and I/O performance.

Hardware Prefetcher

Automatically prefetch data and code for the processor. Enable for better performance.

Adjacent Cache Line Prefetch

Automatically prefetch the subsequent cache line while retrieving the currently requested cache line. Enable for better performance.

CPU AES

Use this to enable or disable CPU Advanced Encryption Standard instructions.

Intel SpeedStep Technology

Intel SpeedStep technology is Intel's new power saving technology. Processors can switch between multiple frequencies and voltage points to enable power saving. The default value is [Enabled]. Configuration options: [Enabled] and [Disabled]. This item will be hidden if the current CPU does not support Intel SpeedStep technology.



Please note that enabling this function may reduce CPU voltage and lead to system stability or compatibility issues with some power supplies. Please set this item to [Disabled] if above issues occur.

Intel Turbo Boost Technology

Use this item to enable or disable Intel Turbo Boost Mode Technology. Turbo Boost Mode allows processor cores to run faster than marked frequency in specific conditions. The default value is [Enabled].

Enable Intel TXT Support

Use this to enable or disable Intel Trusted Execution Technology.

CPU Thermal Throttling

Enable CPU internal thermal control mechanisms to keep the CPU from overheating.


3.3.2 DRAM Configuration



DRAM Frequency

If [Auto] is selected, the motherboard will detect the memory module(s) inserted and assign the appropriate frequency automatically.

3.3.3 Chipset Configuration



Primary Graphics Adapter

If PCI Express graphics card is installed on the motherboard, you may use this option to select PCI Express or Onboard as the primary graphics adapter.

Onboard VGA

Use this to enable or disable the Onboard VGA function. The default value is [Auto].

Onboard LAN1

Use this to enable or disable the Onboard LAN1 function. The default value is [Enabled].

Onboard LAN2

Use this to enable or disable the Onboard LAN2 function. The default value is [Enabled].

Onboard LAN3

Use this to enable or disable the Onboard LAN3 function. The default value is [Enabled].

Onboard LAN4

Use this to enable or disable the Onboard LAN4 function. The default value is [Enabled].

Above 4G Decoding

Enable or disable 64bit capable Devices to be decoded in Above 4G Address Space (only if the system supports 64 bit PCI decoding).

PCIE6 Link Width

This allows you to select PCIE6 Link Width. The default value is [Auto].

PCIE6 Link Speed

This allows you to select PCIE6 Link Speed. The default value is [Auto].

PCIE6 ASPM Support

This option enables or disables the ASPM support for PCIE6.

PCIE5 Link Speed (E3C246D4M-4L only)

This allows you to select PCIE5 Link Speed. The default value is [Auto].

PCIE5 ASPM Support (E3C246D4M-4L only)

This option enables or disables the ASPM support for PCIE5.

PCIE4 Link Speed (E3C246D4M-4L only)

This allows you to select PCIE4 Link Speed. The default value is [Auto].

PCIE4 ASPM Support (E3C246D4M-4L only)

This option enables or disables the ASPM support for PCIE4.

PCIE3 Link Speed (E3C246D4M-4L only)

This allows you to select PCIE3 Link Speed. The default value is [Auto].

PCIE3 ASPM Support (E3C246D4M-4L only)

This option enables or disables the ASPM support for PCIE3.

PCIE2 Link Speed

This allows you to select PCIE2 Link Speed. The default value is [Auto].

PCIE2 ASPM Support

This option enables or disables the ASPM support for PCIE2.

SR-IOV Support

If system has SR-IOV capable PCIe Devices, this option Enables or Disables Single Root IO Virtualization Support.


Onboard Debug Port LED

Enable/Disable the onboard Dr. Debug LED.

Restore AC Power Current State

This allows you to restore AC Power Current State.


3.3.4 Storage Configuration



Hard Disk S.M.A.R.T.

S.M.A.R.T. stands for Self-Monitoring, Analysis, and Reporting Technology. It is a monitoring system for computer hard disk drives to detect and report on various indicators or reliability.

3.3.5 ACPI Configuration



PCIE Devices Power On

Use this item to enable or disable PCIE devices to turn on the system from the power-soft-off mode.


Ring-In Power On

Use this item to enable or disable Ring-In signals to turn on the system from the power-soft-off mode.

RTC Alarm Power On

Use this item to enable or disable RTC (Real Time Clock) to power on the system.


3.3.6 USB Configuration



Legacy USB Support

Enable Legacy OS Support for USB 2.0 devices. Select UEFI Setup Only to support USB devices under the UEFI setup and Windows/Linux operating systems only.

3.3.7 Super IO Configuration



Serial Port 1 Configuration

Use this item to set parameters of Serial Port 1 (COM1).

Serial Port

Use this item to enable or disable the onboard serial port.

Change Settings

Use this item to select an optimal setting for Super IO device.

SOL Port Configuration

Use this item to set parameters of SOL.


SOL Port Configuration

Use this item to enable or disable Serial Port (SOL).

SOL Port Address

Use this item to select an optimal setting for Super IO device.

3.3.8 Serial Port Console Redirection



COM1 / SOL

Console Redirection

Use this option to enable or disable Console Redirection. If this item is set to Enabled, you can select a COM Port to be used for Console Redirection.

Console Redirection Settings

Use this option to configure Console Redirection Settings, and specify how your computer and the host computer to which you are connected exchange information.

Terminal Type

Use this item to select the preferred terminal emulation type for out-of-band management. It is recommended to select [VT-UTF8].

Option	Description
VT100	ASCII character set
VT100+	Extended VT100 that supports color and function keys
VT-UTF8	UTF8 encoding is used to map Unicode chars onto 1 or more bytes
ANSI	Extended ASCII character set

Bits Per Second

Use this item to select the serial port transmission speed. The speed used in the host computer and the client computer must be the same. Long or noisy lines may require lower transmission speed. The options include [9600], [19200], [57600] and [115200].

Data Bits

Use this item to set the data transmission size. The options include [7] and [8] (Bits).

Parity

Use this item to select the parity bit. The options include [None], [Even], [Odd], [Mark] and [Space].

Stop Bits

The item indicates the end of a serial data packet. The standard setting is [1] Stop Bit. Select [2] Stop Bits for slower devices.

Flow Control

Use this item to set the flow control to prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a "stop" signal can be sent to stop the data flow. Once the buffers are empty, a "start" signal can be sent to restart the flow. Hardware flow uses two wires to send start/stop signals. The options include [None] and [Hardware RTS/CTS].

VT-UTF8 Combo Key Support

Use this item to enable or disable the VT-UTF8 Combo Key Support for ANSI/VT100 terminals.

Recorder Mode

Use this item to enable or disable Recorder Mode to capture terminal data and send it as text messages.

Resolution 100x31

Use this item to enable or disable extended terminal resolution support.

Putty Keypad

Use this item to select Function Key and Keypad on Putty.

Legacy Console Redirection**Legacy Console Redirection Settings**

Use this option to configure Legacy Console Redirection Settings, and specify how your computer and the host computer to which you are connected exchange information.

Redirection COM Port

Select a COM port to display redirection of Legacy OS and Legacy OPROM Messages.

Resolution

On Legacy OS, the Number of Rows and Columns supported redirection.

Redirect After POST

When Bootloader is selected, then Legacy Console Redirection is disabled before booting to legacy OS. When Always Enable is selected, then Legacy Console Redirection is enabled for legacy OS. Default setting for this option is set to Always Enable.

Serial Port for Out-of-Band Management/Windows Emergency Management Services (EMS)

Console Redirection

Use this option to enable or disable Console Redirection. If this item is set to Enabled, you can select a COM Port to be used for Console Redirection.

Console Redirection Settings

Use this option to configure Console Redirection Settings, and specify how your computer and the host computer to which you are connected exchange information.

Terminal Type

Use this item to select the preferred terminal emulation type for out-of-band management. It is recommended to select [VT-UTF8].

Option	Description
VT100	ASCII character set
VT100+	Extended VT100 that supports color and function keys
VT-UTF8	UTF8 encoding is used to map Unicode chars onto 1 or more bytes
ANSI	Extended ASCII character set

Bits Per Second

Use this item to select the serial port transmission speed. The speed used in the host computer and the client computer must be the same. Long or noisy lines may require lower transmission speed. The options include [9600], [19200], [57600] and [115200].

Flow Control

Use this item to set the flow control to prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a "stop" signal can be sent to stop the data flow. Once the buffers are empty, a "start" signal can be sent to restart the flow. Hardware flow uses two wires to send start/stop signals. The options include [None], [Hardware RTS/CTS], and [Software Xon/Xoff].


Data Bits

Parity

Stop Bits

3.3.9 H/W Monitor

In this section, it allows you to monitor the status of the hardware on your system, including the parameters of the CPU temperature, motherboard temperature, CPU fan speed, chassis fan speed, and the critical voltage.



FAN Control

If [Auto] is selected, the fan speed will be controlled by BMC.

If [Manual] is selected, configure the items below.

CPU_FAN1

This allows you to set the CPU fan1's speed. The default value is [Smart Fan].

FRNT_FAN1

This allows you to set the front fan 1's speed. The default value is [Smart Fan].

FRNT_FAN2

This allows you to set the front fan 2's speed. The default value is [Smart Fan].

FRNT_FAN3

This allows you to set the front fan 3's speed. The default value is [Smart Fan].

FRNT_FAN4

This allows you to set the front fan 4's speed. The default value is [Smart Fan].

REAR_FAN1

This allows you to set the rear fan 1's speed. The default value is [Smart Fan].

Smart Fan Control

This allows you to set the Smart fan's level speed.

Smart Fan Duty Control

Smart Fan Duty x (x means 1 to 11 stage)


This allows you to set duty cycle for each stage.

Smart Fan Temp Control

Smart Fan Temp x (x means 1 to 11 stage)

This allows you to set temperature for each stage.

3.3.10 Runtime Error Logging



WHEA Support

Use this item to enable or disable Windows Hardware Error Architecture.

Runtime Error Logging System Enabling

Use this item to enable or disable Runtime Error Logging System.

Memory Error Enabling

Memory enabling and logging setup option.

PCI/PCI Error Enabling

Use this item to enable or disable PCI errors.

Corrected Error Enable

Use this item to enable or disable Correctable errors.


Uncorrected Error Enable

Use this item to enable or disable Uncorrectable errors.

Fatal Error Enable


Use this item to enable or disable Fatal errors.

3.3.11 Intel SPS Configuration



SPS screen displays the Intel SPS Configuration information, such as Operational Firmware Version and Firmware State.

3.3.12 Intel(R) Bios Guard Technology




Intel Bios Guard Support

Use this to enable or disable Intel Bios Guard Support. The default value is [Disabled].

3.3.13 Instant Flash

Instant Flash is a UEFI flash utility embedded in Flash ROM. This convenient UEFI update tool allows you to update system UEFI without entering operating systems first like MS-DOS or Windows[®]. Just save the new UEFI file to your USB flash drive, floppy disk or hard drive and launch this tool, then you can update your UEFI only in a few clicks without preparing an additional floppy diskette or other complicated flash utility. Please be noted that the USB flash drive or hard drive must use FAT32/16/12 file system. If you execute Instant Flash utility, the utility will show the UEFI files and their respective information. Select the proper UEFI file to update your UEFI, and reboot your system after the UEFI update process is completed.

3.4 Server Mgmt




Wait For BMC

Wait For BMC response for specified time out. BMC starts at the same time when BIOS starts during AC power ON. It takes around 90 seconds to initialize Host to BMC interfaces.

Inventory Support

This will execute inventory function for system. Enabling this item will take some time at system boot.

3.4.1 System Event Log



SEL Components

Change this to enable or disable event logging for error/progress codes during boot.

Erase SEL

Use this to choose options for erasing SEL.


When SEL is Full

Use this to choose options for reactions to a full SEL.

Log EFI Status Codes

Use this item to disable the logging of EFI Status Codes or log only error code or only progress code or both.

3.4.2 BMC Network Configuration



BMC Out of Band Access

Use this item to enable or disable BMC Out of Band Access.

Lan Channel (Failover)

Manual Setting IPMI LAN

If [No] is selected, the IP address is assigned by DHCP. If you prefer using a static IP address, toggle to [Yes], and the changes take effect after the system reboots. The default value is [No].

Configuration Address Source

Select to configure BMC network parameters statically or dynamically (by BIOS or BMC). Configuration options: [Static] and [DHCP].

Static: Manually enter the IP Address, Subnet Mask and Gateway Address in the BIOS for BMC LAN channel configuration.

DHCP: IP address, Subnet Mask and Gateway Address are automatically assigned by the network's DHCP server.



When [DHCP] or [Static] is selected, do NOT modify the BMC network settings on the IPMI web page.



The default login information for the IPMI web interface is:


Username: admin

Password: admin

For more instructions on how to set up remote control environment and use the IPMI management platform, please refer to the IPMI Configuration User Guide or go to the Support website at: <http://www.asrockrack.com/support/faq.asp>

3.5 Security

In this section, you may set or change the supervisor/user password for the system. For the user password, you may also clear it.



Supervisor Password

Set or change the password for the administrator account. Only the administrator has authority to change the settings in the UEFI Setup Utility. Leave it blank and press enter to remove the password.

User Password

Set or change the password for the user account. Users are unable to change the settings in the UEFI Setup Utility. Leave it blank and press enter to remove the password.

Secure Boot


Use this to enable or disable Secure Boot Control. The default value is [Disabled]. Enable to support Windows Server 2012 R2 or later versions Secure Boot.

Secure Boot Mode

Secure Boot mode selector: Standard/Custom. In Custom mode, Secure Boot Policy variables can be configured by a physically present user without full authentication.

3.5.1 Key Management

In this section, expert users can modify Secure Boot Policy variables without full authentication.



Factory Key Provision

Install factory default Secure Boot keys after the platform reset and while the System is in Setup mode.

Install Default Secure Boot Keys

Please install default secure boot keys if it's the first time you use secure boot.

Clear Secure Boot keys

Force System to Setup Mode - clear all Secure Boot Variables. Change takes effect after reboot.

Export Secure Boot variables

Copy NVRAM content of Secure Boot variables to files in a root folder on a file system device.

Enroll Efi Image

Allow the image to run in Secure Boot mode. Enroll SHA256 Hash certificate of a PE image into Authorized Signature Database (db).

Remove 'UEFI CA' from DB

Device Guard ready system must not list 'Microsoft UEFI CA' Certificate in Authorized Signature database (db).

Restore DB defaults

Restore DB variable to factory defaults.

Platform Key(PK)

Enroll Factory Defaults or load certificates from a file:

1. Public Key Certificate in:

- a) EFI_SIGNATURE_LIST
- b) EFI_CERT_X509 (DER)
- c) EFI_CERT_RSA2048 (bin)
- d) EFI_CERT_SHA256, 384, 512

2. Authenticated UEFI Variable

3. EFI PE/COFF Image(SHA256)

Key Source: Factory, External, Mixed

Key Exchange Keys

Enroll Factory Defaults or load certificates from a file:

1. Public Key Certificate in:

- a) EFI_SIGNATURE_LIST
- b) EFI_CERT_X509 (DER encoded)
- c) EFI_CERT_RSA2048 (bin)
- d) EFI_CERT_SHA256, 384, 512

2. Authenticated UEFI Variable

3. EFI PE/COFF Image(SHA256)

Key Source: Factory, External, Mixed

Authorized Signatures

Enroll Factory Defaults or load certificates from a file:

1. Public Key Certificate in:

- a) EFI_SIGNATURE_LIST
- b) EFI_CERT_X509 (DER encoded)
- c) EFI_CERT_RSA2048 (bin)
- d) EFI_CERT_SHA256, 384, 512

2. Authenticated UEFI Variable

3. EFI PE/COFF Image(SHA256)

Key Source: Factory, External, Mixed

Forbidden Signatures

Enroll Factory Defaults or load certificates from a file:

1. Public Key Certificate in:

- a) EFI_SIGNATURE_LIST
- b) EFI_CERT_X509 (DER encoded)
- c) EFI_CERT_RSA2048 (bin)
- d) EFI_CERT_SHA256, 384, 512

2. Authenticated UEFI Variable

3. EFI PE/COFF Image(SHA256)

Key Source: Factory, External, Mixed

Authorized TimeStamps

Enroll Factory Defaults or load certificates from a file:

1. Public Key Certificate in:

- a) EFI_SIGNATURE_LIST
- b) EFI_CERT_X509 (DER encoded)
- c) EFI_CERT_RSA2048 (bin)
- d) EFI_CERT_SHA256, 384, 512

2. Authenticated UEFI Variable

3. EFI PE/COFF Image(SHA256)

Key Source: Factory, External, Mixed

OsRecovery Signatures

Enroll Factory Defaults or load certificates from a file:

1. Public Key Certificate in:

- a) EFI_SIGNATURE_LIST
- b) EFI_CERT_X509 (DER encoded)
- c) EFI_CERT_RSA2048 (bin)
- d) EFI_CERT_SHA256, 384, 512


2. Authenticated UEFI Variable

3. EFI PE/COFF Image(SHA256)

Key Source: Default, External, Mixed, Test

3.6 Boot Screen

In this section, it will display the available devices on your system for you to configure the boot settings and the boot priority.



Boot Option #1

Use this item to set the system boot order.

Boot Option Filter

This option controls Legacy/UEFI ROMs priority.

Boot From Onboard LAN

Use this item to enable or disable the Boot From Onboard LAN feature.

Setup Prompt Timeout

This shows the number of seconds to wait for setup activation key. 65535(0xFFFF) means indefinite waiting.

Bootup Num-Lock

If this item is set to [On], it will automatically activate the Numeric Lock function after boot-up.

Boot Beep

Select whether the Boot Beep should be turned on or off when the system boots up. Please

note that a buzzer is needed.


Full Screen Logo

Use this item to enable or disable OEM Logo. The default value is [Enabled].

AddOn ROM Display

Use this option to adjust AddOn ROM Display. If you enable the option “Full Screen Logo” but you want to see the AddOn ROM information when the system boots, please select [Enabled]. Configuration options: [Enabled] and [Disabled]. The default value is [Enabled].

3.6.1 CSM Parameters



CSM

Enable to launch the Compatibility Support Module. Please do not disable unless you're running a WHCK test. If you are using Windows 8.1 64-bit and all of your devices support UEFI, you may also disable CSM for faster boot speed.

Launch Other Storage OpROM Policy

Select UEFI only to run those that support UEFI option ROM only. Select Legacy only to run those that support legacy option ROM only. Select Do not launch to not execute both legacy and UEFI option ROM.

Launch Video OpROM Policy

Select UEFI only to run those that support UEFI option ROM only. Select Legacy only to run those that support legacy option ROM only. Select Do not launch to not execute both legacy and UEFI option ROM.

MEZZ1 Slot OpROM

This option controls Legacy/UEFI ROMs priority.

PCIE2 Slot OpROM

This option controls Legacy/UEFI ROMs priority.

PCIE3 Slot OpROM *(E3C246D4M-4L only)*

This option controls Legacy/UEFI ROMs priority.

PCIE4 Slot OpROM *(E3C246D4M-4L only)*

This option controls Legacy/UEFI ROMs priority.

PCIE5 Slot OpROM *(E3C246D4M-4L only)*

This option controls Legacy/UEFI ROMs priority.


PCIE6 Slot OpROM

This option controls Legacy/UEFI ROMs priority.

M2_1 Slot OpROM

This option controls Legacy/UEFI ROMs priority.

3.7 Event Logs



Change Smbios Event Log Settings

This allows you to configure the Smbios Event Log Settings.

When entering the item, you will see the followings:

Smbios Event Log

Use this item to enable or disable all features of the SMBIOS Event Logging during system boot.

Erase Event Log

The options include [No], [Yes, Next reset] and [Yes, Every reset]. If Yes is selected, all logged events will be erased.

When Log is Full

Use this item to choose options for reactions to a full Smbios Event Log. The options include [Do Nothing] and [Erase Immediately].

Log System Boot Event

Choose option to enable/disable logging of System boot event.


View Smbios Event Log

Press <Enter> to view the Smbios Event Log records.



All values changed here do not take effect until computer is restarted.

3.8 Exit Screen



Save Changes and Exit

When you select this option, the following message “Save configuration changes and exit setup?” will pop-out. Press <F10> key or select [Yes] to save the changes and exit the UEFI SETUP UTILITY.

Discard Changes and Exit

When you select this option, the following message “Discard changes and exit setup?” will pop-out. Press <ESC> key or select [Yes] to exit the UEFI SETUP UTILITY without saving any changes.

Discard Changes

When you select this option, the following message “Discard changes?” will pop-out. Press <F7> key or select [Yes] to discard all changes.

Load UEFI Defaults

Load UEFI default values for all the setup questions. F9 key can be used for this operation.

Chapter 4 Software Support

4.1 Install Operating System

This motherboard supports various Microsoft® Windows® / Linux compliant. Because motherboard settings and hardware options vary, use the setup procedures in this chapter for general reference only. Refer to your OS documentation for more information.

**Please download the Intel® SATA Floppy Image driver from the ASRock Rack's website (www.asrockrack.com) to your USB drive or simply install the SATA driver from the Support CD while installing OS in SATA RAID mode.*

4.2 Support CD Information

The Support CD that came with the motherboard contains necessary drivers and useful utilities that enhance the motherboard's features.

4.2.1 Running The Support CD

To begin using the support CD, insert the CD into your CD-ROM drive. The CD automatically displays the Main Menu if "AUTORUN" is enabled in your computer. If the Main Menu does not appear automatically, locate and double click on the file "ASRSetup.exe" from the root folder in the Support CD to display the menu.

4.2.2 Drivers Menu

The Drivers Menu shows the available device's drivers if the system detects installed devices. Please install the necessary drivers to activate the devices.

4.2.3 Utilities Menu

The Utilities Menu shows the application softwares that the motherboard supports. Click on a specific item then follow the installation wizard to install it.

4.2.4 Contact Information

If you need to contact ASRock Rack or want to know more about ASRock Rack, welcome to visit ASRock Rack's website at <http://www.ASRockRack.com>; or you may contact your dealer for further information.

Chapter 5 Troubleshooting

5.1 Troubleshooting Procedures

Follow the procedures below to troubleshoot your system.



Always unplug the power cord before adding, removing or changing any hardware components. Failure to do so may cause physical injuries to you and damages to motherboard components.

1. Disconnect the power cable and check whether the PWR LED is off.
2. Unplug all cables, connectors and remove all add-on cards from the motherboard.
Make sure that the jumpers are set to default settings.
3. Confirm that there are no short circuits between the motherboard and the chassis.
4. Install a CPU and fan on the motherboard, then connect the chassis speaker and power LED.

If there is no power...

1. Confirm that there are no short circuits between the motherboard and the chassis.
2. Make sure that the jumpers are set to default settings.
3. Check the settings of the 115V/230V switch on the power supply.
4. Verify if the battery on the motherboard provides ~3VDC. Install a new battery if it does not.

If there is no video...

1. Try replugging the monitor cables and power cord.
2. Check for memory errors.

If there are memory errors...

1. Verify that the DIMM modules are properly seated in the slots.
2. Use recommended DDR4 ECC/non-ECC U DIMMs.
3. If you have installed more than one DIMM modules, they should be identical with the same brand, speed, size and chip-type.
4. Try inserting different DIMM modules into different slots to identify faulty ones.
5. Check the settings of the 115V/230V switch on the power supply.

Unable to save system setup configurations...

1. Verify if the battery on the motherboard provides ~3VDC. Install a new battery if it does not.
2. Confirm whether your power supply provides adequate and stable power.

Other problems...

1. Try searching keywords related to your problem on ASRock Rack's FAQ page:
<http://www.asrockrack.com/support>

5.2 Technical Support Procedures

If you have tried the troubleshooting procedures mentioned above and the problems are still unsolved, please contact ASRock Rack's technical support with the following information:

1. Your contact information
2. Model name, BIOS version and problem type.
3. System configuration.
4. Problem description.

You may contact ASRock Rack's technical support at:

<http://www.asrockrack.com/support/tsd.asp>

5.3 Returning Merchandise for Service

For warranty service, the receipt or a copy of your invoice marked with the date of purchase is required. By calling your vendor or going to our RMA website (<http://event.asrockrack.com/tsd.asp>) you may obtain a Returned Merchandise Authorization (RMA) number.

The RMA number should be displayed on the outside of the shipping carton which is mailed prepaid or hand-carried when you return the motherboard to the manufacturer. Shipping and handling charges will be applied for all orders that must be mailed when service is complete.

This warranty does not cover damages incurred in shipping or from failure due to alteration, misuse, abuse or improper maintenance of products.

Contact your distributor first for any product related problems during the warranty period.