

GRAEF.




Table of content

| | |
|---|---|
| Safety Instructions..... | 3 |
| Before the first use | 4 |
| Unpacking | 4 |
| Requirements for the installation location | 5 |
| Operating and speed settings | 5 |
| Grind setting | 5 |
| Grinding coffee..... | 6 |
| Grinding coffee directly in the group handle.. | 6 |
| Cleaning | 6 |
| Cleaning the burrs | 7 |
| Adjustment of top burr | 8 |
| Customer service department | 8 |
| Disposal..... | 8 |
| Warranty | 9 |

Safety Instructions

This appliance complies with the statutory safety regulations. Improper use can, however, lead to personal injury and property damage.

To handle the appliance safely, follow the instructions below:

- Check the appliance for external, visible damage to the housing, the connector cable and the plug before using it. Do not put a damaged appliance into operation.
- If the machine's connecting cable is damaged, continued use of the machine is only allowed if it has been replaced with a new one. Have it installed solely by the manufacturer or its customer service or a similarly qualified person to prevent hazards.
- Repairs are only allowed to be performed by a specialist or by the Graef customer service department. Improper repairs can lead to extreme hazards for the user and damage the appliance. Furthermore, the warranty claim expires.
- Only Graef customer service is authorised to repair the appliance during the warranty period, otherwise the warranty expires for subsequent damages.
- Defective components must be replaced solely with genuine spare parts. Fulfilment of the safety regulations is only guaranteed if these parts are used.
- Always disconnect the appliance from the supply if it is left unattended and before assembling, disassembling or cleaning.
- This appliance shall not be used by children. Keep the appliance and its cord out of reach of children.
- Appliance can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved.
- Children shall not play with the appliance.
- Do not use the appliance if the rotating sieve or the protecting cover is damaged or has visible cracks.

- The appliance is not intended to be used with an external timer or a separate telecontrol system.
- This appliance is intended to be used in household and similar applications such as: staff kitchen areas in shops, offices and other working environments; farm houses; by clients in hotels, motels and other residential type environments; bed and breakfast type environments.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service or similarly qualified persons in order to avoid a hazard.
- Always pull the supply line from the electric socket using the connector plug, not on the connector cable.
- Never operate the appliance with wet hands.
- Do not use the packaging material as a toy. Danger of suffocation.
- Do not use any aggressive or abrasive cleaning agents and do not use any solvents.
- Do not scratch off stubborn soiling with hard objects.
- Do not wash in the appliance in water, do not immerse it into water and do not put it in the dishwasher.
- Do not try to regrind previously ground coffee.
- Switch off the appliance and disconnect from supply before changing accessories or approaching parts that move in use.
- Let the appliance cool off before cleaning.
- Make sure that no liquid gets into the interior of the appliance.
- The appliance is suitable solely for grinding coffee beans.

Before the first use

Clean all parts as described in “Cleaning and Care”.

Unpacking

To unpack the appliance, proceed as below:

- Take the appliance out of the carton.
- Remove all pieces of the packaging.
- Remove any possibly extant labels on the coffee grinder (do not remove the rating plate).

Requirements for the installation location

For safe and flawless operation of the appliance, the place of location must meet these prerequisites:

- The appliance must be set up on a firm, flat, level, non-slip and heat resistant base that has sufficient load bearing capacity.
- Select the place of location so that children cannot reach the surfaces of the appliance.
- The appliance is not intended for installation in a wall or a built-in cupboard.
- Do not set up the appliance in a hot, wet or moist environment.
- The electric socket must be readily accessible so that the power cord can be easily unplugged.

Operating and speed settings

- Maximum operating time is 4 minutes. After these 4 minutes please let the appliance cool down to room temperature and start again.

Grind setting

You can influence the composition of the coffee with various grind settings.

The wide range of grind settings allows you to make a precise adjustment.

Notice:

- The finer the coffee grounds, the longer the grinding process takes.
- If you use a fine grind level, it is possible that the coffee grounds clump together. During grinding, slightly knock on the coffee bean container cover so that any possible coffee grounds clumps do not block the grinding.
- Accurate information on the grind setting can not be made, since many factors such as type of coffee / bean, room temperature, personal taste, etc. play a role.

- In general it takes a finer grind for espresso, a medium grind for drip coffee and a coarser grind for French press.

Grinding coffee

- Plug the plug into the electric socket.
- Fill the coffee bean container with coffee beans.

Only use whole coffee beans.

- Select the grind by turning the grind adjustment collar to the desired setting.
- To grind coffee beans, set the switch to the 'On' position.
- When the desired amount of coffee grounds have been ground, set the switch to the 'Off' position. Remove the coffee grounds container.

Grinding coffee directly in the group handle

- Hold the group handle between the group handle bracket.
- Set the switch to "Auto"

- Press the group handle onto the button between the group handle brackets.
- The coffee grounds flow into the group handle.
- When the group handle is full, pull it back.

Cleaning

Old coffee grounds remaining in the appliance can lead to oxidation. That spoils the beverage; it can cause an unpleasant, rancid taste. The appliances should always be in optimum condition to be able to provide optimum results at any time.

Ensure the appliance is switched off and unplugged from the power outlet.

- Clean the exterior of the appliance with a soft, moist cloth. If heavily soiled, a mild detergent can be used.
- Take off the coffee bean container. Press it down and turn counter-clockwise.
- Take out the unused beans and put them in an airtight container so they stay fresh.

- Clean the coffee bean container and the coffee grounds container with warm water and a little detergent.
- After that, dry both container well.
- Remove the grind adjustment collar including the top burr.
- Lift out the top burr from the grind adjustment collar and clean it using the burr cleaning brush.

Cleaning the burrs

If the coffee grinder is used frequently (every day), the burrs need to be cleaned every three weeks to ensure best performance of the coffee grinder. Regular cleaning helps the burrs achieve consistent grinding results, which is especially important when grinding coffee for espresso

- Remove the coffee bean container as described in “Cleaning”.
- Turn the grind adjustment collar counterclockwise until the graphic arrow on the grind adjustment collar is aligned with the first arrow on backside of the appliance.
- Press the unlock button and turn the grind adjustment collar until the upper graphic arrow is aligned on the second graphic arrow on the backside of the appliance.
- Also clean the upper burr with the cleaning brush.
- After cleaning return the grind adjustment collar to its position on the appliance.
- The upper graphic arrow is aligned with the second graphic arrow (Align).
- Replace the top burr back into position in the grind adjustment collar and turn clockwise to the desired grind setting.

Notice: To check if the burr was inserted correctly, you can try to pull out the burr on the metal ring. Now, the burr should not be removable.



Adjustment of top burr

By adjusting the burr you can adjust the grind setting coarser or finer.

- Remove the top burr as described in “Cleaning the burrs”.
- Remove the two small screws with a screw driver.
- Turn the burr one step to the left (coarser) or to the right (finer).
- Turn back the screws.
- Replace the burr.
- Repeat the adjustment if it is not fine or coarse enough.



Customer service department

If your Graef appliance becomes damaged or you lose the instruction manual, please contact your dealer or the Graef customer service department.



Disposal

At the end of its service life, this product must not be disposed through normal domestic waste; rather it must be disposed at a collection point for recycling electronic domestic refuse. The symbol on the product and in the operating instructions points this out. The materials can be recycled in accordance with their markings. By

recycling, making use of the materials or other forms of recycling old units you are making an important contribution to protecting our environment. Please ask your municipal administration about the responsible disposal sites.

flawless product as we choose.

Warranty

2 year warranty

Starting with the date of purchase, we assume a 24 month manufacturer's warranty for defects that are attributable to manufacturing and material defects. Your legal warranty rights in accordance with § 439 ff. German Civil Code-E remain unaffected by this clause. Not included in the warranty are damages that have arisen due to improper handling and use as well as defects which have only a slight influence on the functioning or value of the unit. Furthermore, shipping damages, unless our responsibility, are excluded from warranty rights. Warranty claims are excluded for damages that arise due to repairs we or our representatives have not performed. In case of a justified complaint, we will repair or replace the defective product with a