

Recommended Use Method

For Barcode Position Only

PN:

SP41B21899

Printed in China

Lenovo

Disable discrete graphics

To avoid conflicts with the graphics in Lenovo Legion BoostStation, disable the computer's discrete graphics in the **Device Manager**.

- Step 1. Press the power button to turn on the computer.
- Step 2. Press the Windows logo key + X.
- Step 3. Select **Device Manager**.
- Step 4. Expand the **Display adapters** section.
- Step 5. Right click the name of the discrete graphics and click **Properties**.
- Step 6. Select **Driver** tab.
- Step 7. Select the **Disable Device** option and click **Yes**.
- Step 8. Close the **Device Manager**.

Install BoostStation Optimization

Install program "BoostStation Optimization.exe" before using Lenovo Legion BoostStation.

- Step 1. Press the power button to turn on the computer.
- Step 2. Go to the link <https://support.lenovo.com/accessories/docks> to download the program "BoostStation Optimization.exe".

- Step 3. Save "BoostStation Optimization.exe" in the computer to double click, and the program will be installed automatically.
- Step 4. Once the installation is done, press **OK** to restart the computer.

Enable Thunderbolt™ Boot Once

- Step 1. Press the power button to turn on the computer.
- Step 2. Press the **F2** key to enter the BIOS setup menu.
- Step 3. Select **Configuration → Thunderbolt™ Boot Support → Boot once**.
- Step 4. Press **F10** to pop up the "Save confirmation changes and exit now?" window and click **Yes** to exit the setup menu.

Change the Windows power management setting

This step applies to the Thunderbolt™ controller.

- Step 1. Press the power button to turn on the computer.
- Step 2. Press the Windows logo key + X.
- Step 3. Select **Device Manager**.
- Step 4. Expand the **System devices** section.

- Step 5. Right click on **Thunderbolt™ Controller → Properties**.

- Step 6. Uncheck the **Allow the computer to turn off this device to save power** box in the **Power Management** tab.

- Step 7. Click **OK**.

- Step 8. Close the **Device Manager**.

For detailed information, refer to <https://www.intel.com/content/www/us/en/support/articles/000030689/intel-nuc.html>

Removing the Lenovo Legion BoostStation

Note: Do not disconnect the Thunderbolt™ 3 cable of the Lenovo Legion BoostStation when running (includes running programs or playing media). Safely remove the hardware and eject media from your computer before attempting to disconnect.

- Step 1. Click the **Safely Remove Hardware and Eject Media** icon at the button-right.
- Step 2. Click **Eject NVIDIA USB Type-C Port Policy Controller**.
- Step 3. Click **Eject ASM1153E Test**.

Note: Names may vary depending on the hard drive installed.

建议使用方法

Lenovo

禁用笔记本自带独立显卡

为避免与 Lenovo Legion BoostStation 中的显卡发生冲突，请在**设备管理器**中禁用笔记本自带独立显卡。

- 步骤 1. 按电源键开机。
- 步骤 2. 按 Windows 键和 X 组合键。
- 步骤 3. 选择**设备管理器**。
- 步骤 4. 展开**显示适配器**部分。
- 步骤 5. 右键单击笔记本上显示自带独立显卡的名称**属性**。
- 步骤 6. 选择**驱动程序**。
- 步骤 7. 选择**禁用设备**选项并单击**是**。
- 步骤 8. 关闭**设备管理器**。

安装 BoostStation Optimization

使用 Lenovo Legion BoostStation 前，请先安装程序 BoostStation Optimization.exe。

- 步骤 1. 按电源键开机。
- 步骤 2. 前往路径 <https://newsupport.lenovo.com.cn> 去下载程序“BoostStation Optimization.exe”。
- 步骤 3. 保存“BoostStation Optimization.exe”于笔记本内并双击执行，此程序将自动安装。
- 步骤 4. 安装完成后，按**确定**重启电脑。

启动 Thunderbolt™ Boot Once

- 步骤 1. 按电源键开机。
- 步骤 2. 按 **F2** 键进入 BIOS 设置选单。
- 步骤 3. 选择 **Configuration → Thunderbolt™ Boot Support → Boot once**。
- 步骤 4. 按 **F10** 后在弹出窗口“Save confirmation changes and exit now?”中单击 **Yes**。

更改 Windows 电源管理设置

此步骤适用于 Thunderbolt™ 控制器。

- 步骤 1. 按电源键开机。
 - 步骤 2. 按 Windows 键和 X 组合键。
 - 步骤 3. 选择**设备管理器**。
 - 步骤 4. 展开**系统设备**部分。
 - 步骤 5. 右键单击 **Thunderbolt™ 控制器 → 属性**。
 - 步骤 6. 在**电源管理**选项卡上取消选中**允许计算机关闭此设备以节约电源**复选框。
 - 步骤 7. 单击**确定**。
 - 步骤 8. 关闭**设备管理器**。
- 获悉更多信息，请参看
<https://www.intel.com/content/www/us/en/support/articles/000030689/intel-nuc.html>

移出 Lenovo Legion BoostStation

使用 Lenovo Legion BoostStation 时（包括程式运行和播放过的影片），请勿直接拔除 Thunderbolt™ 3 连接线，请通过系统安全移出硬件并弹出媒体。

- 步骤 1. 点击右下方**安全删除硬件并弹出媒体**图标。
 - 步骤 2. 单击**弹出 NVIDIA USB Type-C Port Policy Controller**。
 - 步骤 3. 单击**弹出 ASM1153E Test**。
- 注：名称会因安装的硬盘而有所不同。