

FRITZ! Notice

WLAN WPS button

- switch wireless LAN on/off » press briefly
- Register wireless LAN device (WPS) » press longer

DECT button

- page (all telephone handsets ring)
» press briefly
- Register a telephone
» press longer



Power

- lights up when FRITZ!Box has electrical power

Fiber

- lights up when Internet connection is active

WLAN

- lights up when wireless LAN is on
- flashes during WPS registration

Fon

- lights up during a telephone call
- flashes when voice messages are waiting in the network

Info

- flashes when messages are waiting on the FRITZ!Box answering machine (configurable)

Factory settings

Einstellungen ab Werk

FRITZ! Notiz

WLAN WPS-Taster

- WLAN an/aus schalten » kurz drücken
- WLAN-Gerät anmelden (WPS) » lang drücken

DECT-Taster

- wiederfinden (alle Telefone klingeln)
» kurz drücken
- Telefon anmelden
» lang drücken



Power

- leuchtet wenn FRITZ!Box mit Strom versorgt wird

Fiber

- leuchtet wenn Internetverbindung besteht

WLAN

- leuchtet wenn WLAN an ist
- blinkt während der WPS-Anmeldung

Fon

- leuchtet bei einem Telefonat
- blinkt bei Sprachnachrichten im Netz

Info

- blinkt bei Nachrichten auf dem FRITZ!Box-Anrufbeantworter (einstellbar)

Custom settings

Eigene Einstellungen

Wireless radio network key (SSID) WLAN-Funknetz (SSID)

Network key WLAN-Netzwerkschlüssel

FRITZ!Box password FRITZ!Box-Kennwort