SENCOR® SMS 5510BK



EN ▪ Electric Shaver

Translation of the original manual

Copyright © 2021, Fast ČR, a.s.

Revision 03/2021

EN

Electric Shaver

Important safety instructions

READ CAREFULLY AND STORE FOR FUTURE USE.

General warnings

- This appliance may be used by children 8 years of age and older and by persons with physical or mental impairments or by inexperienced persons, if they are properly supervised or have been informed about how to use the product in a safe manner and understand the potential dangers.
- Children must not play with the appliance.
- Cleaning and maintenance performed by the user must not be performed by unsupervised children.
- In the event that the power cord is damaged, have it repaired at a professional service centre to prevent causing a dangerous situation. It is forbidden to use the appliance if it has a damaged power cord.



This appliance can be washed under a water tap.



Warning:
Before cleaning with water, make sure that the appliance is disconnected from the power adapter.

- The parts of the appliance that need to be mounted or stood upright, must be mounted or stood upright in such a way that they cannot fall into water.

Copyright © 2021, Fast ČR, a.s.

Revision 03/2021

ELECTRICAL SAFETY

- Before connecting the power adapter to a power socket, check that the voltage on its rating label corresponds to the voltage in the power socket to which you wish to connect it. Do not use an extension cord.
- Connect the power adapter only to a properly grounded power socket.



Attention:
Only use the appliance with the original power adapter that came with it. In order to avoid a dangerous situation from arising, never use a different type of power adapter.

- Do not disconnect the power adapter from the power socket by pulling on the power cord. This could damage the power adapter or the power socket. Disconnect the power adapter from the power socket by pulling on the plug.
- Never use the power adapter supplied with this appliance for any other purposes.
- Keep the power adapter and its power cord dry.
- Do not place the power cord of the power adapter over sharp objects. Make sure that the power cord does not hang over the edge of a table and that it is not touching a heated surface.
- Do not wind the power cord of the power adapter around the handle of the appliance.
- Do not connect and disconnect the power adapter cord to and from the power socket with wet hands.
- Store, charge and use the appliance at an ambient temperature of 15 °C to 35 °C. Do not charge the appliance for longer than is necessary for it to fully charge. Once it is charged, disconnect it from the power source.
- Do not expose the appliance to temperatures higher than 50 °C. Otherwise, the built-in battery could be damaged.
- The appliance is equipped with a built-in long-life battery that can only be removed at a professional service centre. Never attempt to remove it from the appliance yourself.



Attention:
Never disassemble the appliance for the purpose of removing the battery. Never short circuit the appliance or throw it into a fire. Incorrect use, risks releasing toxic substances or causing a fire or explosion.

- Do not charge, use or store the appliance or leave it lying in a bathroom or in locations where it could fall into a bath, wash basin or other containers filled with water.
- In the event that the appliance falls into water, under no condition reach for it, rather, immediately disconnect the power adapter from the power socket. Never use an appliance or power adapter that was submerged in water. Hand it over to an authorised service centre for inspection.



Warning:
Do not use the appliance in the bath or shower. Do not clean the body of the appliance under a water tap, do not spray it with water or any other liquid or submerge it in water or any other liquid.
The appliance is not intended for wet shaving.

SAFETY DURING USE

- This electric shaver is intended for home use only and is designed for shaving and trimming beards or whiskers and facial hair. The electric shaver is not intended for commercial purposes or for trimming animal fur.
- Only use the electric shaver on dry, clean beards or whiskers. Do not use it on wet beards or whiskers on which a shaving foam or gel, etc. is applied.
- We do not recommend using the electric shaver on parts of the face where there are open wounds or lacerations, burns, blisters, etc.
- For hygiene reasons, the electric shaver should be used only by a single user.
- Use the electric shaver in accordance with the instructions contained in this user's manual.
- Use only the original accessories supplied with this electric shaver.
- The electric shaver and its power adapter must only be used in indoor areas. Do not use it outdoors.
- Do not use the electric shaver in rooms where aerosol sprays are used or where oxygen is administered.
- Do not expose the electric shaver to the outdoor environment, extreme temperatures, direct sunlight, excessive humidity or excessively dusty environments.
- Do not place the electric shaver near heaters, open fires or other sources of heat.




Warning:
Keep the electric shaver dry.

- Before every use, check the shaving head for damage. Never use an electric shaver with a damaged shaving head.
- The electric shaver may heat up during use or when it is being charged. This is completely normal.
- Keep the electric shaver at a safe distance from eyes.
- Always turn off the electric shaver and disconnect it from the power socket when not using it, when leaving it without supervision, before cleaning, maintenance or storage. Store the electric shaver and its power adapter in a dry environment.
- Keep the electric shaver clean. Perform cleaning and maintenance according to the instructions in chapter Cleaning and maintenance.
- Do not perform any maintenance on the electric shaver other than cleaning the individual components as described in chapter Cleaning and maintenance.
- Never use an electric shaver or power adapter that are damaged in any way.
- Do not use the electric shaver if it has fallen on the floor, if it was submerged in water, if it is not functioning correctly or if it is damaged in any other way.
- In order to prevent a hazardous situation from arising, do not repair the electric shaver or any of its accessories yourself or modify it in any way. For all repairs, contact an authorised service centre. By tampering with the product you risk voiding your legal rights arising from unsatisfactory performance or quality warranty.

Copyright © 2021, Fast ČR, a.s.

SENCOR® SMS 5510BK


A




Copyright © 2021, Fast ČR, a.s.

Revision 03/2021


B




C



D



E



Copyright © 2021, Fast ČR, a.s.

EN Electric Shaver
User's manual

- Prior to using this appliance, please read the user's manual thoroughly, even in cases, when one has already familiarised themselves with previous use of similar types of appliances. Only use the appliance in the manner described in this user's manual. Keep this user's manual in a safe place where it can be easily retrieved for future use. In the event that you hand this appliance over to somebody else, make sure to also include this user's manual.
- Carefully unpack the appliance and take care not to throw away any part of the packaging before you find all its parts. We recommend saving the original cardboard box, packaging material, purchase receipt and responsibility statement of the vendor or warranty card for at least the duration of the legal liability for unsatisfactory performance or quality. In the event of transportation, we recommend that you pack the appliance in the original box from the manufacturer.

DESCRIPTION OF THE ELECTRIC SHAVER AND ITS ACCESSORIES

A1 Cutters
A2 Shaving head with cutter holder
A3 On/Off switch
A4 Display
A5 Power cord connection socket
A6 Trimming attachment
A7 Power adapter
A8 Power cord plug
A9 Cleaning brush
A10 Protective cover
A11 Cloth bag

B1 Battery level indicator
B2 Need to recharge / charging indicator
B3 Lock indicator

PURPOSE OF USE

- The electric shaver is intended exclusively for dry shaving of beards and trimming of sideburns, moustaches or smaller whiskers. The electric shaver is not intended for wet shaving or for cutting synthetic hair or animal fur.
- The electric shaver is intended for domestic use and is not intended for business activities or other professional areas of use.

CHARGING

- The electric shaver has a built-in battery that enables its cordless operation.

Note:
Before first use or after not using it for a long time, first allow the electric shaver battery to fully charge without turning it on.

- Check that the electric shaver is turned off. Insert the power adapter plug into the socket on the electric shaver and plug the power adapter into a power socket.
- The battery will start charging when connected to mains power. The lightning bolt symbol **B2** will start flashing on the display.
- The charging time differs depending on the current battery power level. If the battery is completely discharged (flat), the charge may take up to 90 minutes.
- When the battery is fully charged, the symbol **B1** will be permanently lit on the display. Disconnect the fully charged electric shaver from the power adapter and disconnect the power adapter from the power socket.

Attention:
Do not leave the electric shaver connected to the power grid for longer than is necessary to charge it.

- A fully charged battery will provide approximately 60 minutes of cordless operation. Then it is necessary to charge the battery again.

DIRECT DRIVE TECHNOLOGY

- If the battery of the electric shaver is discharged (flat) or if it is discharged during cordless operation, the shaver can be plugged into mains power and can continue to be used. This is enabled by **DIRECT DRIVE** technology used on the electric shaver. Therefore, it is not necessary to wait for a minimum charge.

RECOMMENDATIONS FOR EXTENDING THE LIFETIME OF THE BATTERY

- In order for the built-in battery to serve you as long as possible, charge, use and store the electric shaver in a dry environment at an ambient temperature of 15–35 °C. Lower or higher temperatures have a negative impact on the lifespan of the battery.
- Do not wait for the battery to become completely flat. It is better to charge the battery before it is completely flat.
- When the electric shaver is not used for an extended period of time, charge it at least once every 6 months.

OPERATION

SHAVING

- Turn on the electric shaver by pressing the switch **A3**.
- Hold the electric shaver at a right angle to the skin surface and in short circular motions glide the shaving head over the skin on the face, moving against the growth direction of facial hair. Apply appropriate pressure to the skin. Do not push too hard.
- Tension the skin with your free hand when shaving hard to reach places such as, for example, on the chin. In this way you will achieve better shaving results.

Note:
It may take your skin and facial hair two to three weeks to become accustomed to the new way of shaving. During this period, we recommend using the electric shaver every day.

Note:
In the event that the electric shaver heats up significantly during use, allow it to cool down for at least 30 minutes.

- When you have finished shaving, clean the electric shaver according to the instructions in chapter Cleaning and maintenance.

TRIMMING

- For trimming sideburns or clipping moustaches or goatees, use the trimming attachment **A6**.
- Grasp the shaving head **A2** and pull it upwards to slide it out of the body of the electric shaver. In its place, slide in the trimming attachment (fig. **C**).
- Turn on the electric shaver by pressing the switch **A3**. Hold the blades of the trimming attachment at a right angle to the respective part of the skin.
- When you have finished trimming, remove the trimming attachment and clean it according to the instructions in chapter Cleaning and maintenance.

LOW BATTERY POWER INDICATION

- When the lightning symbol **B2** starts flashing on the display while the electric shaver is used, this means that the battery is almost discharged (flat). If this happens, turn off the electric shaver, plug it into mains power and continue using it.

TRAVEL LOCK

- The travel lock prevents the electric shaver from being turned on accidentally, e.g. while travelling.
- Activate the travel lock by pressing and holding down the button **A3** until the lock symbol **B3** is shown on the display. The On/Off switch **A3** does not react to being pressed.
- To deactivate the travel lock, again press and hold down button **A3**. The lock symbol will first start flashing and then turn off. Now the electric shaver is again ready for use.

CLEANING AND MAINTENANCE

- For hygiene reasons, clean the electric shaver after every use. Regular cleaning is also important to ensure the correct operation of the electric shaver and to extend the lifespan of the cutters.
- Turn off the electric shaver before cleaning it. Never clean the electric shaver when it is charging and connected to the power supply.
- For cleaning, do not use brushes with hard bristles, cleaning products with an abrasive effect, solvents, etc. Otherwise, the cleaned surface may be damaged.

CLEANING THE ELECTRIC SHAVER AND ADAPTER

- The electric shaver unit can be cleaned using a clean dry cloth. In the event that it is very dirty, you can use a lightly dampened cloth. Then thoroughly wipe the cleaned surface dry.
- To clean the power adapter and the power cord, use a clean, dry cloth.

CLEANING THE SHAVING HEAD

- Use the cleaning brush **A9** to remove all beard and whisker remains from the shaving head and cutters.
- Pull the shaving head upwards to remove it from the body of the electric shaver. Use the cleaning brush to remove any grime and whisker remains from the shaving head mounting area (fig. **D**).

For quick and easy cleaning, after being removed from the body of the electric shaver, the shaving head can be rinsed under a water tap.

Warning:
Always remove the shaving head from the body of the electric shaver before washing it.
The body of the electric shaver is not intended to be washed using water. There is a risk of serious injury by electrical shock!

- Open the shaving head itself and rinse out and insides with lukewarm running water (fig. **E**). Leave the parts of the shaving head to dry naturally and then reassemble everything and mount it on the body of the electric shaver.

Copyright © 2021, Fast ČR, a.s.

CLEANING THE TRIMMING ATTACHMENT

- Use the cleaning brush to remove all whiskers and body hair from the trimming attachment.
- Remove the attachment from the body of the electric shaver and also clean out the mounting area for the attachment or shaving head.



Attention:
The blade edges of the trimming unit are sharp, pay increased attention when handling them.

STORAGE

- When you have finished using it, you can store the electric shaver with all its accessories in a suitable location out of children's reach. Keep the electric shaver away from extreme temperatures, direct sunlight and excessive humidity. Do not use in an overly dusty environment.

TECHNICAL SPECIFICATIONS

Electric Shaver

Built-in battery ..... Li-Ion, 3.7 V, 800 mAh
Dimensions (width × depth × height) ..... 167 × 56 × 59 mm
Weight ..... 161 g
Noise level ..... 72 dB(A)

Power adapter


Input ..... 100–240 V AC, 50/60 Hz, 0.2 A
Output ..... 5 V/DC, 1 A
Electrical shock protection class II
Safety class for electrical shock protection IPX4

The declared noise emission level of the appliance is 72 dB(A), which represents a level A of acoustic power with respect to a reference acoustic power of 1 pW.

EXPLANATION OF TECHNICAL TERMINOLOGY

Safety class for electrical shock protection for contact with a liquid:
IPX4 – The appliance is protected against spraying water from all angles.

Electric shock protection class:



Class II – Electrical shock protection is provided by double or heavy-duty insulation.

Changes to text and technical parameters are reserved.

DISPOSAL OF USED BATTERIES

Prior to handing over the appliance at a specialised collection facility, it is necessary to ensure that the built-in battery is removed. Battery removal will be performed at the authorised service centre. In the event that the product has been disassembled for the purpose of ecological disposal then it must not be reassembled.



This symbol indicates that used batteries do not belong in ordinary municipal waste. Hand over used batteries to designated collection points for proper disposal. Correct disposal of batteries will help prevent negative impacts on the environment and human health.

Disposal in other countries outside the European Union.
This symbol is valid in the European Union. If you wish to dispose of used batteries, request the necessary information about the correct disposal method from the local authorities or from your vendor.

INSTRUCTIONS AND INFORMATION REGARDING THE DISPOSAL OF USED PACKAGING MATERIALS

Dispose of used packaging material at a site designated for waste in your municipality.

DISPOSAL OF USED ELECTRICAL AND ELECTRONIC EQUIPMENT



This symbol on products or original documents means that used electric or electronic products must not be added to ordinary municipal waste. For proper disposal, renewal and recycling, hand these products over to determined collection points. Alternatively, in some European Union states or other European countries you may return your appliances to the local retailer when buying an equivalent new appliance.
Correct disposal of this product helps save valuable natural resources and prevents potential negative effects on the environment and human health, which could result from improper waste disposal. Ask your local authorities or collection facility for more details.
In accordance with national regulations penalties may be imposed for the incorrect disposal of this type of waste.

For business entities in European Union states
If you want to dispose of electric or electronic equipment, ask your retailer or supplier for the necessary information.

Disposal in other countries outside the European Union.
This symbol is valid in the European Union. If you wish to dispose of this product, request the necessary information about the correct disposal method from the local council or from your retailer.

CE This product meets all the basic requirements of EU directives related to it.

Copyright © 2021, Fast ČR, a.s.