BARBERBOSS

QR-6087



Importer: Elite Capital Limited
Address: Studio 4 Clarks Courtyard, 145 Granville Street, Birmingham, B1 1SB. United Kingdom.
Website: barberboss.co.uk
Email: care@barberboss.co.uk

Thank you for selecting 3 in 1 Pro-Multi-Grooming Set. The Grooming Sets are advanced line of men grooming appliances, known for performance and reliability. This manual provides not only safety information but also important tips on handling your new Grooming Set properly,caring for it and providing helpful styling tips that will give you years of service and elegant style.

UNIT IDENTIFICATION




6


7


8


9


10


11


12

UNIT IDENTIFICATION

1. Blades
2. Rotary knob
3. Power button
4. Digital display
5. USB Charging point
6. Precision blade
7. T- blade
8. Design blade
9. USB cable
10. Lubricating oil
11. Cleaning brush
12. Set of 4 comb, 2 each for T blade & precision blade



Caution

- The standard charging time is 180 minutes. In order to avoid mangling of the batteries, please do not extend the charging time.
- Please do not charge if the temperature is below 0℃ or higher than 45℃.
- Use the cable which is supplied with this unit.
- Please do not charge if it is near sunlight in perpendicular incidence or the heat source radiates.
- Keep away from children.
- Do not panic if the trimmer gets warm during operation or charging.
- Do not tamper with the moving parts.
- Clean the trimmer using only a damp cloth, never use a caustic solution.
- Never clean, replace or remove trimmer comb while the appliance is switched On.
- Do not apply pressure on the cutting blades.
- Do not touch cutting blades with hard objects as this may damage them.

Warning

- Always keep the appliance dry.
- Keep this appliance out of the reach of children and infants.
- This appliance is not intended for use by persons (including children and infants) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given proper supervision and instructions concerning the use of this appliance by a person responsible for their safety.
- Children should be instructed and supervised to ensure that they do not touch or play with this appliance.
- Never reach for any electrical appliance that has fallen into water or any other liquid. Immediately switch off the power supply at the main breaker and then unplug.
- Do not use this appliance near flammable objects such as benzene, aerosol cans, spray products or any other toiletries.
- Never leave this appliance unattended while it is turned on.
- Always unplug the appliance after use, and disconnect the cord from the electricity mains or any other charging device.

- Use this appliance only for its intended use as described in this manual.
- Do not use any attachments or accessories or parts of any other manufacturer or any equipment that product does not recommend.
- Do not use an extension cord to operate this appliance.
- Always check the appliance before use, Do not use the appliance if the cord or blade seems damaged.
- Do not use the appliance with a damaged cord or plug.
- Do not use if the appliance has been dropped, left outdoors, submerged in water or if it is not working according to instructions.
- Do not use the appliance if it is not working properly or a burning smell is coming. Stop using the appliance immediately.
- Avoid using thinner, benzene, or any other solvent to clean the appliance.

Charging

- Beard/hair trimmer is meant for cord and cordless use.
- Make sure the trimmer is switched OFF before charging.
- You can charge the trimmer by just plugging in the USB cable onto a laptop, power bank or use your adaptor.
- Charge your trimmer for 180 minutes to get 150 minutes of cordless use.

Attaching / removing the comb attachment

- Turn off the appliance before placing, changing or removing the comb attachment.
- Place the comb attachment on the cutting edge of the cutting unit and press it down onto the cutting unit in the direction of the unit until light click sound comes. (as shown in fig. 1)

Grooming set attachment description

Precision & T-Blade Combs	RESULTING HAIR LENGTH (In mm)
Comb 1	1-10
Comb 2	11-20
ATTACHMENT	**USAGE**
Precision Blade	For precision styling and grooming
T-Blade	For trimming beard & hair
Design Blade	To design your side looks and beard

How To Use

This beard trimmer comes with Stainless Steel Blades and includes 5 blade and 4 comb attachments with 40 length settings (0.5mm-20mm) to trim your beard to the exact length. The trimmer washable blades and comes with battery. The ergonomically designed trimmer can be used cord and cordless both and is charged with a USB cable.

To Thin and Narrow the Beard/Moustache:

1. Make sure that trimmer is fully charged before you use it for the first time.
2. Rotate knob to set required comb height and Press the switch ON.(fig.2)
3. Place the flat top of the trimmer comb against the skin and keep going.(fig.3)

For Defined Beard/Moustache

1. Hold the personal groomer with precision trimmer blade facing you.
2. Start with the edge of beard or moustache line and gently lower the trimmer blade onto your skin.(fig.4)

Trimming Tips

- If you are trimming for the first time, use the comb at the maximum trimming length setting to prevent inaccurate trimming.
- Since all hair do not grow in the same direction, you may want to try different trimming positions (i.e., upwards, downwards, or across). Practice is best for optimum results.
- Be very careful when you are trimming without comb.
- Use Trimmer without comb for fine trim look.
- Use 1mm-10mm comb for a 3 day stubble look.
- Use 11mm-20mm comb for a medium/long beard.

Cleaning

- Clean the trimmer after each use.
- Always switch OFF the trimmer, unplug or remove power supply cord from trimmer before cleaning.(fig.8)
- Use a soft, dry cloth to clean trimmer body.
- Remove the trimming comb and clean with the brush.
- Remove the cutting unit by pushing against the blades and use the brush supplied to clean. (as shown in fig. 6)

Maintenance

- Make sure the appliance is switched off and disconnected from the mains.
- Remove the beard trimming comb. (fig. 1)
- To clean the blades, detach the cutting unit. (fig. 5)
- Put a drop of oil on blades for lubrication. (fig. 7)

Technical Specifications

Power Source: 100-240V~, 50/60Hz
Input Voltage: 5V ⎓ 1A
Charging Time: 3 Hours
Usage Time: 150 Minute

Safe Appliance Disposal

- At the end of its working life, the product must not be disposed of as urban waste.

It must be taken to a special local authority differentiated waste collection centre or to a dealer providing this service. Disposing of a household appliance separately avoids possible negative consequences for the environment and health deriving from inappropriate disposal and enables the constituent materials to be recovered to obtain significant savings in energy and resources.

- As a reminder of the needs to dispose of household appliances separately, the product is marked with a crossed-out wheeled dustbin.

