

ACW-5054

denver.eu

04/24

FR

Cet appareil et ses accessoires sont recyclables

À DÉPOSER EN MAGASIN

OU

À DÉPOSER EN DÉCHÈTERIE

Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !

Safety information

Please read the safety instructions carefully before using the product for the first time and keep the instructions for future reference.

1. Warning: This product includes lithium polymer batteries
2. Keep produet out of the reach of children and pets to avoid chewing and swallowing.
3. Product operating temperature is from 0 degree Celsius to 45 degree Celsius and storage temperature is from 30 degree Celsius to 65 degree Celsius. Under and over this temperature might affect the function.
4. Never open the product. Touching the inside electrics can cause electric shock.Repairs or service should only be performed by qualified personnel.
5. Do not expose to heat, water, moisture, direct sunlight!
6. The unit is not waterproof unless using the transparent waterproof casing. Casing is water proof to 30 meters.
7. If water or foreign objects enter the unit, it may result in fire or electric shock. If wateror a foreign object enters the unit, stop use immediately
8. Only charge with supplied USB cable.
9. Do not use non original accessories together with the product as this can make theproduct functionality abnormal

camera Diagram



1. USB Type C 2. Microphone 3. Micro SD card 4. Battery door

5. Power button/Mode key 6. Lens 7. Charging indicator 8. Working indicator

9. Display 10. Recording indicator 11. OK 12. Up key/WIFI key 13. Down key

14. Speaker

Detail Instructions

1.Insert Micro SD card

Note: Please use a brand name Micro SD card, format it on a computer before use. Using a low quality card may not be guaranteed to work properly

2. Battery Charge

A. Connect to a computer or a power adapter by USB cable for charging

B. Use a car charger. Product can also be charged in the car.

C. When charging, the red indicator light will stay on, once fully charged, the red light will turn off.

3.Camera on and off

A. Long press the Power button/Mode key for about 3 seconds, camera will then turn on.

B. Long press the Power button/Mode key for about 3 seconds, camera will then turn off.

4. Mode switch

Short Press Power button/Mode key will change the camera to video/photo/playback/setup menu.

5. Video recording

A. Insert Micro SD card, then turn on the camera.

B. Then short press the “OK" button, camera will start recording video.

C. To stop recording video, press the "Ok" button again,

6. Photo taking

A. Change the camera to photo mode by pressing the Power button/Mode key

B. Short press the "OK" button to take the photo.

7. Playback mode

By pressing mode button switch to Playback mode, then press the up and down keys to select the video or photo to review, and press OK to play the video.

8.Menu settings

A. When switching to Menu setting up mode, press the up and down button to select the menu, then press the "OK" button to select.

9. Connecting to computer

With USB cable connect the camera to the computer, on the screen there will appear 3 connection modes: Mass storage/PC camera/Charge battery, You can press the up/down button to select the connection mode.

10. WIFI connection

The machine can be connected to a phone or tablet by following these steps:

A. Search " Denver ACW-5054” in Google Play or App Store to download the APP.

B. Turn on the camera, Short press the "up wifi button to turn on the WiFI, the camera screen will show a WIFI logo and then appears SSID and PW (initial password): 12345678

C. Use your phone to connect to this WIFI

D. Turn on the APP to start to control the camera.

Specifications

LCD Screen	2.0 LCD
Camera shot	140 degree
Menu Language	Danish-German-Spanish-French-Italian-Dutch-Polish-Portuquese-Finnish-Norwegian-English-Swedish-Croatian
Video Resolution	FHD(1920*1080P)(interpolated) HD(1280*720P) VGA(640*480P)
Video Format	AVI
Video compression formats	MJPG
Photo resolution	12M,8M, 5M, 3M, 2M, 1.3M VGA,(interpolated)
Storage card	Micro SD card
USB	USB2.0
Battery capacity	900MAH
Power consumption	400mA@4.2V
Charging time	About 3 hours
Dimension	59.27*41.13*29.28mm

Please notice - All products are subject to change without any notice. We take reservations for errors and omissions in the manual.

ALL RIGHTS RESERVED, COPYRIGHT DENVER A/S

denver

denver.eu

CE



Electric and electronic equipment and included batteries contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment and batteries) is not handled correctly.

Electric and electronic equipment and batteries is marked with the crossed out trash can symbol, seen above. This symbol signifies that electric and electronic equipment and batteries should not be disposed of with other household waste, but should be disposed of separately.

As the end user it is important that you submit your used batteries to the appropriate and designated facility. In this manner you make sure that the batteries are recycled in accordance with legislature and will not harm the environment.

All cities have established collection points, where electric and electronic equipment and batteries can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Additional information is available at the technical department of your city.

Hereby, Denver A/S declares that the radio equipment type ACW-5054 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: denver.eu and then click the search ICON on topline of website. Write model number: ACW-5054.Now enter product page, and RED directive is found under downloads/other downloads.

Operating Frequency Range: 2.412−2.483GHZ

Max Output Power:2W

DENVER A/S
Omega 5A, Soeften
DK-8382 Hinnerup
Denmark
www.facebook.com/denver.eu