英语

EN

Inside The Box



Headphones × 1 Pair
Charging Case × 1



Carrying pouch × 1



User Guide × 1



Type-C Charging Cable × 1



Silicone Ear Tips x 3 Pair
(XS/S/L)




Silicone Ear Tips x 3 Pair
(S/M/L)



Silicone Ear Grips × 3 Pair
(XS/S/L)

EN

Headphones



EN

Replace




Placement



EN

Power



Headphones enter standby mode:
Headphones are turned on:
1. When earbuds are placed into charging case with battery.
2. When earbuds are taken out of the case and not used or worn for 3 minutes.
* Above functions are available for either earbud in individual or Stereo mode.

EN

Pairing the Earbuds

There are two ways to pair the earbuds together:
1. Both earbuds are in the case (with battery). Just open the case and the earbuds will automatically pair to eachother.
2. Take both earbuds out of the case and power on, when turned on simultaneously, they will pair to eachother automatically.

Connecting to your device

To connect to your device during first use, turn the headphones on to enter pairing mode, the red and blue lights of the Master earbud will flash alternatively. Headphones will power off if not paired to a device within 2 minutes.
* After first successful pairing, headphones will automatically connect to your device.
To connect to a different device and pair with a new one, please put headphones back into the case, then press and hold the button in case for 2 seconds to re-enter the pairing mode.
* Above functions are available in individual mode, and can also be implemented in Stereo mode.

Switching Master/Slave Between Left/Right Earbud

The default setting with the earbuds is Right as the Master and Left as the Slave. As the Master, Right earbud will automatically connect to your device, while the Left earbud connects to the Right earbud. Master/Slave switch:
1. Left earbud will switch to Master when the battery level of the Left earbud is 30% higher than the Right.
2. If Master becomes out of range from connected device, then the Slave will switch to Master and initiate pairing mode to connect to your device. Previous Master will enter Left & Right pairing mode.



EN

Charging ① To charge the case with Type-C cable.




② To charge the headphones with the case.




EN

Battery Notification



EN

Controls



* Above functions may vary with different devices.

EN

Active Noise Cancellation & Pass-Through Function

These headphones include 2 levels of ANC and Pass-through functions for a comfortable listening experience in different noisy environments. To activate them, double-tap the surface of the earbud (left or right) with your fingertips to toggle through different settings.

① ANC Level 1: suitable for aviation, highspeed train, metro etc.
② ANC Level 2: suitable for noisy daily circumstances, such as mall, café, streets etc.
③ Pass-through: Let's in environmental sounds so you don't need to take out the earbuds to hear what is going on around you.



EN

Extra Functions

1. If headphones cannot pair normally when power on. Open the case, quickly click the pairing button in the case for 3 times to initial searching for Left & Right pairing.
2. To unpair the cellphone:
Put both L & R into the case, and then press and hold the pairing button in the case for 8 seconds.
3. OTA Firmware Update: can be done synchronously with 1MORE Assistant APP when Left and Right headphones Bluetooth paired to each other.

Limited Warranty

1MORE Inc., (1MORE) warrants to the original retail purchaser that this product is to be free from defective materials and workmanship for a period of one year from the date of purchase, if it is properly used and maintained. If this product proves defective in either material or workmanship, 1MORE, at its option, will (a) repair the product, or (b) replace the product, at no charge for parts or labor. If the product model is no longer available and cannot be repaired effectively or replaced with an identical model, 1MORE at its sole option may replace the unit with a current model of equall or greater value. In some cases, modification to the mounting surface may be required where a new model is substituted. 1MORE assumes no responsibility or liability for such modification.
To obtain a repair or replacement under the terms of this warranty, please return to dealer first, if possible, and the dealer will direct you accordingly for repairs or replacement. You will be required to submit a copy of the original receipt.
Return shipping for exchanges/repairs is the sole responsibility of the original retail purchaser.

EN

Limitations:
- This limited warranty does not cover failure of the product resulting from improper installation, misuse, abuse, accident, neglect, mishandling, or wear from ordinary use or environmental deterioration.
- This limited warranty does not cover cosmetic damage, including paint damage, or consequential damage to other components or premises which may result for any reason from the failure of the product.
- This limited warranty is null and void for products not used in accordance with 1MORE's instructions.
- This limited warranty is null and void for products with altered or missing serial numbers and for products not purchased from an authorized dealer.
- This limited warranty terminates if you sell or otherwise transfer this product to another party.

We Appreciate Your Business

We know you will enjoy new 1MORE headphones as much as we do. At 1MORE, we value your satisfaction. If you would like more details on this product or any of our other products, please visit us online by scanning the QR code. Go to www.1more.com and sign up for VIP, and 1MORE will treat you like one.

Tips

1. Please read this instruction manual carefully and retain for future reference.
2. Please fully charge the battery before first use.
3. If the headphones have been unused for more than 3 months, we recommend that you charge them. This will improve battery capacity.
4. Only use chargers that are FCC (Federal Communications Commission) approved.
5. In dry environments, static electricity may numb your ear. This is not related to the quality of the product.

EN

Safety Information

1. Never disassemble the headphones. There are no user-serviceable parts inside.
2. Do not expose the headphones to temperatures below 32 °F (0 °C) or to temperatures above 113 °F (45 °C).
3. Do not use the headphones in a thunderstorm storm. This could prevent the headphones from working properly, and also increase your chance of being electrically shocked.
4. Do not use oil or any volatile liquid to clean this product.
5. Do not listen at high volumes for extended periods of time.
6. Do not use the headphones while operating a motor vehicle. Do not use the headphones any time it would be dangerous to be unaware of noises around you.
7. Adult supervision is required for children age 6 and under.
8. If you don't feel comfortable after wearing the headphones, please refer to an aurist for advice on whether or not in-ear headphones are suitable for you.

WEEE

Electrical and electronic equipment, parts and batteries marked with this symbol must not be disposed of with normal household wastage, it must be collected and disposed of separately to protect the environment.
Your 1MORE retailer will advise you of the correct way of disposal in your country.
Do not expose batteries or battery packs to excessive heat such as sunshine, fire or the like.

CE

Hereby, 1MORE, declares that this Radio LAN device is in compliance with the essential requirements and other relevant provisions of Directive 2014 / 53 / EU.

EN

FCC

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution!
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

EN

FAQ

1. The headphones don't turn on.
Check if your headphones have enough battery life. If not, please charge them for at least 30 minutes.
2. The headphones and my device do not connect, or take a long time to connect.
1) Check that your headphones are in the "discoverable" mode (red and blue lights flash alternately).
2) Make sure that your headphones are not connected to other devices, and that your device is not connected to other Bluetooth devices.
3) If headphones fail to connect excluding above conditions, please press L and R buttons for 5 seconds when charging, and then take them out of the case:
a. Press L and R buttons twice simultaneously to clear pairing records and re-start the pairing between headphones and device.
b. Press L and R buttons for 4 times simultaneously to clear pairing records and re-start the pairing between headphones.
3. My Android device successfully connects to the headphones, but the headphones don't play music.
After pairing successfully, on the Bluetooth menu of your device, tap the icon on the right of your device name and make sure the "Media Audio" option is on.
4. My Android device successfully connects to the headphones, but there is no sound from the headphones while making phone calls.
After pairing successfully, on the Bluetooth menu of your device, tap the icon on the right of your device name and make sure the "Phone Audio" option is on.
5. The Bluetooth connection is not stable, causing some interruptions.
1) Try shortening the distance between your headphones and device. Avoid solid barriers in between.
2) Please keep away from strong interference sources, such as Wi-Fi and GPRS.
3) Please make sure the Bluetooth antenna of your device is not blocked.
6. While using third party music/video player apps, some in-line remote control functions do not match those in the manual.
Your operating system and the third party music/video player apps may have different settings for the in-line remote control functions. We recommend that you use the music/video player apps that your device has originally provided.