

Covers for switches/push-buttons
Cover plate
with operating knob and neon lamp



For flush-mounted switch 1g1w, 1g2w, intermediate, push switch.

Order Code : 2CKA001753A0067

Article No. : 1786-783

EAN: 4011395083239