



TAB-P748IPS Playstore Fix

*Dear Costumer: This fix has to be done on your **Tablet**.*

Preparation: Be sure to connect the charger to the tablet!




Switch on tablet:


Step 1: Select your Language (Portuguese)

TAB-P748IPS PLAYSTORE FIX


2: Press Skip /



3: Confirm /



4: Set your time zone and press next /



5: Enter your name and press next / Digite seu nome e pressione a seguinte

A adição do seu nome permite ao telemóvel personalizar algumas aplicações.

Nome

Próprio 1

Apelido 2

3 SEGUINTE >

6: Make your selection and press next /

Este telemóvel também pode receber e instalar atualizações a partir do Google. Ao continuar, estará a aceitar os [Termos de Utilização do Google](#) e a [Política de Privacidade](#).

☒ Utilize o serviço de localização da Google para ajudar as aplicações a determinar a localização. Isso significa enviar dados de localização anónimos para a Google, mesmo quando não há aplicações em execução. [Saiba mais](#)


☒ Ajuda a melhorar os serviços de localização deixando as aplicações e os serviços a procurar redes Wi-Fi, mesmo quando o Wi-Fi está desativado.

☒ Ajuda a melhorar a sua experiência Android enviando dados de diagnóstico e utilização automaticamente para a Google. Estas informações não serão utilizadas para c(a) identificar e ajudar as equipas a trabalhar em coisas como a autonomia da bateria, o desempenho da aplicação e novas funcionalidades Google. [Saiba mais](#)

Serviços Google


SEGUINTE >

7: Press OK /




TAB-P748IPS PLAYSTORE FIX


8: Press OK /



9: Press Settings /



10: Press Wifi /




TAB-P748IPS PLAYSTORE FIX


11: Select Wifi you want to connect to /



12: Enter your password and press connect /




13: When connected to your Wifi press Circle (Home) on screen




TAB-P748IPS PLAYSTORE FIX


14: Press Browser /



15: Enter: downloads.pointofview-online.com




16: Press 748fix.zip to start download




TAB-P748IPS PLAYSTORE FIX

17: Tablet starts downloading file /




18: Wait until download is finished /




19: Press Settings /




20: Press About Tablet /




21: Press Wireless update /




22: Press option /



23: Select local updates /





24: Go to **Download** folder and select **748.zip** and confirm /




TAB-P748IPS PLAYSTORE FIX

25: Press OK and Wait until tablet restarts (this can take up to 3-5 minutes !)


So be patient. /




26: Now wait until tablet is finished updating /




27: Congratulations Your Tablet is now updated /




28: Optional to free up Space on tablet => Go to File Manager /




29: Press and Hold *LocalSdUpdate.zip*



30: Press Delete File /



31: Press Delete /



End