

Covers for switches/push-buttons
Switch rocker with marking
with small transparent lens



With "Plug" icon.

As cover for flush-mounted switch 1g1w DP and 3pole with neon lens and marking "I O"

As cover for flush-mounted 1gang 1way, 1gang 2way switch, intermediate switch, push-button and control switch 1gang 2way.

Order Code : 2CKA001751A3162

Article No. : 1789 ST-866

EAN: 4011395227862