







SILVERSTONE

IceMyst Pro Series

liquid cooling
user's manual




www.silverstonetek.com

SilverStone Technology Co., Ltd.
support@silverstonetek.com

NO.G11255880

Contents

A




FAN SCREW x8 (240/280)
x12 (360/420)

B




CASE SCREW x8 (240/280)
x12 (360/420)

C




SPRING SCREW x4

D



LGA115x WASHER x4

E



LGA1700 SPACER x4

F




AM4/AM5 SCREW x4

G




TR4/TR5 SCREW x2

H



THERMAL GREASE x1

I



Intel CLIP x1

J




AM4/AM5 CLIP x1

K



TR4/TR5 CLIP x1

L




Intel BACK PLATE x1

M




4PIN PERIPHERAL
ADAPTER CABLE x1

N



2 IN 1 FAN CABLE x1
(240/280)

O




3 IN 1 FAN CABLE x1
(360/420)

P




ARGB SYNC CABLE x1

Q



MB SYNC CABLE x1

R




ARGB CONTROL BOX x1

S






SATA POWER ADAPTER x1


T







2 IN 1 ARGB CABLE x1




240/280




240/280





360/420




360/420



INTEL







Intel LGA 115X/1200





Intel LGA 1700/1851



AMD




AMD Socket AM4/AM5

AMD Socket TR4/sTR5
SP3/SP6






MOTHERBOARD SYNC



ARGB CONTROL BOX



PLEASE CONFIRM THE CONNECTOR, THE DEFINITION AND DIRECTION OF YOUR PIN HEADER WHEN CONNECTING CABLES.

ENSURE ARGB CONTROLLER / MOTHERBOARD HAS SAME +5V PIN DEFINITION AS ICEMYST SERIES.