

CONGRATULATIONS!

You are now the proud owner of a ROCCAT® Suora! The Suora's frameless design channels its philosophy as a raw, performance keyboard for gaming purists. Its stripped back style provides you with a more direct gaming experience that puts you closer in touch with its impressive command power. For those who want their finger on the pulse of their games, there's no better choice.

The Suora gives you raw power, unchained!



COMPACT
FRAMELESS

No palm rest, no thick border, no thumb keys, and no unnecessary media keys – just high-quality, robust mechanical keys mounted on a durable plate.

ADVANCED
ANTI-GHOSTING

The Suora comes complete with n-key rollover plus a 1000Hz (1ms) polling rate, ensuring that every key stroke will be registered, time and time again.

SOLID
DURABLE

Featuring a robust aluminum housing that provides a consistent gaming platform. Complemented by tough mechanical keys with a 50 million key stroke lifecycle.

QUICK-INSTALLATION GUIDE
IMPORTANT DOCUMENT



Should you need assistance ...
Our support team is ready to help with any technical questions. Just send an e-mail to support@roccat.org. Or visit our website at:
WWW.ROCCAT.ORG/SUPPORT

PLEASE USE YOUR PRODUCT'S SERIAL NUMBER
(LOCATED ON THE BOTTOM LABEL)
FOR REGISTRATION. SIGN IN AT:
WWW.ROCCAT.ORG/SUPPORT/AUTHENTICITY-CHECK



SPECIFICATIONS

PACKAGE CONTAINS

- ROCCAT® Suora – Frameless Mechanical Gaming Keyboard
- Quick-Installation Guide

SYSTEM REQUIREMENTS

- Windows® 7 32/64 bit
- Windows® 8
- Windows® 10
- USB 1.1 port (or better)
- Internet connection (for driver installation)

TECH SPECS

- N-key rollover
- Polling rate 1000Hz (1ms response time)
- 50 Million keystrokes lifecycle
- Multimedia functions and 6 programmable macro keys
- 43cm × 12.5cm size

ROCCAT GmbH | Gasstrasse 4 | 22761 Hamburg | Germany

© 2018 ROCCAT GmbH. All rights reserved. Any product names mentioned in this manual may be trademarks or registered trademarks and are the property of their respective owners. Information contained herein is subject to change without notice. ROCCAT GmbH shall not be made liable for any errors that may appear in this manual. This publication or parts of it may not be reproduced without the express consent of the publisher.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

FCC Caution: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

BSMI 限用物質聲明表查詢, 請上 <http://bsmi.roccat.org/154/>





Swarm provides next-level ROCCAT® product integration. It works a unified driver suite where you can keep tabs on all of your ROCCAT® devices in one place. Say goodbye to multiple tray icons – with Swarm you have a veritable gaming command HQ for every weapon in your arsenal.



KEY REMAPPING

Ensure your most-used gaming keys are remapped so that you're fully prepared for battle.



GAME MODE BUTTON

Quicklaunch gaming profiles and deactivate the Windows key with the game mode button.

MACRO EXAMPLES

WORLD OF WARCRAFT

- M1 ATTACK
- M2 AUTORUN
- M3 CHARACTER INFO
- M4 CHAT PAGE UP
- M5 CRAFTING PANEL
- M6 QUESTLOG

DE ANLEITUNG

- Für einen ergonomischeren Stand klappe die Füße an der Unterseite der Tastatur aus.
- Verbinde den USB-Stecker der ROCCAT® Suora mit einer freien USB-Schnittstelle.
- Starte deinen Computer neu und stelle eine Verbindung zum Internet her.
- Rufe www.roccat.org/roccat-swarm auf und lade dir die neuste Swarm Version herunter.
- Starte die Software Installation und folge den Anweisungen.

DK INSTRUKTIONER

- Til ergonomisk opstilling klappes fødderne på tastaturets bund ud.
- Forbind ROCCAT® Suora's USB-stik med et ledigt USB-interface.
- Start computeren op, og forbind den med internettet.
- Naviger til www.roccat.org/roccat-swarm og download den nyeste version af Swarm.
- Start software-installationen, og følg anvisningerne på skærmen.

EN INSTRUCTIONS

- For a more ergonomic position, fold out the stands on the base of the keyboard.
- Plug the ROCCAT® Suora's USB connector into any free USB port.
- Start computeren op, og forbind den med internettet.
- Navigate to www.roccat.org/roccat-swarm and download the latest version of Swarm.
- Start the software installation process and follow the on-screen instructions.

ES INSTRUCCIONES

- Para un equilibrio más ergonómico, saca las patas que están debajo del teclado.
- Enchufa el conector USB del ROCCAT® Suora a un puerto libre USB.
- Reinicie el ordenador y conéctese a internet.
- Acceda a la página www.roccat.org/roccat-swarm y descárguese la última versión swarm.
- Inicie el proceso de instalación de software y siga las instrucciones de la pantalla.

FI OHJEET

- Käännä näppäimistön alla olevat jalat ulos ergonomista asentoa varten.
- Liitä ROCCAT® Suora :n USB-pistoke vapaaseen USB-liitântään.
- Käynnistä tietokoneesi ja yhdistä internetiin.
- Siirry osoitteeseen www.roccat.org/roccat-swarm ja lataa Swarm-ohjelmiston uusin versio.
- Käynnistä ohjelmiston asennusprosessi ja seuraa näyttörudulla näkyviä ohjeita.

FR INSTRUCTIONS

- Déplie les pieds sur la face inférieure du clavier pour une plus grande ergonomie.
- Relie la fiche USB de la souris ROCCAT® Suora à une prise USB libre.
- Allumez votre PC et connectez-vous à internet.
- Allez sur www.roccat.org/roccat-swarm et téléchargez la dernière version de Swarm.
- Débuter l'installation du programme et suivez les indications.

PL INSTRUKCJA

- Aby uzyskać pozycję ergonomiczną, rozłóż nóżki po spodniej stronie klawiatury.
- Podłącz wtyk USB ROCCAT® Suora do wolnego złącza USB.
- Uruchom komputer i połącz się z Internetem.
- Przejdź do strony www.roccat.org/roccat-swarm i pobierz najnowszą wersję Swarm.
- Rozpocznij instalację oprogramowania i postępuj zgodnie z instrukcjami na ekranie.

PT INSTRUÇÕES

- Para uma posição mais ergonómica, desdobre os suportes da base do teclado.
- Ligue os dois conetores USB do ROCCAT® Suora em quaisquer umas das duas portas USB livres.
- Ligar o computador e estabelecer ligação à internet.
- Navegar para www.roccat.org/roccat-swarm e descarregar a versão mais recente do Swarm.
- Iniciar o processo de instalação do software e seguir as instruções indicadas no ecrã.

RU ИНСТРУКЦИИ

- Для обеспечения эргономичного положения открой ножки на нижней стороне клавиатуры.
- Соедини USB-штекер ROCCAT® Suora со свободным USB-портом.
- Включите компьютер и выйдите в Интернет.
- Зайдите на www.roccat.org/roccat-swarm и загрузите самую новую версию Swarm.
- Начните процесс установки программного обеспечения и следуйте указаниям на экране.

SE INSTRUKTIONER

- Fäll ut fötterna under tangentbordet så att det står i en ergonomisk ställning.
- Sätt ROCCAT® Suora USB-kontakt i en ledig USB-port.
- Boota datorn och koppla upp dig på Internet.
- Gå till www.roccat.org/roccat-swarm och ladda ned den senaste versionen av Swarm.
- Starta programvaruinstallationen och följ anvisningarna på bildskärmen.