

Covers for switches/push-buttons
Switch rocker with symbol mounting hole



As cover for flush-mounted switch 1gang,2way, intermediate switch, pull switch and push switch.

for symbols 2525... and 2145...

Order Code : 2CKA001731A2000

Article No. : 2520-212-500

EAN: 4011395173855