Covers for switches/push-buttons
Rocker
screwable (fixing element)



For flush-mounted switch 1g1w, 1g2w, intermediate, push switch.

Order Code : 2CKA001731A1007
Article No. : 2506-215
EAN: 4011395113608