1Mii E700 Headphones User Guide

Connect/Pair:

1.What devices are the 1Mii E700 headphones compatible with?

Compatible with any Bluetooth device such as mobile phones,tablets,laptops,etc.

2.How to connect to a mobile phone?

1)When the 1Mii E700 headphones are turned off,press and hold the power button for 5 seconds to enter the pairing state directly(the indicator light flashes red and blue);

2)Turn on the Bluetooth function of the mobile phone and find the model "E700" to connect.

3.Why can't it be turned on?

It is recommended to charge the headphones for half an hour first.When the charging cable is connected,check whether the charging indicator light stays solid red to ensure that the 1Mii E700 headphones are charging.If the problem persists,please try to contact after-sales service.

4.How to confirm that 1Mii E700 headphones have been successfully paired?

After pairing successfully,1Mii E700 headphones will have a voice prompt and the switch indicator light will stay on for two seconds and then flash every five seconds.

5.What should I do when 1Mii E700 headphones cannot be paired?

1)Try restarting 1Mii E700 headphones and the device,make sure the Bluetooth function is turned on and the headphones are within the 1-meter pairing range;

2)If necessary,reset 1Mii E700 headphones(press and hold the"volume +"volume -"buttons for 5 seconds at the same time);

3)After resetting,1Mii E700 headphones will automatically enter the pairing state and the indicator light will flash red and blue;

4)Delete the original device name "E700" in the device list,and search for device name "E700" again to connect.

ANC:

Noise cancellation technology is designed to reduce ambient noise,but it may not completely eliminate all sounds,especially high-frequency sounds like human voices.

1.If you find that the noise cancellationfeature is not working as expected,please try:

(1)Press the ANC button until you hear the "Noise Cancelling" prompt to ensure the ANC mode is activated.

(2)Ensure L/R markings match your ears.

(3)Adjust the headband so ear cups fully cover and seal your ears.

(4)Try the headphones in a different environment.

2.How to turn on the ANC function?

When 1Mii E700 headphones is turned on,click the ANC button to switch the ANC ON/Transparent Mode/ANC OFF.

3.What is Transparency Mode?

Transparency Mode allows external sound to enter the headphones,allowing you to hear the surrounding environment while enjoying music,and is suitable for use in outdoor scenes.

4.How can I use the ANC function only without connecting any device?

When 1Mii E700 headphones is turned on(press and hold the power button for 1 second,and the red and blue lights flash),then press the ANC button to use it.

Call:

1.Does 1Mii E700 support voice calls?

1Mii E700 headphones have a built-in microphone and support voice calls. Press the power button once to answer/reject/hang up the call.

2.How do I mute the microphone?

Quickly press the ANC button 3 times to mute or unmute the microphone.

3.Why is the call volume so low?

1)Check whether the device is connected correctly;

2)Make sure the call audio and media audio are enabled and paired;

3)Try to adjust the volume using the volume button on the phone or 1Mii E700 headphones;

LDAC:

1.What devices are LDAC compatible with?

LDAC is compatible with Android devices.Not compatible with IOS devices.

2.When using the LDAC function,please follow the steps below to set up your device for your listening experience:

After connecting to 1Mii E700 headphones,please enter the Phone Bluetooth settings,find the connected Bluetooth device "E700",then enter the settings interface,find LDAC playback quality/audio quality, finally select "Compatible Audio and Connection Quality".

Charging:

1.When 1Mii E700 headphones are not charging,the following troubleshooting tips may help:

1)USB charging cable may be defective,you can replace it;
2)Please dry the charging cable.Water may cause a short circuit and prevent charging;
3)It is recommended to use a 5V/1A adapter;
4)If the problem persists,please contact after-sales team.

2.How do I know when 1Mii E700 headphones needs to be charged?

When the 1Mii E700 headphones are low on power, the LED light will flash red and emit a low-battery tone.If 1Mii E700 headphones is connected to the phone and the battery level is below 20%, it is recommended to charge the headphones immediately.

3.Can I continue to use 1Mii E700 headphones while charging?

No,but 1Mii E700 headphones supports five hours of battery life with ten minutes of charging.

4.How long does it take to fully charge the 1Mii E700 headphones?

It takes about two hours to charge the headphones to over 90%.It is recommended to charge to 90% to avoid overcharging.It takes about 3 hours to fully charge the headphones until the charging indicator turns off.

Battery Life:

1.How long can the 1Mii E700 headphones be used in ANC OFF and Bluetooth mode?

In ANC OFF mode,you can enjoy up to 75 hours of music playback time.

Note:Test data at 50% volume in 1Mii Acoustic Laboratory.

2.How long can the 1Mii E700 headphones be used in ANC ON and Bluetooth mode?

In ANC ON mode,you can enjoy up to 26 hours of music playback time.

Note:Test data at 50% volume in 1Mii Acoustic Laboratory

3.How long can the ANC function be used in wireless mode without connecting the headphones to a device?

It can be used for 2 hours,and the headphones will automatically shut down after 2 hours.

Connection Distance:

1.Why does the Bluetooth connection drop?

Make sure the 1Mii E700 headphones are fully charged and the distance between the headphones and the device is within the Bluetooth effective range.If the connection is frequently disconnected,reset the 1Mii E700 headphones and the paired device, and check for interference sources.

2.Why is the connection unstable during use?

Under normal use conditions,1Mii E700 headphones connection is usually stable,but occasional connection problems may occur in environments with strong signal interference(such as traffic lights and wireless cameras).

3.How to ensure the best Bluetooth connection stability when using 1Mii E700 headphones?

Avoid connecting to other Bluetooth devices at the same time and keep 1Mii E700 headphones and the device at a proper distance to improve the connection stability.

Wired Connection:

1.How to play audio in wired mode?

Make sure the 1Mii E700 headphones have power and plug in the included AUX to Type-C audio cable to use.

Reset:

1.How to reset E700?

Press and hold the "volume +" and "volume -" buttons for five seconds to reset (the indicator light will flash purple three times),then enter Bluetooth pairing mode(indicator will flash red and blue).

Voice Assistant:

1.How to activate the voice assistant?

You can briefly press the power button twice to activate it.

Use on Airplanes:

1.How to use the 1Mii E700 headphones on an airplane?

1)You can use a 3.5mm audio cable to connect 1Mii E700 headphones;

2)You can purchase a Bluetooth airplane adapter to connect the 1Mii E700 headphones via Bluetooth;

3)When using the headphones on an airplane without a stereo output interface,you need to purchase an adapter plug.

Multipoint Connection:

1.Does the 1Mii E700 headphones support multipoint connection?

Yes.

Note:When the first paired device is playing audio, press the pause button to allow the second paired device to play audio.

Product Parameters:

Bluetooth Version	5.1
Bluetooth Protocol	Support a2dp\avctp\avdtp\avrcp\hfp\spp\smp\att\gap\gatt\rfcomm\sdp\l2cap
Speaker Size	40mm
Speaker Power	20mW
Frequency Response	20Hz-40KHz