










Dell Pro P 24 USB-C Hub Konferenz-Monitor
P2426HEB
Schnellstartanleitung









2



3






4





1

















1







2




3











Dell Display and Peripheral Manager
Dell.com/support/ddpm



KVM



Reihenschaltung



Dell.com/support/P2426HEB