

This product has a limited 1 year warranty in North America and Australia.
For information on warranty periods in other regions, please contact your reseller or SilverStone authorized distributor.
本产品自购买之日起, 于中国地区 (不包含澳门, 香港特别行政区) 享有一年有限保证责任保固 (部分产品为二年, 三年或五年)。
详细保固年限请参照官方网站 <https://silverstonetek.com.cn/> 公布之产品型号为依据。

Warranty terms & conditions

1. Product component defects or damages resulted from defective production is covered under warranty.
Defects or damages with the following conditions will be fixed or replaced under SilverStone Technology's jurisdiction.
a) Usage in accordance with instructions provided in this manual, with no misuse, overuse, or other inappropriate actions.
b) Damage not caused by natural disaster (thunder, fire, earthquake, flood, salt, wind, insect, animals, etc...)
c) Product is not disassembled, modified, or fixed. Components not disassembled or replaced.
d) Warranty mark/stickers are not removed or broken.
Loss or damages resulted from conditions other than ones listed above are not covered under warranty.

2. Under warranty, SilverStone Technology's maximum liability is limited to the current market value for the product (depreciated value, excluding shipping, handling, and other fees). SilverStone Technology is not responsible for other damages or loss associated with the use of product.

3. Under warranty, SilverStone Technology is obligated to repair or replace its defective products. Under no circumstances will SilverStone Technology be liable for damages in connection with the sale, purchase, or use including but not limited to loss of data, loss of business, loss of profits, loss of use of the product or incidental or consequential damage whether or not foreseeable and whether or not based on breach of warranty, contract or negligence, even if SilverStone Technology has been advised of the possibility of such damages.

4. Warranty covers only the original purchaser through authorized SilverStone distributors and resellers and is not transferable to a second hand purchaser.

5. You must provide sales receipt or invoice with clear indication of purchase date to determine warranty eligibility.

6. If a problem develops during the warranty period, please contact your retailer/reseller/SilverStone authorized distributors or SilverStone <http://www.silverstonetek.com>.
Please note that: (i) You must provide proof of original purchase of the product by a dated itemized receipt; (ii) You shall bear the cost of shipping (or otherwise transporting) the product to SilverStone authorized distributors. SilverStone authorized distributors will bear the cost of shipping (or otherwise transporting) the product back to you after completing the warranty service; (iii) Before you send the product, you must be issued a Return Merchandise Authorization ("RMA") number from SilverStone. Updated warranty information will be posted on SilverStone's official website. Please visit <http://www.silverstonetek.com> for the latest updates.

Additional info & contacts
For North America (usasupport@silverstonetek.com)
SilverStone Technology in North America may repair or replace defective product with refurbished product that is not new but has been functionally tested.
Replacement product will be warranted for remainder of the warranty period or thirty days, whichever is longer. All products should be sent back to the place of purchase if it is within 30 days of purchase, after 30 days, customers need to initiate RMA procedure with SilverStone Technology in USA by first downloading the "USA RMA form for end-users" form from the below link and follow its instructions.
<http://silverstonetek.com/contactus.php>

For Australia only (support@silverstonetek.com)
Our goods come with guarantees that cannot be excluded under the Australian Consumer Law.
You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage.
You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.
Please refer to above "Warranty terms & conditions" for further warranty details.

SilverStone Technology Co., Ltd. 12F No. 168 Jiankang Rd., Zhonghe Dist., New Taipei City 235 Taiwan R.O.C.
+ 886-2-8228-1238 (standard international call charges apply)

For Europe (support.eu@silverstonetek.de)
For all other regions (support@silverstonetek.com)

计算机机壳		有毒有害物质/元素及其化学含量表				
部件名称	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
印刷电路板组件	-	○	○	○	○	○
线缆/ 连接器	○	○	○	○	○	○
金属结构件	○	○	○	○	○	○
塑料结构件	○	○	○	○	○	○
风扇	-	○	○	○	○	○
其它	○	○	○	○	○	○
包装材料	○	○	○	○	○	○
辅助材	○	○	○	○	○	○

本表格依据 SJ/T 11364 的规定编制。
○ : 表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。
— : 表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 规定的限量要求。且該限用物質為排除項目

产品合格证

检验员: 检01
生产日期: 见产品条码

Please refer to SilverStone website for latest specifications updates.

SilverStone Technology Co., Ltd.
www.silverstonetek.com
support@silverstonetek.com
NO:G11222431

PRECISION SERIES PS11

A VERSATILE ATX TOWER CASE FOR PERFORMANCE OR SILENCE

Special Features

Quick access filters for easy cleaning
Motherboard back plate opening for quick CPU cooler assembly
Mesh front panel intake maximizes airflow with side window for viewing system innards (PS11-W)
Front-side intake vents with foam padded side panels to minimize noise (PS11-Q)
All black painted interior for stylish look
Support graphics cards up to 16.2 inches

Specifications

Model No.	SST-PS11B-W / SST-PS11B-Q	
Material	Mesh front panel, steel body (SST-PS11B-W) / Plastic front panel, steel body (SST-PS11B-Q)	
Motherboard	ATX , Micro ATX	
Drive Bay	External	5.25" x 3 , 2.5" x 2
	Internal	3.5" x 3 , 2.5" x 2
Cooling System	Front	2 x 120mm/140mm fan slot, included 1x 120mm 1200rpm fan
	Rear	1 x 120mm fan slot
	Top	2 x 120mm fan slot (PS11-W)
	Bottom	1 x 120mm fan slot
Expansion Slot	7	
Front I/O Port	USB 3.0 x 2 / Audio x 1 / MIC x 1	
Power Supply	Optional Standard PS2 (ATX)	
Expansion Card	Compatible with expansion cards up to 16.2" , width restriction - 6.1"	
Limitation of CPU cooler	161mm	
Limitation of PSU	225mm	
Dimension	215.3mm (W) x 426.5mm (H) x 481.5mm (D), 44L	

PICTURE	ITEM	PURPOSE
	SCREW-P/W-M3*4-BK	SECURE 2.5" HDD, 5.25"DRIVE
	SCREW-I-6-32*5-BK	SECURE PSU, MB, 3.5"HDD
	STANDOFF-6-32*6.5H-6-32	SUPPORT MB
	STANDOFF-SOCKET-WRENCH	STANDOFF SCREWS
	BUNCH-WIRE-TIES	CABLE MANAGEMENT

5.25" Device Installation

ENGLISH
Remove front panel as indicated in the diagram

DEUTSCH
Frontblende wie abgebildet entfernen

FRANÇAIS
Retirez le panneau frontal comme indiqué dans le diagramme

ESPAÑOL
Retire el panel frontal como se indica en el diagrama

ITALIANO
Rimuovere il pannello frontale come indicato nella figura


РУССКИЙ
Снимителицевую панель, как показано на рисунке

繁體中文
請依圖示由面板正面取下擋版

日本語
図示されるようにフロントパネルを取り外します

한국어
그림과 같이 전면 패널을 분리합니다

简体中文
请依图示由面板正面取下挡版



ENGLISH
① Slide 5.25" device from the outside into the bay until it locks into place
② Secure with screws from both side

DEUTSCH
① 5.25-Zoll-Gerät von außen in den Schacht schieben, bis es einrastet
② Mit Schrauben von beiden Seiten sichern

FRANÇAIS
① Insérez le périphérique 5,25" de l'extérieur dans la baie jusqu'à ce qu'il s'enclenche
② Fixez avec des vis de chaque côté

ESPAÑOL
① Deslice el dispositivo de 5,25" desde el exterior hacia la bahía hasta que encaje en su sitio
② Asegure con tornillos desde ambos lados

ITALIANO
① Far scorrere il dispositivo da 5.25" dall'esterno verso l'interno dell'alloggio finché si blocca in posizione
② Fissare con viti su entrambi i lati


РУССКИЙ
① Установите 5,25-дюймовое устройство в отсек до его фиксации.
② Закрепите винтами с обеих сторон.

繁體中文
①直接將5.25"裝置推入到定位後會自動鎖上，
②於兩側鎖上螺絲固定

日本語
①5.25"デバイスを外側からスライドさせて固定されるまでペイに入れます
②ネジで両側を固定します。

한국어
①5.25" 장치를 제자리에 고정될 때까지 바깥쪽에서 베이로 밀어 넣습니다.
②양쪽 나사로 고정합니다.

简体中文
①直接將5.25"裝置推入到定位后会自動鎖上，
②于兩側鎖上螺絲固定



ENGLISH
To remove device, push the tool-less tab forward and pull device out

DEUTSCH
Zum Entfernen des Geräts die Nase nach vorne drücken (kein Werkzeug erforderlich) und das Gerät herausziehen

FRANÇAIS
Pour retirer le périphérique, poussez l'onglet d'ouverture sans outil vers l'avant et tirez pour le faire sortir

ESPAÑOL
Para retirar el dispositivo, empuje hacia delante la pestaña sin herramientas y tire del dispositivo

ITALIANO
Per rimuovere il dispositivo, spingere in avanti la linguetta ed estrarre il dispositivo


РУССКИЙ
Для извлечения устройства нажмите на фиксатор и вытащите устройство.

繁體中文
要移除的話將免工具扣具扭頭往前推後將裝置抽出

日本語
装置を取り外すには、ツール不要タブを前に押して、デバイスを引き出します。

한국어
장치를 분리하려면, 공구 사용이 필요 없는 끝부분을 앞쪽으로 민 후 장치를 당겨 뺍니다.

简体中文
要移除的话將免工具扣具扭头往前推后将裝置抽出



ENGLISH
① To remove drive, first pull tool-less tab outward
② Then pull drive out.

DEUTSCH
① Zum Entfernen des Laufwerks zunächst die Nase nach außen ziehen (kein Werkzeug erforderlich)
② Dann das Laufwerk herausziehen.

FRANÇAIS
① Pour retirer le disque, tirez en premier l'onglet d'ouverture sans outil vers l'extérieur
② Puis retirez le disque.

ESPAÑOL
① Para retirar el dispositivo, primero tire de la pestaña sin herramientas hacia fuera
② Luego tire del dispositivo hacia fuera.

ITALIANO
① Per rimuovere l'unità, prima tirare verso l'esterno la linguetta
② Quindi estrarre l'unità.


РУССКИЙ
① Для извлечения диска потяните фиксатор наружу.
② Затем извлеките привод диска.

繁體中文
①移除時先將扣具扳開
②將硬碟向外抽出

日本語
①ドライブを取り出すには、ツール不要ブラケットのタブを外側へ引きます
②それから、ドライブを引き出します。

한국어
①드라이브를 트레이에 놓고 나서 고정합니다.
②설치를 하려면 위의 단계를 역으로 따라하면 됩니다.

简体中文
①移除时先将扣具扳开
②将硬盘向外抽出



2.5" HDD/SSD Installation

ENGLISH
① Remove thumbscrew
② Remove 2.5" tray by lifting it

DEUTSCH
① Rändelschraube entfernen
② 2,5-Zoll-Fach durch Anheben entfernen

FRANÇAIS
① Enlevez les vis à oreilles.
② Enlevez le plateau 2,5" en le soulevant.

ESPAÑOL
① Quite el tornillo mariposa
② Retire la bandeja de 2,5" levantándola

ITALIANO
① Rimuovere la vite a testa zigrinata
② Rimuovere il cassetto 2.5" sollevandolo


РУССКИЙ
① Отверните барашковый винт.
② Приподнимите и извлеките 2,5-дюймовый отсек.

繁體中文
①將手扭螺絲取下
②向上提取即可取出2.5" 硬碟架

日本語
①つまみネジを取り外します。
②2.5"トレイは上方に取り外します。

한국어
①나비 나사를 제거합니다.
②2.5" 트레이를 들어올려 분리합니다.

简体中文
①將手扭螺絲取下
②向上提取即可取出2.5" 硬盘架



3.5" Hard Drive Installation

ENGLISH
① Pull the tab of tool-less bracket outward
② Slide drive in with SATA interface facing inwards until it locks into place

DEUTSCH
① Nase der Halterung nach außen ziehen (kein Werkzeug erforderlich)
② Laufwerk mit der SATA-Schnittstelle nach innen zeigend bis zum Einrasten hineinschieben

FRANÇAIS
① Tirez l'onglet du support sans outil vers l'extérieur
② Insérez le disque avec l'interface SATA tournée vers l'intérieur jusqu'à ce qu'il s'enclenche

ESPAÑOL
① Tire de la pestaña del bracket sin herramientas hacia fuera
② Deslice el dispositivo en el interfaz SATA mirando hacia el interior hasta que encaje en su sitio

ITALIANO
① Tirare verso l'esterno la linguetta della staffa ad incastro
② Far scorrere l'unità con l'interfaccia SATA rivolta verso l'interno finché non si blocca in posizione


РУССКИЙ
① Потяните фиксатор кронштейна наружу.
② Установите привод диска таким образом, чтобы разъем SATA был направлен внутрь, и нажмите до фиксации привода.

繁體中文
①將免工具支架往外扳開後，
②SATA端朝內放入硬碟，推到底即可被免扣具裝置固定

日本語
①ツール不要ブラケットのタブを外側へ引きます。
②ドライブはSATAインターフェースを内側に向けて、きちんと固定されるまで中に入れます。

한국어
①공구 사용이 필요 없는 브래킷의 끝부분을 바깥쪽으로 당겨 뺍니다.
②SATA 인터페이스를 안쪽으로 향하게 한 채로 드라이브가 제자리에 고정될 때까지 안으로 밀어 넣습니다.

简体中文
①將免工具支架往外扳开后，
②SATA端朝內放入硬盘，推到底即可被免扣具裝置固定



ENGLISH
① Place drive into tray and secure with screws
② Follow above steps in reverse to complete installation

DEUTSCH
① Laufwerk in das Fach einsetzen und mit Schrauben sichern
② Obige Schritte zum Abschießen der Installation in umgekehrter Reihenfolge befolgen

FRANÇAIS
① Mettez le disque dans le support et attachez-le avec des vis
② Suivez les étapes ci-dessus dans l'ordre inverse pour terminer l'installation

ESPAÑOL
① Sitúe el dispositivo en la bandeja y fjelo con tornillos
② Sigla los pasos anteriores en orden inverso para completar la instalación

ITALIANO
① Collocare l'unità nel cassetto e fissarla con le viti
② Attenersi alle istruzioni di cui sopra in ordine inverso per completare l'installazione

РУССКИЙ
① Установите привод в отсек и закрепите винтами.
② Для завершения установки выполните описанные выше операции в обратном порядке.

繁體中文
①將硬碟放入托盤後用螺絲鎖固
②依照反順序裝回托盤即可

日本語
①ドライブをトレイに入れて、ネジで固定します。
②インストールを完了するには、上記のステップを逆順に実行します。

한국어
①드라이브를 트레이에 넣고 나서 고정합니다.
②설치를 하려면 위의 단계를 역으로 따라하면 됩니다.

简体中文
①將硬盘放入托盘后用螺丝锁固
②依照反顺序装回托盘即可

