


Covers for switches/push-buttons
Symbol for push-switch
without symbol



For rocker 2520-...

Order Code : 2CKA001433A0036

Article No. : 2525 KI-214

EAN: 4011395047903