

Covers for switches/push-buttons
Cover plate
with rotary control, with marking



As cover for flush mounted three-step rotary switch.
Without zero position.
For insert 2710/1 U.

Order Code : 2CKA001710A3419
Article No. : 2542 DR/02-212
EAN: 4011395008911