



RAZER PRIO

MASTER GUIDE

CONTENTS

1. WHAT'S INSIDE 2

2. WHAT'S NEEDED 4

3. LET'S GET YOU COVERED 4


4. GETTING STARTED 5

5. SAFETY AND MAINTENANCE 7

6. LEGALESE..... 8

1. WHAT'S INSIDE

- Razer Prio



- A. D-pad
- B. Options button
- C. Clickable capacitive thumbsticks
- D. Home button
- E. Elastic bridge
- F. USB Type C connector
- G. Menu button
- H. Silent tactile face buttons
- I. Razer Cortex Mobile button
- J. Triggers (L2/R2)
- K. Bumpers (L1 / R1)

- Interchangeable rubber cushions*

For iPhone



For iPhone Pro Max



For iPhone Air



- Important Product Information Guide

**Rubber cushions A are pre-installed with the controller.*


2. WHAT'S NEEDED

PRODUCT REQUIREMENTS

- Mobile device with a USB Type-C port
- iOS 18 / Android™ 14 or higher
- Internet connection for app installation

i Full compatibility list available here: rzt.to/prio

3. LET'S GET YOU COVERED



*Your product's serial number
can be found here.*




You've got a great device — now make it even better. Register your device at razerid.razer.com to get covered and unlock exclusive Razer benefits.

i *A valid Proof of Purchase is required for any Limited Warranty Claim.*


4. GETTING STARTED

SET UP FOR MOBILE


1.



2.




3.



INSTALL THE RAZER CORTEX MOBILE GAME LAUNCHER (FOR MOBILE DEVICES)

Launch compatible games, remap controller buttons, enable or disable haptic feedback, take screenshots, record or share gameplay, and much more.



(for China only)



RZR.TO/CORTEX MOBILE



Razer Cortex Mobile
Game Launcher

SHORTCUT COMMANDS

Input	Function
 + X Hold Press	Use XInput Mode
 + A Hold Press	Use HID Mode

i *The Razer Cortex Mobile Game Launcher app can automatically switch the controller between HID and XInput modes when launching vibration-compatible games.*

Find out more about your mobile gaming controller at support.razer.com

5. SAFETY AND MAINTENANCE

SAFETY GUIDELINES

To achieve maximum safety while using your Razer Prio, we suggest that you adopt the following guidelines:

Should you have trouble operating the device properly and troubleshooting does not work, make sure to unplug the device (if applicable) and contact the Razer hotline or go to support.razer.com for support.

Don't take apart the device, and don't attempt to operate it under abnormal current loads. Doing so will void your warranty.

Keep the controller's accessories out of the reach of small children to avoid accidents and/or injuries.

Keep the device away from liquid, humidity, or moisture. Operate the device only within the specific temperature range of 0°C (32°F) to 40°C (104°F). Should the temperature exceed this range, detach the device to let its temperature stabilize to an optimal level.

MAINTENANCE AND USE

The Razer Prio requires minimum maintenance to keep it in optimum condition. Once a month, we recommend you clean the device using a soft cloth or cotton swab to prevent dirt buildup.

6. LEGALESE

COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION

©2026 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, "For Gamers. By Gamers.", and "Razer Chroma" logo are trademarks or registered trademarks of Razer Inc. and/or affiliated companies in the United States or other countries. All other trademarks are the property of their respective owners.

Android, Google, Google Logo, Google Play, and the Google Play logo are trademarks of Google LLC.

Use of the Made for Apple badge means that an accessory has been designed to connect specifically to the Apple product(s) identified in the badge and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with an Apple product may affect wireless performance.

Apple, the Apple logo, iPad mini, iPhone, Made for iPad logo, and Made for iPhone logo are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

Razer Inc. ("Razer") may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such copyright, trademark, patent or other intellectual property right. The Razer Prio (the "Product") may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

LIMITED PRODUCT WARRANTY

For the latest and current terms of the Limited Product Warranty, please visit [razer.com/warranty](https://www.razer.com/warranty).

LIMITATION OF LIABILITY

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer's liability exceed the retail purchase price of the Product.

GENERAL

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.