



Make It Yours.

COSMOS C700M

User manual / English

التثبيت دليل / Arabic

Инструкция за експлоатация / Български

安装说明 / 简体中文

安裝說明 / 繁體中文

Uživatelská příručka / Čeština

Handuch / Deutsch

Εγχειρίδιο χρήσης / Ελληνικά

Manual de Usuario / Español

Manuel de l'utilisateur / Français

فارسی / راهنمای کاربری

Felhasználói kézikönyv / Magyar

Manuale d'uso / Italiano

ユーザーズマニュアル / 日本語

Handleiding / Nederlands

설치 안내 / Korean

Instrukcja Użytkownika / Polski

Manual do Usuário / Português

Руководство пользователя / русский

Uputstvo za korišćenje / Srpski

Kullanım Kılavuzu / Türkçe

Panduan Pengguna / Indonesia

CONTENTS


Package Content	2
Front I/O & Buttons	3
Compatibility	3
Installation Guide	
1 How to remove side panels	4
2 How to install power supply	4
3 How to install motherboard	6
4 How to remove/install GFX bracket & SSD bracket	7
5 How to install add-on cards	8
6 How to install 5.25" devices	10
7 How to install 3.5" devices	13
8 How to install 2.5" devices	15
9 How to install case fans and radiators	17
10 How to install 420mm radiator	18
11 How to install radiator in the rear	21
12 Cable Management	21
13 Completing installation	22
Fan & A-RGB controller operation	23
Control Board Layout	24
I/O connectors	24
Inverse layout adjustment	25
Chimney effect layout adjustment	31

Net Weight		23.4kg / 51.6lb
Available Color		Grey, Silver & Black
Materials		Outlook: Aluminum, Plastic, Steel
		Body: Steel
		Side panel: Tempered Glass, Steel
Dimensions (LxWxH)		650 x 306 x 651mm / 25.6 x 12.0 x 25.6inch
Motherboard Support		Mini-ITX, Micro-ATX, ATX, E-ATX (support upto 12" x 10.7")
Expansion Slots		8
Drive Bays	5.25"	1
	2.5"/3.5"	4 + 1 (in the accessory box)
	2.5" SSD	4
I/O Port		USB 3.1 Type-C x 1 USB 3.0 Type-A x 4 3.5mm Headset Jack (Audio+Mic) x 1 3.5mm Mic Jack x 1 Fan Speed & A-RGB Control Buttons
Pre-installed Fan(s)	Front	140mm PWM Fan x 3 (Speed: 1200RPM / Connector: 4Pin PWM)
	Rear	140mm PWM Fan x 1 (Speed: 1200RPM / Connector: 4Pin PWM)
Fan Support	Top	120/140mm fan x 3
	Front	120/140mm fan x 3
	Rear	120/140mm fan x 1
	Bottom	120/140mm fan x 2
Liquid Cooling Support	Top	120mm, 140mm, 240mm, 280mm, 360mm, 420mm (remove ODD, maximum thickness clearance 70mm)
	Front	120mm, 140mm, 240mm, 280mm, 360mm, 420mm (remove ODD)
	Rear	120mm, 140mm
	Bottom	120mm, 140mm, 240mm
Clearances	CPU Cooler	198mm
	GPU	490mm (without 3.5" HDD Bracket) 320mm (with 3.5" HDD Bracket)
Power Supply Support		Bottom Mount, ATX PS2


Package Content / Lieferumfang / Contenido de la confección / Contenu de l'emballage / Contenuto della confezione / Zawartość opakowania / Содержание комплекта / Съдържание / balení obsahuje / Περιεχόμενα συσκευασίας / A csomag tartalma / Verpakkingsinhoud / Conteúdo da embalagem / Sadržajpakovanja / Paket içeriği / 包装内含物品明細 / 包装内含物品清單 / パッケージ内容 / Isi Paket / 구성품 내용 / فهرست محتويات / محتوی الطرد

	Figure	Name	Q'ty	Used for
1		2-Bay ODD or Function Panel bracket	2	2-Bay 5.25" optical drive or function Panel
2		#6-32*6mm screw	17	2-Bay 5.25" optical drive or function panel bracket, PSU, motherboard
3		M3*5mm screw	8	5.25" optical drive
4		HDD screw	20	HDD cage
5		SSD screw	12	Mounting SSD on M.port cover
6		Stand-off	3	Motherboard tray
7		Stand-off socket	1	Motherboard stand-off installation
8		Cable Tie	10	Cable management
9		φ5*10mm screw	8	Installing fans
10		Cleaning Cloth	1	Cleaning glass
11		M3*4mm screw	20	SSD / mounting in SSD pockets
12		#6-32*6mm screw	2	Tap thread on frame holes
13		HDD SSD combo bracket	1	Install 3.5" devices
14		A-RGB splitter + Sata connector	1	Adding more A-RGB lighting Requires additional power source from SATA
15		Riser Cable	1	Connecting graphics card when using the rotateable graphics card holder


EN	Front I/O & Buttons	HU	Előlap I/O & kapcsolók
AR	المنافذ الأمامية والأزرار	ID	Tombol dan I/O depan
BG	Преден панел и бутони	IT	Pulsanti e I/O frontali
CHS	前面板接口及按键说明	JP	フロントI/Oパネル
CHT	前面板接口及按鍵說明	KR	전면 I/O & 버튼
CS	Vstupy/Výstupy a další tlačítka na předním panelu	NL	Bedieningspaneel
DE	Front I/O & Tasten	PL	Przedni panel I/O & Przyciski
EL	Εμπρός I/O & διακόπτες	PT	Botões e frontal I/O
ES	Frontal I/O & Botones	RU	Фронтальные кнопки и панель ввода/вывода
FA	دکمه‌ها و درگاه‌های پنل جلو	SR	Front I/O & Tasteri
FR	Boutons sur le panneau E/S de façade	TR	Ön I/O & Düğmeler



EN	Compatibility	HU	kompatibilitás
AR	التوافق	ID	Kompatibilitas
BG	съвместимост	IT	Compatibilità
CHS	相容性	JP	パーツ互換性
CHT	兼容性	KR	호환성
CS	kompatibilita	NL	Compatibiliteit
DE	Kompatibilität	PL	Zgodność
EL	Συμβατότητα	PT	Compatibilidade
ES	Compatibilidad	RU	Совместимость
FA	سازگاری	SR	kompatibilnost
FR	Compatibilité	TR	Uyumluluk



Maximum height for CPU cooler





Maximum length for Graphics card

Installation Guide / Installationsanleitung / Guía para la instalación / Guide d'installation / Guida per l'installazione / Instrukcja instalacji / Руководство пользователя / Ръководство за инсталация / Instalační příručka / Οδηγός εγκατάστασης / Telepítési útmutató / / Guia de instalação / Uputstvo za instalaciju / Kurulum Kılavuzu / 組裝說明 / 組裝說明 / 製品の使い方 / Panduan Instalasi / 설치 안내 / راهنمای نصب / دليل التثبيت

1


- | | | | |
|-------|-------------------------------------|------|-------------------------------------|
| [EN] | How to remove side panels | [HU] | Oldalsó panel eltávolítása |
| [AR] | كيفية إزالة اللوح الجانبي | [ID] | Cara melepaskan panel samping |
| [BG] | Как се отстранява страничният панел | [IT] | Come rimuovere il pannello laterale |
| [CHS] | 移除側板 | [JP] | サイドパネルの取り外し方法 |
| [CHT] | 移除側板 | [KR] | 사이드 패널 제거 방법 |
| [CS] | Jak odstranit boční kryt | [NL] | Verwijderen van het zijpaneel |
| [DE] | So entfernen Sie das Seitenpanel | [PL] | Jak zdjąć pokrywę boczną |
| [EL] | Πως να αφαιρέσετε το πλαϊνό κάλυμα | [PT] | Como remover o painel lateral |
| [ES] | Como extraer el panel lateral | [RU] | Как снять боковую панель |
| [FA] | نحوه باز کردن پل کناری | [SR] | Kako da uklonite bočnu stranicu |
| [FR] | Comment retirer le panneau latéral | [TR] | Yan paneli kaldırma |








2

- | | | | |
|-------|---|------|--------------------------------------|
| [EN] | How to install power supply | [HU] | Tápegység beszerelése |
| [AR] | كيفية تثبيت موثر الطاقة | [ID] | Cara memasang power supply |
| [BG] | Как се поставя захранващият блок | [IT] | Come installare l'alimentatore |
| [CHS] | 安裝電源 | [JP] | 電源ユニットの取り付け方法 |
| [CHT] | 安裝電源 | [KR] | 파워 서플라이 설치 방법 |
| [CS] | Jak zapojit zdroj | [NL] | Installeren van de voeding |
| [DE] | So installieren Sie das Netzteil | [PL] | Jak podłączyć zasilanie |
| [EL] | Πως να εγκαταστήσετε το τροφοδοτικό | [PT] | Como instalar a fonte de alimentação |
| [ES] | Como instalar la fuente de alimentación | [RU] | Как установить блок питания |
| [FA] | نحوه نصب منبع تغذیه | [SR] | Kako da instalirate napajanje |
| [FR] | Comment installer l'alimentation | [TR] | Güç kaynağını kurma |


A Install regular PSU



B Install longer PSU



B6



3

[EN] How to install motherboard

[AR] كيفية تثبيت اللوحة الأم

[BG] Как се инсталира дънната платка

[CHS] 安裝主板

[CHT] 安裝主機板

[CS] Jak nainstalovat motherboard

[DE] So installieren Sie das Motherboard

[EL] Πως να εγκαταστήσετε τη μητρική κάρτα

[ES] Como instalar la placa base

[FA] نحوه نصب مادربرد

[FR] Comment installer la carte mère

[HU] Alaplap beszerelése

[ID] Cara memasang motherboard

[IT] Come installare la motherboard

[JP] マザーボードの取り付け方法

[KR] 마더보드 설치 방법

[NL] Installeren van het moederbord

[PL] Jak zamontować płytę główną


[PT] Como instalar a placa-mãe

[RU] Как установить материнскую плату


[SR] Kako da instalirate matičnu ploču




[TR] Anakartı kurma

A Internal installation (for ATX)



B External installation (for ATX)








For other motherboard sizes please refer to motherboard manual. You may need to remove 1 or more the pre-installed stand-offs for proper installation.

4

- | | |
|--|--|
| [EN] How to remove/install GFX bracket & SSD bracket | [HU] Hogyan telepítsük/távolítsuk el a GFX és SSD keretet |
| [AR] قرص و الرسوميات بطاقة حامل فك و تركيب طريقة | [ID] Cara Instalasi / Melepas Braket GFX & Braket SSD |
| [BG] Как се монтира/премахва скобите за графична карта и SSD. | [IT] Come installare / rimuovere la staffa GFX e la staffa SSD |
| [CHS] 安裝/拆卸显卡支架和SSD支架 | [JP] グラフィックスカードブラケットおよびSSDブラケットの取付け/取外しの仕方 |
| [CHT] 安裝/拆卸顯示卡支架和SSD支架 | [KR] GFX 브라켓 및 SSD 브라켓 설치 / 제거 방법 |
| [CS] Jak nainstalovat / odebrat držák GFX a držák SSD | [NL] Installeren/verwijderen van videokaart bracket & SSD bracket |
| [DE] Ein-/Ausbau von Grafikkarten-Halterung und SSD-Halterung | [PL] Jak zamontować/usunąć ramkę GFX i SSD |
| [EL] Πώς να εγκαταστήσετε / αφαιρέσετε το GFX bracket & SSD bracket | [PT] Como instalar/remover os brackets GFX e SSD |
| [ES] Cómo instalar / extraer el soporte GFX y el soporte SSD | [RU] Как установить/удалить кронштейн GFX и кронштейн SSD. |
| [FA] SSD و گرافیک کارت برکت یساز جدا و نصب یچگونگ | [SR] Kako instalirati/ukloniti GFX nosač & SSD nosač |
| [FR] Comment installer / retirer le support pour carte graphique et le support pour SSD | [TR] GFX ve SSD Desteği Nasıl Takılır/Çıkartılır |



5

- [EN]** How to install add-on cards
[AR] كيفية تثبيت بطاقات مضافة
[BG] Как се инсталират допълнителните платини
[CHS] 安裝显卡
[CHT] 安裝顯示卡
[CS] Jak nainstalovat přídatné karty
[DE] So installieren Sie Erweiterungskarten
[EL] Πως να εγκαταστήσετε πρόσθετες κάρτες
[ES] Como instalar tarjetas adicionales
[FA] نحوه نصب کارت‌ها
[FR] Comment installer les cartes supplémentaires


- [HU]** Add-on kártyák beszerelése
[ID] Cara memasang perangkat kartu tambahan
[IT] Come installare le schede aggiuntive
[JP] 拡張カードの取り付け方法
[KR] 애드 온 카드 설치 방법
[NL] Installeren van de extra kaarten
[PL] Jak podłączyć karty rozszerzeń
[PT] Como instalar as placas adicionais
[RU] Как установить карты расширения
[SR] Kako da instalirate dodatne kartice
[TR] Eklenti kartlarını kurma

A Regular position


B Install on midplate

C Install on M.Port


A1




A2




B1




B2







B3



B4











6

- EN** How to install 5.25" devices
- AR** كيفية تثبيت الأجهزة مقاس 5.25"
- BG** Как се инсталират 5,25" устройствата
- CHS** 安裝5.25"裝置
- CHT** 安裝5.25"裝置
- CS** Jak nainstalovat zařízení 5.25"
- DE** So installieren Sie 5.25" Zoll Geräte
- EL** Πως να εγκαταστήσετε τις συσκευές 5,25"
- ES** Como instalar los dispositivos de 5,25"
- FA** نحوه نصب درایوهای 5.25 اینچ
- FR** Comment installer les périphériques 5,25 pouces


A Install 1x 5.25" optical drive

- HU** 5,25" eszközök beszerelése
- ID** Cara memasang perangkat 5.25
- IT** Come installare le unità da 5.25"
- JP** 5.25"インチデバイス (光学ドライブなど) の取り付け方法
- KR** 5.25인치 장치 설치 방법
- NL** Installeren van de 5.25" apparaten
- PL** Jak zamontować urządzenia 5.25"
- PT** Como instalar os dispositivos de 5,25"
- RU** Как установить 5,25" устройства
- SR** Kako da instalirate 5,25" uređaje
- TR** 5,25" aygıtın kurma


B Install 2x 5.25" optical drive




B1




B2




B3




B4





B5



B6















7

- [EN] How to install 3.5" devices
- [AR] كيفية تثبيت القرص الصلب مقاس 3.5" بوصة
- [BG] Как се инсталират 3.5" устройствата
- [CHS] 安裝3.5"裝置
- [CHT] 安裝3.5"裝置
- [CS] Jak nainstalovat zařizení 3.5"
- [DE] So installieren Sie 3,5 Zoll Geräte
- [EL] Πως να εγκαταστήσετε τις συσκευές 3.5"
- [ES] Como instalar los dispositivos de 3.5"
- [FA] نحوه نصب درایوهای 3.5 اینچ
- [FR] Comment installer les périphériques 3.5 pouces

- [HU] 3.5" eszközök beszerelése
- [ID] Cara memasang perangkat 3.5
- [IT] Come installare le unità da 3.5"
- [JP] 3.5インチデバイス（HDDなど）の取り付け方法
- [KR] 3.5인치 하드 디스크 드라이브 설치 방법
- [NL] Installeren van de 3.5" apparaten
- [PL] Jak zamontować urządzenia 3.5 "
- [PT] Como instalar os dispositivos de 3,5"
- [RU] Как установить 3,5" устройства
- [SR] Kako da instalirate 3,5" uređaje
- [TR] 3,5" aygıtları kurma








8


- EN** How to install 2.5" devices
- AR** كيفية تثبيت القرص الصلب مقاس 2.5 بوصة
- BG** Как се инсталират 2.5" устройствата
- CHS** 安裝2.5"裝置
- CHT** 安裝2.5"裝置
- CS** Jak nainstalovat zařízení 2.5"
- DE** So installieren Sie 2,5 Zoll Geräte
- EL** Πως να εγκαταστήσετε τις συσκευές 2.5"
- ES** Como instalar los dispositivos de 2.5"
- FA** نحوه نصب درایوهای 2.5 اینچ
- FR** Comment installer les périphériques 2.5 pouces


- HU** 2.5" eszközök beszerelése
- ID** Cara memasang perangkat 2.5"
- IT** Come installare le unità da 2.5"
- JP** 2.5インチデバイス (SSDなど) の取り付け方法
- KR** 2.5인치 하드 디스크 드라이브 설치 방법
- NL** Installeren van de 2.5" apparaten
- PL** Jak zamontować urządzenia 2.5"
- PT** Como instalar os dispositivos de 2,5"
- RU** Как установить 2,5" устройства
- SR** Kako da instalirate 2,5" uređaje
- TR** 2,5" aygıtları kurma

A Installation behind motherboard tray








B Installation on M.Port





OR



9





- [EN] How to install case fans and radiators
 [AR] كيفية تركيب المراوح و المبرد
 [BG] Как се инсталират радиатори и вентилатори
 [CHS] 安装风扇和水冷排
 [CHT] 安裝風扇和水冷排
 [CS] Jak nainstalovat ventilátory a chladiče
 [DE] So installieren Sie Lüfter und Radiatoren
 [EL] Πώς να εγκαταστήσετε ανεμιστήρες και ψυγεία
 [ES] Como instalar ventiladores de caja y radiadores
 [FA] نحوه نصب رادیاتورها و فن‌های کیس
 [FR] Comment installer les ventilateurs et radiateurs



- [HU] Ventilátorok és a radiátorok beszerelése
 [ID] Cara memasang kipas kasus dan radiator
 [IT] Come Installare ventole e radiatori
 [JP] ケースファンとラジエーターの取り付け方法
 [KR] 케이스 팬 및 라디에이터 설치 방법
 [NL] Installeren van de ventilatoren en radiatoren
 [PL] Jak zamontować wentylatory i radiatory
 [PT] Como instalar as ventoinhas e os radiadores
 [RU] Как установить корпусные вентиляторы и радиаторы
 [SR] Kako da instalirate ventilatore i radijatore
 [TR] Kasa fanlarını ve radyatörleri takmak

A Install on top

B Install in front

C Install in bottom










10


- EN** How to install 420mm radiator
- AR** كيفية تركيب المبرد 420mm
- BG** Как да инсталирате 420 мм радиатор
- CHS** 安装420mm水冷排
- CHT** 安裝420mm水冷排
- CS** Jak nainstalovat chladič o průměru 420 mm
- DE** So installieren Sie 420mm Radiator
- EL** Πώς να εγκαταστήσετε ψυγείο 420mm
- ES** Cómo instalar un radiador de 420mm
- FA** نحوه نصب رادیاتور 420 میلیمتری
- FR** Comment installer un radiateur de 420 mm

- HU** 420mm radiátor felszerelése
- ID** Cara memasang radiator 420mm
- IT** Come installare radiatore da 420mm
- JP** 420mmラジエーターの取り付け方法
- KR** 420mm 라디에이터 설치 방법
- NL** Installeren van de 420mm radiator
- PL** Jak zainstalować chłodnicę 420 mm
- PT** Como instalar o radiador de 420mm
- RU** Как установить радиатор 420 мм
- SR** Kako da instalirate 420mm radiator
- TR** 420mm Radyatörü takmak






Fan



Radiator





	Position	Support
Fan	Top	120/140mm x 3
	Front	120/140mm x 3
	Bottom*	120/140mm x 2
Radiator	Top	120mm, 140mm, 240mm, 280mm, 360mm/420mm (requires removal of 5.25" Optical drive Cage)
	Front	120mm, 140mm, 240mm, 280mm, 360mm, 420mm (requires removal of 5.25" Optical drive Cage)
	Bottom*	120mm, 140mm, 240mm, 360mm (requires alternative PSU location)

For all 3positions it requires the purchase of an additional cooling bracket.

11

- [EN] How to install radiator in the rear
- [AR] كيفية تركيب المبرد في الخلف
- [BG] Как се инсталира радиатор в задния панел
- [CHS] 安装后方的水冷排
- [CHT] 安裝後方的水冷排
- [CS] Jak nainstalovat chladič vzadu
- [DE] So installieren Sie einen Radiator am Heck
- [EL] Πώς να εγκαταστήσετε ψυγείο στο πίσω μέρος
- [ES] Como instalar el radiador en a parte posterior
- [FA] نحوه نصب رادیاتور در قسمت پشتی
- [FR] Comment installer le radiateur à l'arrière
- [HU] Radiátor beszerelése hátulra





- [ID] Cara memasang radiator bagian belakang
- [IT] Come installare un radiatore nella sezione posteriore
- [JP] 後部にラジエーター 取り付け方法
- [KR] 뒤쪽에 라디에이터를 설치하는 방법
- [NL] Installeren van de radiator aan de achterkant
- [PL] Jak zamontować radiator na tylniej ścianie
- [PT] Como instalar o radiador na traseira
- [RU] Как установить радиатор в задней части корпуса
- [SR] Kako instalirati radiator u zadnjem delu
- [TR] Radyatörü arkaya takmak



12

- [EN] Cable management
- [AR] تنظيم الأسلاك
- [BG] Кабел мениджмънт
- [CHS] 线缆整理
- [CHT] 線纜整理
- [CS] Cable management
- [DE] Kabel-management
- [EL] Διαχείριση καλωδίων
- [ES] Gestión de cable
- [FA] مدیریت کابل
- [FR] Gestion des câbles

- [HU] Kábel menedzsment
- [ID] Manajemen Kabel
- [IT] Cable Management
- [JP] 配線収納
- [KR] 케이블 관리
- [NL] Kabel management
- [PL] Zarządzanie kablami
- [PT] Gestão de cabos
- [RU] Кабель менеджмент
- [SR] Pozicioniranje kablova
- [TR] Kablo Yönetimi



13

[EN] Completing installation

[AR] استكمال التثبيت

[BG] Завършване на инсталацията

[CHS] 完成组裝

[CHT] 完成組裝

[CS] Dokončení instalace

[DE] So schliessen Sie die Installation ab

[EL] Ολοκλήρωση εγκατάστασης

[ES] Completar la instalación

[FA] تکمیل نصب

[FR] Terminer l'installation

[HU] A szerelés befejezése

[ID] Menyelesaikan Instalasi

[IT] Completamento dell'installazione

[JP] 完成図

[KR] 설치 완료

[NL] Installatie voltooid



[PL] Kończenie instalacji

[PT] Finalizar a instalação


[RU] Завершение сборки

[SR] Dovođavanje instalacije

[TR] Kurulum tamamlanıyor




Fan & A-RGB controller operation / Lüfter und A-RGB Steuerung / Funcionamiento del ventilador y del controlador A-RGB / Fonctionnement du contrôleur d'éclairage A-RGB et de ventilateurs / Funzionamento del controller Ventola& A-RGB / Obsługa kontrolera wentylatorów i podświetlenia A-RGB / Управление контроллера вентилятора и A-RGB / Как функционира контролер вентилатор и A-RGB / Ovládání ventilátoru a A-RGB / Χρήση ηλεκτρική fan & A-RGB / Ventilátor és A-RGB vezérlő kezelése / Ventilator & A-RGB controller bediening / Funcionamento do controlador das ventoinhas e A-RGB / Funkcija ventilatora i A-RGB kontrolera / Fan & A-RGB kontrolcü işlemleri / 風扇和A-RGB燈光控制操作 / 風扇和A-RGB燈光控制操作 / ファンとA-RGBコントローラー操作説明 / Pengontrol operasional kipas danA-RGB / 팬 및 A-RGB 컨트롤러 작동 / عملکرد کنترلر فن و A-RGB / A-RGB / A-RGB متحكم المراوح وإضاءة



	Mode	Description
(✱) Fan controller	(H) High	Fan operates at 100%
	(M) Medium	Fan operates at 75%
	(L) Low	Fan operates at 50%
	(↑↓) M/B sync	Motherboard sync (PWM input)
(✱) Addressable RGB controller	(☼) Static	7 preset colors
	(🔄) Cycle	4 preset dynamic color cycles
	(↑↓) M/B sync*	Sync up with motherboard lighting

*M/B sync mode only works when connecting control board to motherboard A-RGB header. Do NOT connect to regular RGB header!

Control Board Layout / Layout der Steuerplatine / Diseño de la tarjeta de control / Disposition de la carte de contrôle / Layout della scheda di controllo / Układ panelu sterowania / Панель управления / Карта на контролния панел / Rozložení ovládací desky / Διάταξη του control board / Kezelő lap kiosztása / Ventilator & RGB aansluit schema / Layout do kontrolador da board / Šema kontrolne ploče / Kontrol kartı şeması / 控制板接口 / 控制板接口 / コントロールボードレイアウト / Susunan Papan Kontrol / 컨트롤 보드 레이아웃 / طرح مدار کنترل / لوحة التحكم



	Connector Name	Description
A	Molex connector	4 pin power input. Use native Molex (1)
B	Front panel control connector	Connects to IO panel
C	A-RGB Lighting connector	Total 4 channels,max 2A output per channel, total 8A output for all A-RGB out put (2)
D	MB A-RGB sync connector	Connect to motherboard A-RGB sync port
E	USB connector	Connect to motherboard USB2.0 port for controller Firmware upgrade
F	MB FAN sync connector	Connect to motherboard FAN port
G	Fan Connectors	FAN1~FAN6 4pin PWM FAN connector(compatible with 3pin FAN),0.4A output channel and 2.4A total



(1) Total current may be over 6A,requires a power supply with at least 18AWG thickness wires.

(2) 3 channels for pre-installed lighting on case.






1 channel for additional A-RGB devices. Connect via splitter with SATA to supply power.







I/O connectors / I/O Anschlüsse / Conectores I/O / Connecteurs E/S / Connettori I/O / Złącza panelu I/O / Разъемы ввода/вывода / Интерфейсни конектори / Vstupy/Výstupy / Συνδέσεις I/O / I/O csatlakozók / I/O connectoren / Conectores I/O / I/O konektori / I/O bağlantıları / I/O面板接頭 / I/O面板接头 / I/Oコネクタ / Konektor I/O / I / O 커넥터 / موصلات المنافذ / I/O کنکطور های







- [EN] Please follow motherboard manual instruction for connection.
- [AR] يرجى اتباع دليل استخدام اللوحة الرئيسية لتكوين التوصيلات
- [BG] Моля следвайте инструкциите на дънната платка за инсталация
- [CHS] 请遵照主板安装手册进行连接
- [CHT] 請遵照主機板安裝手冊進行連接
- [CS] Pro připojení využijte návod dodávaný k základní desce
- [DE] Für die Anschlüsse bitte die Bedienungsanleitung des Mainboards lesen
- [EL] Ακολουθήστε τις οδηγίες την μητρικής κάρτας για την σύνδεση.
- [ES] Siga las instrucciones del manual de la placa base para la conexión.
- [FR] Veuillez vous reporter au manuel de la carte mère pour les instructions de branchement
- [HU] Kövesd az alaplap útmutatóját a helyes csatlakoztatáshoz.
- [ID] Mohon mengikuti instruksi manual motherboard untuk koneksi
- [IT] Seguire le istruzioni della scheda madre per la connessione.
- [JP] マザーボードの取り付け方法
- [KR] 연결을 위해 마더보드 매뉴얼 지시를 따르십시오.
- [NL] Volg de handleiding van het moederbord voor installatie
- [PL] Przy podłączaniu kieruj się instrukcją obsługi płyty głównej
- [PT] Por favor siga o manual da motherboard para as conexões
- [RU] Для подключения, пожалуйста, следуйте инструкциям материнской платы.
- [SR] Molimo vas da pratite uputstva matične ploče za povezivanje.
- [TR] Bağlantılar için lütfen anakart kullanma kılavuzuna bakınız







Case Connector	
USB 3.0 connector	
USB 3.1 connector	
HD Audio connector	
Power SW/ LED,HDD LED Reset SW	
Power SW Power LED + Power LED - HDD LED Reset SW	







Inverse layout adjustment / Anpassung des Layouts: Montage auf der gegenüberliegenden Seite / Ajuste de disposición inverso / Réglage de la disposition inversée / Regolazione inversa del layout / Dostosowanie odwrotnego układu / Обратная настройка схемы / Възможност за множество ориентации на дънната платка / Inverzní rozložení / Ρύθμιση αντίστροφης διάταξης / Fordított kiosztás beállítása / Aanpassingen voor gespiegelde opstelling / Ajustamento inverso de layout / Rotiranje i podešavanje rasporeda konstrukcije / Ters düzen ayarlaması / 倒轉配置調整 / 倒置(180度翻转)調整 / インバースレイアウト調整 / Pengaturan tata letak terbalik / 역 레이아웃 조정 / تعديل التخطيط العكسي / پیکربندی طرح معکوس

























Chimney effect layout adjustment / Anpassung des Layouts: Kamin-Effekt / Ajuste de la disposición del efecto chimenea / Réglage de la disposition avec effet de cheminée / Regolazione del layout dell'effetto camino / Dostosowanie układu typu efekt kominowy / Регулировка эффекта образования тяги / Възможност за инсталация тип комин / Uspořádání využívající kominový efekt / Ρύθμιση διάταξης φυσικού ελκυσμού / Kémény effektus kiosztás beállítása / Aanpassingen aan de indeling voor Chimney effect / Ajustamento de layout efeito chaminé / Pozicioniranje rasporeda konstrukcije radi efikasnog prenosa toplote "Efekat dimnjaka" / Baca etkisi düzeni ayarı / 煙肉效應配置調整 / 垂直風道(90度旋轉)調整 / 煙突効果レイアウト調整 / Pengaturan tata letak efek cerobong asap / 굴뚝 효과 레이아웃 조정 / تعديل مخطط تأثير المدخنة / پیکر بندی طرح «اثر دودکش»









Make It Yours.

Asia Pacific - Cooler Master Technology Inc.
8F., No. 788-1, Zhongzheng Rd., Zhonghe Dist.,
New Taipei City 23586, Taiwan (R.O.C.).
Tel: +886-2-2225-3517

China - Cooler Master China
Room 2062, Floor 6, No. 421, Weiqing Rd.,
Jinshan District, Shanghai City, China
Tel: +86-21-51872177

Europe - Cooler Master Europe B.V.
Lodewijkstraat 1b, 5652AC Eindhoven, The Netherlands
Tel: +31-(0)40-702-0900

North America - Cooler Master NA
2929 E Imperial Hwy., Suite#110, Brea, CA 92821
Tel: +1-888-624-5099

South America
E-mail: Soporte_Latam@coolermaster.com.tw



Product Page

[www.coolermaster.com/case/full-tower/
cosmos-c700m](http://www.coolermaster.com/case/full-tower/cosmos-c700m)



Technical Support

account.coolermaster.com

512001810-GP Ver 1.0: 2018/08 

The color and specification are subject to be changed without further notification.
Please visit our website for updated information: www.coolermaster.com

©2018 Cooler Master Technology Inc. All Rights Reserved. All trademarks are registered to their respective owners.