

playmobil®

6898



WARNING: CHOKING HAZARD

Contains a small ball and small parts.
Not for children under 3 years.

"Ne concerne que les USA"

Wichtige Unterlagen, bitte sorgfältig aufbewahren !
Important: Please keep these instructions for future reference !
Documents importants, à conserver soigneusement !
Belangrijke documenten, bewaar deze zorgvuldig !

1

1	1	2	3	4	5	6	7	8	9
10	11	12	13	14					
15	16	17	18	19					
20	21	22	23						


1	1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17						
18	19	20	21	22	23						

© 2016 geobra Brandstätter
Stiftung & Co. KG
Brandstätterstraße 2-10
90513 Zirndorf/Germany
No. 30825534 10.15

30 82 5534



www.playmobil.com



30 00 7583



© 2005 geobra Brandstätter • D-90511 Zirndorf • 02.07 No. 30885832

30 88 5832

2



30 02 4522

3



30 02 4532

(D) (A) (CH) (L) (B) ACHTUNG!

Nicht auf Augen oder Gesicht zielen.

(USA) (GB) (CDN) (M) (IRL) WARNING!

Do not aim at eyes or face.

(F) (CDN) (B) (L) (CH) ATTENTION!

Ne pas viser les yeux ou le visage

(E) (MEX) ¡ADVERTENCIA!

No apuntar a los ojos ni a la cara.

(NL) (B) WAARSCHUWING!

Niet op ogen of gezicht richten.

(I) (CH) AVVERTENZA!

Non mirare agli occhi o al viso.

(P) ATENÇÃO!

Não apontar para os olhos ou face.

(DK) ADVARSEL!

Sigt ikke mod øjne eller ansigt.

(N) ADVARSEL!

Sikt ikke på ansikt eller øyne.

(S) (FIN) VARNING!

Sikta inte mot ögon eller ansikte.

(FIN) VAROITUS!

Ei saa kohdistaa suoraan silmiin tai kasvoihin.

(H) FIGYELMEZTETÉS.

Tilos szemre vagy arcra célozni.

(CZ) UPOZORNĚNÍ!

Nemířte na oči nebo na obličej!

(EST) HOIATUS!

Ära sihi silmadesse ega näkku.

(LV) BRĪDINĀJUMS!

Nevērst pret acīm vai seju.

(LT) ĮSPĖJIMAS!

Netaikyti į akis arba veidą.

(SLO) OPOZORILO!

Ne merite v oči ali obraz.

(SK) UPOZORNENIE!

Nemieriť do očí alebo do tváre.

(PL) OSTRZEŻENIE!

Nie celować w oczy i twarz.

(TR) (CY) ΔΙΚΚΑΤ!

Göze veya yüze doğru tutmayınız.

(GR) (CY) Προειδοποίηση!

Μη μην γίνεται στόχευση στα μάτια ή στο πρόσωπο.

(RO) AVERTISMENT!

Nu se țintește în ochi sau în față.

(BG) Внимание!

Не насочвайте към очите и лицето.

(HR) UPOZORENJE!

Ne ciljati u oči ili lice.


(CN) 警告!

请勿瞄准眼睛或脸。

30 64 6474



30 64 6474



30 92 0532

Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

In alle PLAYMOBIL catalogi vindt u het adres van onze klantendienst.

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησης Καταναλωτών PLAYMOBIL βρίσκεται σε όλους τους καταλόγους PLAYMOBIL.

pronounce: plāy-mō-bēēl

© 2015 geobra Brandstätter Stiftung & Co.KG
Brandstätterstr. 2-10
90513 Zirndorf, Germany.
No. 30 82 8144 10.15