



Meaningful Innovation.

WEEE Number: 80133970

INSTRUCTION MANUAL

MOTION SENSOR

TECHNICAL DATA


MODEL	VT-8025
SKU	5084
INPUT VOLTAGE	AC:220-240V, 50/60Hz
RATED CURRENT	5A
SENSOR TYPE	Infrared
UNIT COLOR	White
BODY TYPE	Plastic
RATED LOAD	500W (Traditional Lighting) 200W (LED Lighting)
DETECTION DISTANCE	5-6cm
IP RATING	IP20
WORKING TEMPERATURE	-20°C to +50°C
DIMENSION	35.5x78.2x20.6mm



05 YEAR
WARRANTY*

INTRODUCTION & WARRANTY


Thank you for selecting and buying V-TAC product. V-TAC will serve you the best. Please read these instructions carefully before starting the installation and keep this manual handy for future reference. If you have any another query, please contact our dealer or local vendor from whom you have purchased the product. They are trained and ready to serve you at the best. The warranty is valid for 5 years from the date of purchase. The warranty does not apply to damage caused by incorrect installation or abnormal wear and tear. The company gives no warranty against damage to any surface due to incorrect removal and installation of the product. The products are suitable for 10-12 Hours Daily operation. Usage of product for 24 Hours a day would void the warranty. This product is warranted for manufacturing defects only.



Caution, risk of electric shock.



This marking indicates that this product should not be disposed of with other household wastes.



MULTI-LANGUAGE MANUAL QR CODE

Please scan the QR code to access the manual in multiple languages.



FR
Cet appareil, ses accessoires et cordons se recyclent

À DÉPOSER EN MAGASIN

À DÉPOSER EN DÉCHÈTERIE

OU

Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !


IN CASE OF ANY QUERY/ISSUE WITH THE PRODUCT, PLEASE REACH OUT TO US AT: SUPPORT@V-TAC.EU
FOR MORE PRODUCTS RANGE, INQUIRY PLEASE CONTACT OUR DISTRIBUTOR OR NEAREST DEALERS.
V-TAC EUROPE LTD. BULGARIA, PLOVDIV 4000, BUL.L.KARAVELOW 9B

WARNING


1. Please make sure to turn off the power before starting the installation.
2. Installation should be done by certified electrician.
3. For indoor use only.

INSTALLATION INSTRUCTION

1. Switch off the power.
2. Install the product on the wall with two enclosed inflated screws.
3. Connecting the power and the load to sensor as the connection-wire diagram.
4. Switch on the power and test it



CONNECTION-WIRE DIAGRAM



TEST

- Switch on the power.
- When you move your hands towards the IR sensor, it gets detection and turn on the light.
- The light will be switched off until the IR sensor detects another movement by hands.

NOTE: In front of the detection window there shouldn't be hinder or unrest objects affecting detection.



V-TAC WEST EUROPE LTD. IN CASE OF ANY QUERY/ISSUE WITH THE PRODUCT, PLEASE REACH OUT TO US AT:
SUPPORT@V-TAC.EU FOR MORE PRODUCTS RANGE, INQUIRY PLEASE CONTACT OUR DISTRIBUTOR OR NEAREST DEALERS.
V-TAC WEST EUROPE LTD. GROUND FLOOR, 71 LOWER BAGGOT STREET, DUBLIN 02, IRELAND D02 P593

V-TAC UK LTD. IN CASE OF ANY QUERY/ISSUE WITH THE PRODUCT PLEASE REACH OUT TO US AT
SUPPORT@VTACEXPORTS.COM V-TAC, 5A TUNGSTEN PARK, DOWNS ROAD, WITNEY, OXFORDSHIRE, OX29 0AX