


- ① **Configuration interface (Console)**
Connect the configuration interface via the included serial configuration cable to the serial interface of the device you want to use for configuring / monitoring the switch.
- ② **TP Ethernet interfaces**
Use Ethernet cables to connect the interfaces 1 to 24 to your PC or a LAN switch.



TP Ethernet interfaces:



Use Ethernet cables to connect the interfaces 1 to 24 to your PC or a LAN switch.




Insert suitable LANCOM SFP modules into the SFP+ interfaces 25 to 26. Choose cables which are compatible with the SFP modules and connect them as described in the module's documentation.



Supply power to the device via the power connector. Please use the IEC power cable supplied or a country-specific LANCOM Power Cord.



MOUNTING AND CONNECTING THE DEVICE



System: off	Device powered off
System: green	Device operational
System: red	Hardware error
Link/Act/Speed: green	Port LEDs show link / activity / port speed status
PoE: green	Port LEDs show PoE status

Pressed until all port LEDs are off	Device restart
Pressed until all port LEDs glow permanently	Configuration reset and device restart

Off	Port inactive or disabled
Green	Link 1000 Mbps
Green, blinking	Data transfer, link 1000 Mbps
Orange	Link $\leq$ 100 Mbps
Orange, blinking	Data transfer, link $\leq$ 100 Mbps

Off	Port inactive or disabled
Blue	Link 10 Gbps
Blue, blinking	Data transfer, link 10 Gbps
Green	Link 1 Gbps
Green, blinking	Data transfer, link 1 Gbps

Power supply	Internal power supply unit (110–240 V, 50–60 Hz), PoE based on IEEE 802.3af and IEEE 802.3at
Power consumption	Max. 235 W
Environment	Temperature range 0–40 °C; short term temperature conditions 0–50 °C; humidity 10–90%; non-condensing
Housing	Robust metal housing, 1 HU with removable mounting brackets for 19" installation, network connectors on the front, 442 x 44 x 211 mm (W x H x D)

ETH	> 24 TP Ethernet ports 10 / 100 / 1000 Mbps
SFP+	> 2 SFP+ ports 1 / 10 Gbps
	> 26 concurrent ports in total

Hereby, LANCOM Systems GmbH | Adenauerstrasse 20/B2 | D-52146 Wuersele, declares that this device is in compliance with Directives 2014/30/EU and 2014/35/EU. The full text of the EU declaration of conformity is available at the following internet address: www.lancom-systems.com/ce/

Manual	Quick Reference Guide (DE/EN), Installation Guide (DE/EN)
Mounting brackets	Two 19" brackets for rack mounting
Cable	IEC power cord 230 V, serial configuration cable 1.5 m