

Covers for switches/push-buttons
Switch rocker with marking
with small transparent lens



With bell symbol.
For flush-mounted push switch.

Order Code : 2CKA001751A2840

Article No. : 1789 KI-266

EAN: 4011395006061