



Install Hard Drive



1-1 Remove the drive tray.



1-2 Install 2 × 3.5" drives or 2 × 2.5" drives.



1-3 Install the drive tray into the chassis.



RM31-MINI

3U rackmount server chassis with
8 expansion slots & 360mm radiator support

User manual


www.silverstonetek.com

Accessories Content

		
Motherboard standoff	Motherboard screws	Secure 2.5" SSD screws
		
Secure 2.5" SSD tray screws	Secure 3.5" HDD, power supply screws	L-shaped bracket
		
Handle bar	Handle bar bracket screws	


Power Supply and Radiator limitations

Supports installation of PSU up to 166mm
Supports installation of front fans and radiator
up to 55mm




Power Supply Installation

2-1 Power Supply Installation




Left and Right Handles Installation

3-1 Secure the handle assemblies to both sides of
the chassis.




Install radiator


4-1 Remove Front Panel



4-2 Install 120 mm fan + radiator





4-3 Install Front Panel



Radiator and Expansion Card Limitations


Combined radiator and expansion card length: 361 mm

If the radiator length exceeds 397 mm, the fans must be installed in the front with the radiator positioned behind.




Graphics Card Width Limitation

Expansion Card Width Limit: 115 mm




CPU Cooler Limitation

CPU Cooler Height Limit: 110 mm




If no side tray is installed, the CPU cooler may extend up to 6 mm beyond the edge of the motherboard.

If a side tray with a 2.5" drive is installed, the CPU cooler must remain within 7 mm inside the edge of the motherboard.




Install Hard Drive


5-1 Remove the 2.5" Tray



5-2 Install the 2.5" Drive




5-3 Mount the Drive to the Chassis



Motherboard Component Limitations

The drive mounting surface is 8 mm outside the motherboard, and the drive has 33 mm of clearance above the motherboard.

Please determine whether the drive will interfere with motherboard components based on these two conditions and the drive thickness.



Warranty Information

This product has a limited 1 year warranty in North America and Australia. For information on warranty periods in other regions, please contact your reseller or SilverStone authorized distributor. 本产品自购买之日起，于中国地区（不包含澳门，香港特别行政区）享有一年有限保证责任保固（部分产品为二年，三年或五年）。详细保固年限请参考官方网站 <https://silverstonetek.com.cn/> 公布之产品型号为依据。

Warranty terms & conditions

- Product component defects or damages resulted from defective production is covered under warranty. Defects or damages with the following conditions will be fixed or replaced under SilverStone Technology's jurisdiction.
 - Usage in accordance with instructions provided in this manual, with no misuse, overuse, or other inappropriate actions.
 - Damage not caused by natural disaster (thunder, fire, earthquake, flood, salt, wind, insect, animals, etc...)
 - Product is not disassembled, modified, or fixed. Components not disassembled or replaced.
 - Warranty mark/stickers are not removed or broken.Loss or damages resulted from conditions other than ones listed above are not covered under warranty.
- Under warranty, SilverStone Technology's maximum liability is limited to the current market value for the product (depreciated value, excluding shipping, handling, and other fees). SilverStone Technology is not responsible for other damages or loss associated with the use of product.
- Under warranty, SilverStone Technology is obligated to repair or replace its defective products. Under no circumstances will SilverStone Technology be liable for damages in connection with the sale, purchase, or use including but not limited to loss of data, loss of business, loss of profits, loss of use of the product or incidental or consequential damage whether or not foreseeable and whether or not based on breach of warranty, contract or negligence, even if SilverStone Technology has been advised of the possibility of such damages.
- Warranty covers only the original purchaser through authorized SilverStone distributors and resellers and is not transferable to a second hand purchaser.
- You must provide sales receipt or invoice with clear indication of purchase date to determine warranty eligibility.
- If a problem develops during the warranty period, please contact your retailer/reseller/SilverStone authorized distributors or SilverStone <http://www.silverstonetek.com>. Please note that: (i) You must provide proof of original purchase of the product by a dated itemized receipt; (ii) You shall bear the cost of shipping (or otherwise transporting) the product to SilverStone authorized distributors. SilverStone authorized distributors will bear the cost of shipping (or otherwise transporting) the product back to you after completing the warranty service; (iii) Before you send the product, you must be issued a Return Merchandise Authorization ("RMA") number from SilverStone. Updated warranty information will be posted on SilverStone's official website. Please visit <http://www.silverstonetek.com> for the latest updates.

Additional info & contacts

For North America (usasupport@silverstonetek.com)
SilverStone Technology in North America may repair or replace defective product with refurbished product that is not new but has been functionally tested.
Replacement product will be warranted for remainder of the warranty period or thirty days, whichever is longer. All products should be sent back to the place of purchase if it is within 30 days of purchase, after 30 days, customers need to initiate RMA procedure with SilverStone Technology in USA by first downloading the "USA RMA form for end-users" form from the below link and follow its instructions. <http://silverstonetek.com/contactus.php>
For Australia only (support@silverstonetek.com)
Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.
Please refer to above "Warranty terms & conditions" for further warranty details.
SilverStone Technology Co., Ltd. 12F No. 168 Jiankang Rd., Zhonghe Dist., New Taipei City 235 Taiwan R.O.C. + 886-2-8228-1238 (standard international call charges apply)
For Europe (support.eu@silverstonetek.de)
For China (support@silverstonetek.com.cn)
For all other regions (support@silverstonetek.com)

有毒有害物质/元素及其化学含量表						
部件名称	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
机壳 (金属)	○	○	○	○	○	○
风扇	○	○	○	○	○	○
线材	○	○	○	○	○	○
螺丝	○	○	○	○	○	○
包材	○	○	○	○	○	○

本表格依据SJ/T 11364的规定编制
○：表示该有毒有害物质在该部件所有均质材料中的含量均在GB/T 26572 规定的限量要求以下。
×：表示该有毒有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572 规定的限量要求。



SilverStone Technology Co., Ltd.
www.silverstonetek.com
support@silverstonetek.com