




TUF Gaming Monitor VG27AQML5F Series

User Guide



™ The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

Copyright © 2026 ASUSTeK COMPUTER INC. All Rights Reserved.

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUSTeK COMPUTER INC. ("ASUS").

Product warranty or service will not be extended if: (1) the product is repaired, modified or altered, unless such repair, modification or alteration is authorized in writing by ASUS; or (2) the serial number of the product is defaced or missing.

ASUS PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ASUS, ITS DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OR DATA, INTERRUPTION OF BUSINESS AND THE LIKE), EVEN IF ASUS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES ARISING FROM ANY DEFECT OR ERROR IN THIS MANUAL OR PRODUCT.

SPECIFICATIONS AND INFORMATION CONTAINED IN THIS MANUAL ARE FURNISHED FOR INFORMATIONAL USE ONLY, AND ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE, AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY ASUS. ASUS ASSUMES NO RESPONSIBILITY OR LIABILITY FOR ANY ERRORS OR INACCURACIES THAT MAY APPEAR IN THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

Contents

Notices.....	iv
Safety information	v
Care & Cleaning	vii
Takeback Services	viii
Product information for EU energy label	viii
1.1 Welcome!	1-1
1.2 Package contents	1-1
1.3 Monitor introduction	1-2
1.3.1 Front view	1-2
1.3.2 Back view	1-3
2.1 Assembling the monitor arm/base	2-1
2.2 Adjusting the monitor	2-2
2.3 Detaching the arm (for VESA wall mount).....	2-3
2.4 Cable management	2-4
2.5 Connecting the cables	2-4
2.6 Turning on the monitor	2-5
3.1 OSD (On-Screen Display) menu.....	3-1
3.1.1 How to reconfigure.....	3-1
3.1.2 OSD function introduction	3-4
3.2 Specifications.....	3-19
3.3 Outline dimensions	3-21
3.4 Troubleshooting (FAQ).....	3-22
3.5 Supported timing list	3-23

Notices

Federal Communications Commission Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



WARNING: The use of shielded cables for connection of the monitor to the graphics card is required to assure compliance with FCC regulations. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Canadian Department of Communications Statement

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

This class B digital apparatus complies with Canadian ICES-003.

This Class B digital apparatus meets all requirements of the Canadian Interference - Causing Equipment Regulations.

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.



Safety information

- Before setting up the monitor, carefully read all the documentation that came with the package.
- To prevent fire or shock hazard, never expose the monitor to rain or moisture.
- Never try to open the monitor cabinet. The dangerous high voltages inside the monitor may result in serious physical injury.
- If the power supply is broken, do not try to fix it by yourself. Contact a qualified service technician or your retailer.
- Before using the product, make sure all cables are correctly connected and the power cables are not damaged. If you detect any damage, contact your dealer immediately.
- Slots and openings on the back or top of the cabinet are provided for ventilation. Do not block these slots. Never place this product near or over a radiator or heat source unless proper ventilation is provided.
- The monitor should be operated only from the type of power source indicated on the label. If you are not sure of the type of power supply to your home, consult your dealer or local power company.
- Use the appropriate power plug which complies with your local power standard.
- Do not overload power strips and extension cords. Overloading can result in fire or electric shock.
- Avoid dust, humidity, and temperature extremes. Do not place the monitor in any area where it may become wet. Place the monitor on a stable surface.
- Unplug the unit during a lightning storm or if it will not be used for a long period of time. This will protect the monitor from damage due to power surges.
- Never push objects or spill liquid of any kind into the slots on the monitor cabinet.
- To ensure satisfactory operation, use the monitor only with UL listed computers which have appropriate configured receptacles marked between 100-240V AC.
- If you encounter technical problems with the monitor, contact a qualified service technician or your retailer.
- Adjustment of the volume control as well as the equalizer to other settings than the center position may increase the ear-/headphones output voltage and therefore the sound pressure level.



The Waste Electrical and Electronic Equipment (WEEE) Directive (Directive 2012/19/EU) is a European Union law that aims to reduce the environmental impact of electrical and electronic equipment. It mandates producers to take responsibility for the end-of-life management of their products, promoting collection, treatment, and recycling to minimize waste and encourage resource recovery.

Do not throw your Electronic and electrical equipment in municipal waste.

The symbol of the crossed-out wheeled bin on the product or packaging indicates that this product (including any batteries it contains), must not be disposed of with your household waste.

To prevent potential harm to the environment and human health, a collection framework should be used to return, recycle, and recover waste electrical and electronic equipment (WEEE), and this product has been designed to enable the reuse of parts and facilitate the recycling of certain materials.

Improper disposal may involve risks due to the presence of hazardous substances within electrical and electronic equipment, such as lead and BFR and other harmful components.

Check your local recycling services for electronic products.

(<https://esg.asus.com/en/circular-economy/resource-regeneration/global-take-back-service>).

AEEE yönetmeliine uygundur

Care & Cleaning

- Before you lift or reposition your monitor, it is better to disconnect the cables and power cord. Follow the correct lifting techniques when positioning the monitor. When lifting or carrying the monitor, grasp the edges of the monitor. Do not lift the display by the stand or the cord.
- Cleaning. Turn your monitor off and unplug the power cord. Clean the monitor surface with a lint-free, non-abrasive cloth. Stubborn stains may be removed with a cloth dampened with mild cleaner.
- Avoid using a cleaner containing alcohol or acetone. Use a cleaner intended for use with the monitor. Never spray cleaner directly on the screen, as it may drip inside the monitor and cause an electric shock.

The following symptoms are normal with the monitor:

- The screen may flicker during the initial use due to the nature of the fluorescent light. Turn off the Power Switch and turn it on again to make sure that the flicker disappears.
- You may find slightly uneven brightness on the screen depending on the desktop pattern you use.
- When the same image is displayed for hours, an afterimage of the previous screen may remain after switching the image. The screen will recover slowly or you can turn off the Power Switch for hours.
- When the screen becomes black or flashes, or cannot work anymore, contact your dealer or service center to fix it. Do not repair the screen by yourself!

Conventions used in this guide



WARNING: Information to prevent injury to yourself when trying to complete a task.



CAUTION: Information to prevent damage to the components when trying to complete a task.



IMPORTANT: Information that you **MUST** follow to complete a task.



NOTE: Tips and additional information to aid in completing a task.

Where to find more information

Refer to the following sources for additional information and for product and software updates.

1. **ASUS websites**

The ASUS websites worldwide provide updated information on ASUS hardware and software products. Refer to <http://www.asus.com>

2. **Optional documentation**

Your product package may include optional documentation that may have been added by your dealer. These documents are not part of the standard package.

3. **About Flicker**

https://www.asus.com/Microsite/display/eye_care_technology/

Takeback Services

ASUS recycling and takeback programs come from our commitment to the highest standards for protecting our environment. We believe in providing solutions for our customers to be able to responsibly recycle our products, batteries and other components as well as the packaging materials.

Please go to <https://esg.asus.com/en/circular-economy/resource-regeneration/global-take-back-service> for detail recycling information in different region.

Product information for EU energy label



VG27AQML5F

1.1 Welcome!

Thank you for purchasing the ASUS® LCD monitor!

The latest widescreen LCD monitor from ASUS provides a broader, brighter and crystal-clear display, plus a host of features that enhance your viewing experience.

With these features, you can enjoy the convenience and delightful visual experience that the monitor brings to you!

1.2 Package contents

Check your package for the following items:


- ✓ LCD monitor
- ✓ Monitor base
- ✓ Monitor stand
- ✓ Monitor VESA
- ✓ Quick Start Guide
- ✓ Warranty card
- ✓ Power cord
- ✓ DisplayPort cable



-
- If any of the above items is damaged or missing, contact your retailer immediately.
-

1.3 Monitor introduction

1.3.1 Front view




1. (⊙ 5-way) button:
 - Activates the Quick menu.
 - Enacts the selected OSD menu item.
 - Increases/Decreases values or moves your selection up/down/left/right.
 - Displays the input selection bar when the monitor enters standby mode or displays the “NO SIGNAL” message.
2. button:
 - Exits the OSD menu item.
 - Displays the input selection bar when the monitor enters standby mode or displays the “NO SIGNAL” message.
3. Shortcut 1 button:
 - Default: GamePlus.
 - To change the shortcut function, go to the MyFavorite > Shortcut > Shortcut 1 menu.
 - Displays the input selection bar when the monitor enters standby mode or displays the “NO SIGNAL” message.

4. **Shortcut 2 button:**
 - Default: GameVisual.
 - To change the shortcut function, go to the MyFavorite > Shortcut > Shortcut 2 menu.
 - Displays the input selection bar when the monitor enters standby mode or displays the “NO SIGNAL” message.
5. **Power button/power indicator:**
 - Turns the monitor on/off.
 - The color definition of the power indicator is as the below table.

Status	Description
White	ON
Amber	Standby mode/No signal
OFF	OFF

1.3.2 Back view




1. **Earphone jack.** This port is only available when an HDMI/DisplayPort cable is connected.
2. **Service port.** Use this port to connect the monitor with your PC via USB type-C cable to upgrade the firmware of the monitor.
3. **HDMI ports.** These ports are for connection with an HDMI compatible devices.
4. **DisplayPort.** This port is for connection for a DisplayPort compatible device.
5. **ACIN port.** This port connects the power cord.
6. **Kensington lock slot.**
7. **Control buttons.**

2.1 Assembling the monitor arm/base

To assemble the monitor base:


1. Have the front of the monitor face down on a table.
2. Attach the arm hinge to the arm. Then press the arm until you hear a click, ensuring the latch is fully engaged. (Figure 1)
3. Align and install the arm hinge of the stand assembly onto its compartment on the rear of the monitor. (Figure 2)
4. Attach the base into the arm. (Figure 3)
5. Tighten the bundled screw to secure the base. (Figure 4)



We recommend that you cover the table surface with soft cloth to prevent damage to the monitor.

2.2 Adjusting the monitor

- For optimal viewing, we recommend that you look at the full face of the monitor, then adjust the monitor to the angle that is most comfortable for you.
- Hold the stand to prevent the monitor from falling when you change its angle.
- The recommended adjusting angle is -5° to 20° (for tilt) / -20° to 20° (for swiveling), supported rotation is 90° , and adjustable height is 120 mm.




- It is normal that the monitor slightly shakes while you adjust the viewing angle.

2.3 Detaching the arm (for VESA wall mount)

The detachable arm/base of this monitor is specially designed for VESA wall mount.

To detach the arm/base:

1. Have the front of the monitor face down on a table.
2. Loosen the bundled screw securing the base. (Figure 1)
3. Remove the base. (Figure 2)
4. Press the release button to detach the stand from the monitor. Then remove the stand. (Figure 3)
5. Press the latch to disengage the arm hinge from the arm. Then remove the arm. (Figure 4)




- We recommend that you cover the table surface with soft cloth to prevent damage to the monitor.



- The VESA wall mount kit (100 x 100 mm) is purchased separately.
- Use only the UL Listed Wall Mount Bracket with minimum weight/load 22.7kg (Screw size: M4 x 13 mm).


2.4 Cable management

You can organize the cables using the cable management slot. Connect the cables accordingly and guide them through the slot.



2.5 Connecting the cables

Connect the cables as the following instructions:



- **To use the earphone:** Connect the end with plug type to the monitor's earphone jack when an HDMI/DisplayPort signal is fed.
- **Service port:** Use this port to connect the monitor with your PC via USB type-C cable to upgrade the firmware of the monitor.
- **To connect the HDMI/DisplayPort cable:**
 - a. Plug one end of the HDMI/DisplayPort cable to the monitor's HDMI/DisplayPort jack.
 - b. Connect the other end of the HDMI/DisplayPort cable to your device's HDMI/DisplayPort jack.
- **To use the power cord:** Connect the power cord to a power outlet.


2.6 Turning on the monitor

Press the Power (⏻) button. The Power indicator lights up in white to indicate that the monitor is turned on.


3.1 OSD (On-Screen Display) menu

3.1.1 How to reconfigure

1. After the monitor is turned on, press the  button to activate the OSD Quick Menu.




2. When the Quick Menu is activated:



OSD (On Screen Display) icon	 Control button operation	Function
Quick Menu	Move up/down	Switches to the previous/next menu setting.
	Move left/right	• Selects the previous/next menu item. • Selects the desired parameter.
	Press (center)	Confirms the selection.


To modify the Quick Menu options, refer to the Quick Menu item in the OSD function introduction (page 3-15).

3. When the Menu is activated:




OSD (On Screen Display) icon	Control button operation	Function
Menu	Move up/down	- Selects the previous/next menu item. - Selects the desired parameter.
	Move left/right	Switches to the left/right menu.
	Press (center)	Confirms the selection.

- **ASUS DisplayWidget Center:** Displays a QR code for you to access the information about ASUS DisplayWidget Center.
 - Please go to VG27AQML5F official website, find "Support" tab and choose "Driver & Utility" to download latest DisplayWidget Center.
 - Please always connect your VG27AQML5F to input device first, and then turn on DisplayWidget Center.
 - We also suggest you to create a shortcut of DisplayWidget Center on your computer desktop for easier activation.



3.1.2 OSD function introduction

1. Gaming



Menu Option		Description	Remark
Variable OD	Level 0~5	Speeds up the response time by Over Drive technology.	
Variable Refresh Rate	On / Off	Allows an Adaptive-Sync supported graphics source to dynamically adjust display refresh rate based on typical content frame rates for power efficient, virtually stutter free and low-latency display update.	- Variable Refresh Rate can only be activated within 48Hz~320Hz for both HDMI and DisplayPort. - For supported GPUs, minimum PC system and driver requirements, please contact the GPU manufactures. - The following function will be disabled when Variable Refresh Rate is On: ELMB.

Menu Option		Description	Remark
ELMB Setup	ELMB	When Variable Refresh Rate is Off, this function can only be activated when the refresh rate is higher than 100Hz.	The following functions will be disabled when ELMB is On: - Variable Refresh Rate - ELMB SYNC - Brightness - Aspect Control - ASCR - Blue Light Filter - Variable OD - HDR Setting
	ELMB SYNC	Allows you to turn on the function when Variable Refresh Rate is On. This function eliminates screen tearing, reduces ghosting and motion blur when playing games.	The following functions will be disabled when ELMB SYNC is On: - ELMB - Brightness - Aspect Control - ASCR - Blue Light Filter - HDR Setting
	Clarity Level	Adjusts the sharpness level of the ELMB effect. There are 5 clarity levels available, allowing you to fine-tune motion clarity based on your preference.	When Clarity Level or Clarity Position is enabled, the following functions will be unavailable: Variable Refresh Rate, ELMB Sync, Brightness, Aspect Control, Dynamic Dimming, ASCR, Blue Light Filter, Variable OD, HDR Setting.
	Clarity Position	Adjusts where the blur-reduction effect appears on screen. Choose from 3 levels — Top, Middle, or Bottom — to match different types of content.	


Menu Option		Description	Remark
GamePlus	FPS Counter	Displays real-time frames per second (FPS) to indicate how smoothly the game is running. You can choose to show the FPS as a number or a bar graph on screen.	
	Crosshair	Provides 6 built-in crosshair styles, so you can choose the one that best fits your game. Also includes a Dynamic Crosshair option that adjusts the crosshair automatically based on gameplay.	
	Timer	Displays a countdown timer on the upper-left corner of the screen to help you track gameplay or rest time. You can choose from the following preset durations: 30:00, 40:00, 50:00, 60:00, or 90:00 minutes.	
	Stopwatch	Displays a stopwatch on the upper-left corner of the screen to help you track elapsed time during gameplay or activities. The stopwatch starts from 00:00 and counts upward until manually stopped.	
	Display Alignment	Displays alignment lines on all four sides of the screen to help you align multiple monitors more precisely and easily.	

Menu Option		Description	Remark
Game Visual	Scenery mode	This is the best choice for scenery photo displaying with GameVisual™ Video intelligence Technology.	
	Racing Mode	This is the best choice for racing game playing with GameVisual™ Video intelligence Technology.	
	Cinema Mode	This is the best choice for movie watching with GameVisual™ Video intelligence Technology.	
	RTS/RPG Mode	This is the best choice for Real-Time Strategy(RTS)/ Role-Playing Game (RPG) playing with GameVisual™ Video intelligence Technology.	
	FPS Mode	This is the best choice for First Person Shooter game playing with GameVisual™ Video intelligence Technology.	
	sRGB Mode	This is the best choice for viewing photos and graphics from PCs.	In the sRGB mode, the following function(s) are not user-configurable: Contrast, Saturation, Color Temp., and ASCR.
	MOBA Mode	This is the best choice for multiplayer online battle arena game playing with GameVisual™ Video intelligence Technology.	In the MOBA/ Night Vision mode, the following function(s) are not user-configurable: Saturation.
	Night Vision	This is the best choice for dark scenery playing GameVisual™ Video intelligence Technology.	
	User Mode	More items are adjustable in the Color menu.	

Menu Option		Description	Remark
Shadow Boost		Dark color enhancement adjusts monitor gamma curve to enrich the dark tones in an image, making dark scenes and objects much easier to be seen.	This function is not available in sRGB mode and MOBA mode.
ASUS Display Widget Center		Displays a QR code for you to access the information about ASUS DisplayWidget Center.	

2. Image

Adjust the image settings.



Menu Option		Description	Remark
Brightness	0 to 100	Adjust screen brightness. When HDR is enabled, only adjustment via HDR Brightness is supported.	
Contrast	0 to 100	Adjust contrast to enhance image detail and depth.	
HDR Setting	Gaming HDR	Delivers richer details and more realistic colors, especially noticeable in scenes with strong contrast between light and dark areas. <u>Gaming HDR</u> A mode designed for gamers. <u>Cinema HDR</u> Ideal for movies and cinematic content. <u>Console HDR</u> Tailored for gaming consoles.	When detecting HDR content, an “HDR ON” message will pop up. When displaying HDR content, the following function(s) are not available: ELMB, GameVisual, Shadow Boost, Brightness, Contrast, ASCR, Blue Light Filter, Color Temp., Saturation, and Display Color Space.
	Cinema HDR		
	Console HDR		
	Brightness Adjustable	By default, brightness in HDR mode is automatic. Enabling this feature allows manual brightness adjustment.	
ASCR	On / Off	Turns on/off the ASCR (ASUS Smart Contrast Ratio) function.	This function is not available in sRGB mode.


Menu Option		Description	Remark
Aspect Control	16:9/ Square	Select the aspect ratio and adjust the screen position. <u>16:9 Full</u> Fills the screen by stretching the image without preserving the aspect ratio. The image becomes larger but may distort, affecting the viewing experience. <u>16:9 24.5" Simulation</u> Displays the image at a 24.5-inch size, maintaining the aspect ratio without distortion, but the image appears smaller. <u>16:9 Pixel by Pixel</u> 16:9 native mode maps pixels directly, keeping clarity and aspect ratio. Low resolution images may show black borders. <u>Square Full</u> Stretches the image to fill the entire screen without preserving the aspect ratio. The image becomes larger but may be distorted, affecting the viewing experience. <u>Square Equivalent</u> Scales the image up while maintaining the original aspect ratio to avoid distortion, but may result in black borders. <u>Square Pixel by Pixel</u> Displays the image at its original resolution without scaling or stretching.	

Menu Option		Description	Remark
Blue Light Filter	Level 0	No change.	Please refer to the following to alleviate eye strains: • Users should take some time away from the display if working for long hours. It is advised to take short breaks (at least 5 mins) after around 1 hour of continuous working at the computer. Taking short and frequent breaks is more effective than a single longer break. • To minimize eye strain and dryness in your eyes, users should rest the eye periodically by focusing on objects that are far away. • Eye exercises can help to reduce eye strain. Repeat these exercises often. If eye strain continues please consult a physician. Eye exercises: (1) Repeating look up and down (2) Slowly roll your eyes (3) Move your eyes diagonal. • High energy blue light may lead to eye strain and AMD (Age-Related Macular Degeneration). Blue light Filter to reduce 70% (max.) harmful blue light to avoid CVS (Computer Vision Syndrome).
	Level 1~4	The higher the level, the less blue light is scattered. When Blue Light Filter is activated, the default settings of Racing Mode will be automatically imported. Between Level 1 to Level 3, the Brightness function is user-configurable. Level 4 is optimized setting. It is compliance with TUV Low Blue Light Software Solution Certification. The Brightness function is not userconfigurable.	

Menu Option		Description	Remark
SmartPixel	Level 3 / Level 2 / Level 1 / OFF	Enhances overall image details in real time for clearer and more vivid visuals.	
VividPixel	0 to 100	Enhances the outline of the displayed picture and generates high-quality images on screen.	

3. Color


Set a desired color setting from this menu.



Menu Option		Description	Remark
Display Color Space	sRGB / DCI-P3 / Wide Gamut	Selects the color space for the monitor color output.	
Color Temp.	Warm / Normal / Cool / User Mode	Contains 4 modes including Warm, Normal, Cool, and User Mode.	User R/G/B: Adjustable from 0~100
Saturation	0 to 100	Adjusts the saturation level.	

4. Input Select


In this function, you can select your desired input source or allow to automatically detect the input source.



Menu Option		Description	Remark
Auto Input Detection	On / Off	Once turned on, it automatically detects the signal and switches the input source.	
DisplayPort		Select DisplayPort as the video input source.	
HDMI-1		Select HDMI-1 as the video input source.	
HDMI-2		Select HDMI-2 as the video input source.	

5. MyFavorite

Assign a function to the Quick Menu and shortcut button, save the current system configurations, or restore the system configuration.




Menu Option		Description	Remark
Quick Menu	Mode1 / Mode2 / Mode3 / Mode4	The Quick Menu provides 4 customizable shortcuts for easy access to frequently used settings	• The available functions include: GameVisual, ELMB, Shadow Boost, Saturation, Brightness, Variable Refresh Rate, Contrast, Input Select, VividPixel, Variable OD, ColorTemp. • To keep the Quick Menu shorter, you can select None to hide a shortcut. • Do not assign the same function to multiple positions. A Shortcut will be grayed out if it is not supported in the current mode.

Menu Option		Description	Remark
Shortcut	Shortcut 1 / Shortcut 2	Sets the shortcut functions for shortcut buttons.	When a certain function is selected or activated, your shortcut button may not be supported. Available function choices: GamePlus, GameVisual, Variable OD, Brightness, Mute, Shadow Boost, Contrast, Input Select, HDR Setting, Blue Light Filter, Color Temp., Volume, Customized Setting-1, and Customized Setting-2.
Customized Setting	Setting 1 / Setting 2	Loads/Saves all settings on the monitor.	

6. System Setup

Adjust the system configuration.



Menu Option		Description	Remark
Language	Language Selection	Selects an available language for the OSD menu.	
Sound	Volume	Adjusts the volume level from 0 to 100.	
	Mute	If checked, mutes the volume.	
Power Indicator	On / Off	Turns the power LED indicator on/off.	
Power Key Lock	On / Off	Enables or disables the power key.	
Key Lock	On / Off	Enable this function to disable all function keys. Press the Navigation button down for more than five seconds to cancel the key lock function.	
Power Setting	Performance Mode / Power Saving Mode	Sets the power mode. <u>Performance Mode</u> Offers better performance but consumes more power. <u>Power Saving Mode</u> Limits brightness and features to save energy. HDR must be turned off before enabling this; a reminder will appear when adjusting brightness.	

Menu Option		Description	Remark
OSD Setup	OSD Position	Sets the OSD menu position.	
	OSD Timeout	Adjusts the OSD timeout from 10 to 120 seconds.	
	Transparency	Adjusts the OSD background from opaque to transparent.	
	DDC/CI	Enables or disables the DDC/CI function.	
DisplayPort Stream	DisplayPort 1.2 / or DisplayPort 1.4	Selects DisplayPort 1.2 or DisplayPort 1.4 according to the graphic card DP version.	
DSC Support	On / Off	Enables/Disables the DSC (Display Stream Compression) function.	
ASUS Power Sync	On / Off	Optimizes the performance of ASUS NUC devices by eliminating cable clutter, enhancing power delivery efficiency, and providing superior device connectivity for an improved user experience.	
Information		Shows the monitor information.	
All Reset	YES / NO	Select YES to revert all settings to the factory default mode.	

3.2 Specifications


Model	VG27AQML5F
Panel type	TFT LCD
Panel size	27.0 inches (68.6 cm) diagonal
Max. resolution	2560 (H) x 1440 (V) pixels
Brightness (max.)	SDR: 350 cd/m ² HDR: 400 cd/m ²
Intrinsic Contrast Ratio (max.)	1300 :1
Dynamic Contrast Ratio (max.)	≥ 100,000,000:1
Viewing angle (CR ≤ 10)	≥ 178°(V); ≥ 178°(H)
Display colors	1.07B (8 bit + FRC)
Response time (typ.)	0.3 ms GTG
Color temperature selection	4 color temperatures
Digital input	HDMI v2.1 x2, DisplayPort v1.4 x1, Audio out x1
Earphone jack	Yes
Audio input	No
Speaker (built-in)	2W x2
Colors	Black
Power LED	White (On)/Amber (Standby)
Tilt	+20° ~ -5°
Pivot	+90° ~ -90°
Swivel	+20° ~ -20°
Height adjustment	0~120 mm
VESA wall mounting	100 x 100 mm
Kensington lock	Yes
Voltage rating	AC 100 ~ 240V at 50/60Hz
Power consumption	< 31W**
Standby power consumption	< 0.5 W
Power off power consumption	< 0.3 W
Temperature	Operating temperature: 0 ~ 40°C Non-operating temperature: -20 ~ 60°C
Dimension (W x H x D) with stand	61.50 x 53.50 x 19.40 cm

Model	VG27AQML5F
Dimension (W x H x D) without stand	61.50 x 36.70 x 5.40 cm
Box dimension (W x H x D)	67.50 x 50.00 x 13.50 cm
Net weight (Esti.) with stand	5.5±0.5 kg
Net weight (Esti.) without stand	3.6 ±0.5 kg
Gross Weight (Esti.)	6.8±0.5 kg
Muti-language	23 Languages (English, French, German, Spanish, Italian, Dutch, Russian, Polish, Czech, Croatian, Hungarian, Romanian, Portuguese, Turkish, Simplified Chinese, Traditional Chinese, Japanese, Korean, Persian, Thai, Indonesian, Ukrainian, and Vietnamese)
Accessories	Power Cord, DP cable, Warranty Card, QSG
Compliance and Standards	cTUVus, CU, CB, CE, ErP, FCC,CEC, CCC,RCM, BSMI, VCCI, PSB, RoHS, J-MOSS, VN MEPS, WEEE, PSE, Windows 10/11 WHQL, CEL(L2), KC, KCC, KMEPS (Korea MEPS),TUV flicker free and low blue light, HDMI, DP, ICES-003, UkrSEPRO, Ukraine Energy, SIOC, PC Recycle

*Specifications subject to change without notice.

** Measuring a screen brightness of 200 nits without audio/ USB/ Card reader connection.

3.3 Outline dimensions



3.4 Troubleshooting (FAQ)

Problem	Possible Solution
Power LED is not ON	• Press the  button to check if the monitor is in the ON mode. • Check if the power cord is properly connected to the monitor and the power outlet. • Check Power Indicator function in main menu OSD. Select ON to turn on power LED.
The power LED lights amber and there is no screen image	• Check if the monitor and the computer are in the ON mode. • Make sure the signal cable is properly connected the monitor and the computer. • Inspect the signal cable and make sure none of the pins are bent. • Connect the computer with another available monitor to check if the computer is properly working.
Screen image is too light or dark	• Adjust the Contrast and Brightness settings via OSD.
Screen image bounces or a wave pattern is present in the image	• Make sure the signal cable is properly connected to the monitor and the computer. • Move electrical devices that may cause electrical interference.
Screen image has color defects (white does not look white)	• Inspect the signal cable and make sure that none of the pins are bent. • Perform Reset via OSD. • Select the appropriate Color Temperature via OSD.
No sound or sound is low	• Adjust the volume settings of both your monitor and computer. • Make sure the computer sound card driver is properly installed and activated.

3.5 Supported timing list

Resolution Frequency	
HDMI	DP
640x480 @ 60Hz	640x480 @ 60Hz
640x480 @ 75Hz	640x480 @ 75Hz
720x480 @ 60Hz	720x480 @ 60Hz
720x576 @ 50Hz	720x576 @ 50Hz
800x600 @ 60Hz	800x600 @ 60Hz
800x600 @ 75Hz	800x600 @ 75Hz
1024x768 @ 60Hz	1024x768 @ 60Hz
1024x768 @ 75Hz	1024x768 @ 75Hz
1280x720 @ 50Hz	1280x720 @ 50Hz
1280x720 @ 60Hz	1280x720 @ 60Hz
1280x960 @ 60Hz	1280x960 @ 60Hz
1280x1024 @ 60Hz	1280x1024 @ 60Hz
1600x1200 @ 60Hz	1600x1200 @ 60Hz
1920x1080 @ 24Hz	1920x1080 @ 24Hz
1920x1080 @ 25Hz	1920x1080 @ 25Hz
1920x1080 @ 30Hz	1920x1080 @ 30Hz
1920x1080 @ 50Hz	1920x1080 @ 50Hz
1920x1080 @ 60Hz	1920x1080 @ 60Hz
1920x1080 @ 100Hz	1920x1080 @ 100Hz
1920x1080 @ 120Hz	1920x1080 @ 120Hz
1920x1080 @ 240Hz	1920x1080 @ 240Hz
1920x1080 @ 320Hz	1920x1080 @ 320Hz
2560x1440 @ 60Hz	2560x1440 @ 60Hz
2560x1440 @ 120Hz	2560x1440 @ 120Hz
2560x1440 @ 144Hz	2560x1440 @ 144Hz
2560x1440 @ 240Hz	2560x1440 @ 165Hz
2560x1440 @ 320Hz	2560x1440 @ 240Hz
3840x2160 @ 24Hz	2560x1440 @ 320Hz
3840x2160 @ 25Hz	
3840x2160 @ 30Hz	
3840x2160 @ 50Hz	
3840x2160 @ 60Hz	
3840x2160 @ 100Hz	
3840x2160 @ 120Hz	