

Quick Start Guide

Kurzanleitung

Snelle Starthandleiding

Guía de inicio rápido

Guida rapida all'avvio

Guide de démarrage rapide

Przewodnik szybkiego uruchomienia






EN Non Contractual Picture.
DE Außervertragliches Bild.
NL Niet-contractueel beeld.
ES Fotografía no contractual.
IT Foto non contrattuali.


FR Photo non contractuelle.
PL Zdjęcia mogą różnić się od oryginału.




EN What's in the box
DE Lieferumfang
NL Wat zit er in de doos?
ES Contenido de la caja
IT Contenuto della confezione
FR Contenu de l'emballage
PL Zawartość opakowania




1




2




3





5




6



4



5






27R83U

UPSTREAM HDMI™ 1 HDMI™ 2 DP TYPE-C (Max 50W) Headphone



UPSTREAM HDMI™ 1 HDMI™ 2 DP TYPE-C (Max 50W) Headphone 18V

6


27"



34"



7 Wall mounting



	W	H	VESA Screws	Torque
27/34"	100mm	100mm	M4x10mm-4pcs	< 1.2N.m