

Product data sheet

Insert without symbol, translucent



Reference number

33 NR

Insert without symbol, translucent

for rockers CD 590 KO .. and CD 590 NAKO ..

for ref.-no.: 5560 KO, 5561 KO, 5560 KO WW and 5561 KO WW

for switches with indicator light and push-buttons in design range WG 800

for switches with indicator light and push-buttons in design range WG 600

for switches with indicator light and push-buttons ref.-no.: 602 KOA .., 631 A .., 634 A .., 633 A ..

for push-buttons ref.-no.: 331 A, 333 A

Colour:

red