



PQCW-5010

denver.eu

08/2025



FR

Cet appareil et
ses accessoires
sont recyclables

À DÉPOSER
EN MAGASIN



À DÉPOSER
EN DÉCRETERIE



OU

Points de collecte sur www.quefairede mesdechets.fr
Privilégiez la réparation ou le don de votre appareil !

Safety information


Please read the safety instructions carefully before using the product for the first time and keep the instructions for future reference.

1. This product is not a toy. Keep it out of reach of children.
2. Please keep the product away from pets.
3. Warning this power bank is with Lithium polymer battery inside
4. Do not try to open the power bank.
5. Do not expose to heat, water, moisture, direct sunlight!
6. Do not attempt to replace the battery yourself- you may damage the battery, which could cause overheating and injury. Repairs or service should only be performed by qualified personnel
7. Battery must be recycled or disposed of separately from household waste. Do not incinerate the battery.
8. To reduce the risk of fire or electric shock, do not expose this product to rain or moisture.
9. Please remove the charging cable when the power bank is fully charged.
10. Product operating and storage temperatures are from 5 degree Celsius to 35 degree Celsius. Under and over this temperature might affect the function.
11. Do not drop or expose to impact shock in any way.

Denver A/S reserves the rights for print errors

Denver A/S cannot be held responsible for any technical or typographical errors and reserves the right to make changes to the product and manuals without prior notice. If you detect any inaccuracies or omissions, please inform us at the address on the back cover.

Product overview:



1. On/Off button
2. Type C input and output
3. Magnetic wireless charging pad
4. LED indicator lights for battery power
5. LED indicator lights for wireless charging

Specifications:


- Capacity: 5000 mAh/3.85V/19.25Wh
- Battery Type: Lithium Polymer
- Material: Aluminum Alloy + ABS
- LED Power Level Display
- USB-C Input: 5V/3A, 9V/2A, 12V/1.5A (18W)
- USB-C Output: 5V/3A, 9V/2.22A, 12V/1.67A (20W)
- Magnetic Wireless Output: 5W/7.5W/10W/15W (make sure that your device must support Magnetic Wireless charging)
- USB-C Charging Cable support for both Input & Output

Operation:

If using a cable for charging (not Wireless charging)

1. Single press button to turn on the power bank
2. Double click the button to turn off the power bank

If using Magnetic Wireless charging or normal Wireless charging the phone will automatically turn on the wireless charging when placed in the Power bank's wireless charging position, and if the phone supports magnetic wireless charging, the power bank will stay on the back on the phone through magnetic pull.



LED Status During charging/discharging:

1. When the mobile phone is Wireless charged, and the Power bank is in a state of discharging, the power indicator light of the power bank will light up in blue, and the wireless charging indicator light is always on in orange.

2. When the mobile phone is wired charged, the Power bank is in a state of discharge. The power indicator light of the power bank will light up in blue, and the wireless charging indicator light is not on in orange.
3. When the power bank is in a state of charging, the battery indicator light blinks blue, until it is fully charged, at which point the blue light remains on.

Note: Ensure that the protective case on the phone does not create a distance greater than 4 mm between the charging pad and the back of the phone.

Do not charge your phone in a metal case or near any other magnetically sensitive devices, such as metallic studs, magnetic clasps or magnetic plates. If this is the case, please remove the case before placing your phone on the charging pad.

Please notice - All products are subject to change without any notice. We take reservations for errors and omissions in the manual.

ALL RIGHTS RESERVED, COPYRIGHT DENVER A/S



denver.eu



Electric and electronic equipment and included batteries contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment and batteries) is not handled correctly.

Electric and electronic equipment and batteries is marked with the crossed out trash can symbol, seen above. This symbol signifies that electric and electronic equipment and batteries should not be disposed of with other household waste, but should be disposed of separately.

As the end user it is important that you submit your used batteries to the appropriate and designated facility. In this manner you make sure that the batteries are recycled in accordance with legislature and will not harm the environment.

All cities have established collection points, where electric and electronic equipment and batteries can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Additional information is available at the technical department of your city.

Contact

Main contact point: contact.hq@denver.eu

Nordics

Headquarter
Denver A/S
Omega 5A, Soeften
DK-8382 Hinnerup
Denmark

Phone: **+45 86 22 61 00**
(Push "1" for support)

E-Mail
For technical questions, please write to:
support.hq@denver.eu

For all other questions please write to:
contact.hq@denver.eu

Benelux

DENVER BENELUX B.V.
Barwoutswaarder 13C+D
3449 HE Woerden
The Netherlands

Phone: **0900-3437623**
E-Mail: **support.nl@denver.eu**

Spain/Portugal

DENVER SPAIN S.A
Ronda Augustes y Louis Lumiere, nº 23 – nave
16
Parque Tecnológico
46980 PATERNA
Valencia (Spain)

Spain

Phone: **+34 960 046 883**
Mail: **support.es@denver.eu**

Portugal:

Phone: **+35 1255 240 294**
E-Mail: **denver.service@satfiel.com**

Germany

Denver Germany GmbH Service
Service Center
Max-Emanuel-Str. 4
94036 Passau

Phone: **+49 851 379 369 40**

E-Mail
support.de@denver.eu

Monday - Thursday 09:00 - 16:30
Friday 09:00 - 14:00

Austria

Lurf Premium Service GmbH
Deutschstrasse 1
1230 Wien

Phone: **+43 1 904 3085**
E-Mail: **denver@lurfservice.at**

Poland

LetMeRepair Poland sp. z o.o.

ul. Częstochowska 140
62-800 Kalisz

Phone: **62 75 38 092**
E-Mail: **denver-service@letmerepair.pl**

Godziny pracy: 8 – 18 (poniedziałek – piątek)

If your country is not listed above,
please write an email to
contact.hq@denver.eu



Denver A/S
Omega 5A, Soeften
DK-8382 Hinnerup
Denmark

denver.eu
facebook.com/denver.eu

