

ALL IN CASE SURFACE Go 4 - 3 - 2 - 1

Protect your device with our ultra-hard case, designed to withstand the most extreme conditions.

Equipped with a 360° rotating hand strap, it offers optimum handling in all circumstances.
Robust and ergonomic, it's the ideal ally for professionals on the move!



RUGGED PROTECTIVE CASE + SHOULDER STRAP
FOR SURFACE GO 4 - GO 3 - GO 2 - GO 1
Ref. 072005



REINFORCED CORNERS

Absorb shocks in the event of a fall

SILICONE EXTERIOR

Anti-slip, anti-scratch and anti-shock silicone coating



RIGID EDGE

Rigid protective edge to shield the screen in the event of a fall

ROTATIVE HAND STRAP

360° rotating hand strap



INTEGRATED TRIPOD

Landscape/video position

Weight: 414 g | Dimensions: 275 x 190 x 20 mm

ACCESSORIES INCLUDED

Hand strap



360° rotation



Landscape mode
(Non contractual photo)



Portrait mode
(Non contractual photo)

Tripod



Video/landscape position

Stylus holder



Intregated on the hand strap
Stylus not icluded

Shoulder strap



Shoulder strap included

REFERENCE

Ref	Product	EAN Code
072005	All in Case for Surface Go 4 - Go 3 - Go 2 - Go 1 + Shoulderstrap	3700992535777

INSTALLATION GUIDE


REF. 072005

PROTECTIVE CASE

1



2



USE THE INSTALLATION TOOL TO UNLOCK THE FOUR SIDE CLIPS AND REMOVE THE HARD FRONT PANEL.

3



4



PLACE THE TABLET ON THE RIGID BACK PLATE, MAKING SURE THAT THE CAMERA LENS IS ALIGNED WITH THE CUT-OUT.

5



6



REPLACE THE SILICONE BASE AND CORNERS, THEN REPOSITION THE FRONT PANEL, INSERTING THE SIDES FIRST. THE SIDES FIRST. CONTINUE ALL THE WAY ROUND UNTIL ALL THE FIXING CLIPS ARE PROPERLY ENGAGED.

INSTALLATION GUIDE

REF. 072005

TRIPOD MODE

1



2



PULL OUT THE BRACKET AND INSERT IT INTO THE SLOT TO SECURE THE TRIPOD.
TO STORE, SIMPLY PRESS THE BUTTON.

SHOULDER STRAP

1



2



PASS THE TOOL THROUGH THE CORD, THEN THREAD THE CORD THROUGH THE NOTCH UNTIL IT PASSES THROUGH THE SILICONE CASE.

3



4



PULL THE CORD AT BOTH ENDS, TIE A KNOT AND ATTACH THE LOOP TO THE REST OF THE SHOULDER STRAP.