


Covers for switches/push-buttons
Symbol for push-switch
without symbol



For rocker 2520-...
For SM switch button 2601/. SK..
For SM push button 2601

Order Code : 2CKA001714A0211
Article No. : 2145 LI
EAN: 4011395076903