SPORTZ Titanium

User Guide

Register your product

We've got your back against damages. Register your Sportz Ti at


bit.ly/RegisterSportzTi

Visit bit.ly/sportzuserguide to view this guide in:

English | Español | Français | Deutsche | Italiano | 日本語 | 中文 | Português | Nederlands

Power Button (A)

Function	Action
Power on	Press and hold the power button for 1.5 seconds
Power off	Press and hold the power button for 2 seconds




Play/Pause Button (B)

Function	Action
Play/Pause	One click
Skip to next song	Double-click while music is playing
Answer/end call	One click

Volume Buttons (C)

Function	Action
Adjust volume	One click



LED Indicator (D)

Function	Action
Solid red	Charging
Solid blue	Charging complete
Flashing red every 4 seconds	Low battery

USB Charging Port (E)

Charge the headphones with the included micro-USB charging cable. The LED indicator will turn blue when charging is complete.



Specifications

Part number	AS451
Speaker type	Bone conduction transducer
Frequency response	15Hz~15KHz
Sensitivity	101 ± 3dB
Microphone	-44dB ± 3dB
Continuous play	12 hours
Standby time	100 days
Charge time	2 hours
Weight	1.48 oz (42g)
Warranty	2 years

Storage and maintenance

- Store the headphones in a cool and dry place. The working temperature should be $0\sim45^{\circ}C$ (32 $\sim113^{\circ}F$). Working in cold/hot environments or highly humid areas may reduce the life of the battery.
- After storing the headphones for an extended period, charge the unit before using it again.
- The headphones are sweat resistant, but are NOT waterproof. DO NOT submerge the headphones in water.
- Listening with headphones at a high volume may affect your hearing and may distort the audio.
- · When cleaning the headphones, use a soft dry cloth.
- Do not charge your headphones immediately after exercising, as any sweat or moisture inside the charging port could lead to a circuit burning.

#beopen

Visit us at aftershokz.com