

playmobil®

9493



**WARNING:**  
**CHOKING HAZARD**





Small parts. Not for children under 3 years.

"Ne concerne que les USA"




Wichtige Unterlagen, bitte sorgfältig aufbewahren!  
Important: Please keep these instructions for future reference!  
Documents importants, à conserver soigneusement!  
Belangrijke documenten, bewaar deze zorgvuldig!




1




2



1







2





3

4


5





3



4





5








6





7



8







9






11








1.







2.








3.



30 51 8022







30 08 8042



30 07 9762



30 13 1550

30 25 5863



30 10 4290

30 25 9080




30 11 3900

30 51 8012




30 08 8012



30 08 8002



30 08 8032



30 08 8022




30 51 8042



30 51 8032



30 80 6275



30 07 9982




30 07 9882



30 80 6285



30 08 8062



30 07 9992



30 21 9630




30 07 9972



30 07 9842



30 07 9922



30 07 9892



30 07 9912



30 02 6680



30 07 9722



30 07 9712



30 07 9702



30 08 8082



30 07 9652



30 07 9862



30 25 9003



30 81 1173



2x 30 07 9942



2x 30 07 9952



30 07 9672



30 07 9662



30 08 8052



30 08 8072



2x 30 07 9852



30 08 8092



30 07 9902



30 07 9782



30 07 9732



3x 30 07 9932



30 67 4392



30 63 4994



30 07 9752




30 07 9742



30 07 9872



30 63 6460



30 07 9682



30 64 2815



30 80 7235



30 64 2655



2x 30 05 8570



30 22 3822



2x 30 06 0040



30 82 5314



30 25 8440



10x 30 03 6600



15x 30 09 6900



30 60 8352




30 60 8362



30 64 2895



30 60 6562



Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

In alle PLAYMOBIL catalogi vindt u het adres van onze klantendienst.

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησης Καταναλωτών PLAYMOBIL βρίσκεται σε όλους τους καταλόγους PLAYMOBIL.

pronounce: plāy-mō-bēēl

