

NETGEAR Orbi App



You can use the NETGEAR Orbi app to set up your Orbi network.

To find the app, scan a QR code or search for NETGEAR Orbi in the Apple App Store or Google Play Store. Launch the NETGEAR Orbi app on your mobile device and follow the onscreen instructions.

Note: If you don't own a mobile device, launch a web browser and visit orbilogin.com to set up your Orbi network.



Satellite Sync LED Colors

After the satellites are powered on, each satellite's ring LED lights white while the satellite attempts to sync with the router, lights one of the following colors for about three minutes, and then turns off:

- **Blue**
The connection between the satellite and router is good.
- **Amber**
The connection between the satellite and router is fair. Consider moving the satellite closer to the router.
- **Magenta**
The satellite failed to sync with the router. Move the satellite closer to the router.

Note: If the ring LED still lights magenta after about one minute, press the **Sync** button on the router and on the satellite. If the satellite successfully syncs with the router, the satellite's ring LED lights white, then lights blue to indicate a good connection, and then turns off.

Support

Thank you for purchasing this NETGEAR product. You can visit www.netgear.com/support to register your product, get help, access the latest downloads and user manuals, and join our community. We recommend that you use only official NETGEAR support resources.

For the current EU Declaration of Conformity, visit http://support.netgear.com/app/answers/detail/a_id/11621/.

For regulatory compliance information, visit <http://www.netgear.com/about/regulatory/>.

See the regulatory compliance document before connecting the power supply.



201-21490-01

January 2017

NETGEAR, Inc.

350 East Plumeria Drive
San Jose, CA 95134, USA



NETGEAR INTL LTD
Building 3, University Technology Centre
Curraheen Road, Cork, Ireland

© NETGEAR, Inc., NETGEAR and the NETGEAR Logo are trademarks of NETGEAR, Inc. Any non-NETGEAR trademarks are used for reference purposes only.

orbi™

Quick Start Guide

NETGEAR®

All Set Up!



Package Contents



Orbi Mini Router
(Model RBR40)

Orbi Wall Plug
Satellite (2)
(Model RBW30)



Ethernet cable



Power adapter (varies by region)

Orbi Mini Router Overview



- 1 Ring LED (not shown in image)
- 2 Sync button (also used for WPS connection)
- 3 Internet port
- 4 Ethernet ports
- 5 Power On/Off button and Power LED
- 6 DC power connector
- 7 Reset button

Orbi Wall Plug Satellite Overview



- 5 Power On/Off button and Power LED
- 6 DC power connector
- 7 Reset button