

Mechanical Gamer Keyboard

Quick guide

Item no. 640-29 NORDIC

Item no. 640-30 UK


Item no. 640-31 DE



The displayed photo shows UK keyboard layout.



Connection



Functions

- Switch 22 modes LED by  button
- FN+ (↑ ↓) for backlight brightness adjustment
- FN+ (←→) for backlight speed adjustment
- FN+WIN to lock Windows, repeat to unlock
- Press FN+W to use WASD keys as arrow keys
- Fn + [F1 ~ F12]: Multimedia functions:

Fn + F1	Media
Fn + F2	Volume -
Fn + F3	Volume +
Fn + F4	Mute
Fn + F5	Stop
Fn + F6	Pre-track
Fn + F7	Play/Pause
Fn + F8	Next Track
Fn + F9	Email
Fn + F10	Web/Home
Fn + F11	My computer
Fn + F12	Calculator
Fn + Space	Back to default mode
Fn + Alt-L	Red, green, blue LED colors to switch

Support

<http://helpdesk.sandberg.world>

Warranty

There is a five-year warranty on your Sandberg product.
Please read the warranty terms and register your new
Sandberg product at www.sandberg.world/warranty

5
Years
Warranty



Item no. 640-29 NORDIC
Item no. 640-30 UK
Item no. 640-31 DE

Mechanical Gamer Keyboard

Sandberg A/S www.sandberg.world Made in China
Bregnerødvej 133D,
3460 Birkerød,
Denmark



For information on handling electronic waste, see www.sandberg.world/weee