


## FLAT/FLAT = NO EQ - NO PROBLEM



## FLAT/12kHz = SLAP REDUCTION



## FLAT/5kHz = BOTTOM TOM



## 80Hz/FLAT = BOTTOM-END CLEANUP



## 80Hz/5kHz = ONLY THE NOTE



## 140Hz/FLAT = RACK ATTACK





# STUDIO Tom Mic over rim & approx. 4" from head.



**LIVE**Tom Mic in safe zone
& approx. 2" from head.



## **BOTTOM**

Tom Mic under drum & approx. 3" from head.