

Microwave Oven

Installation manual

MG22M80**** / MS22M80****



SAMSUNG

Contents

Important safety information	2
For your safety	2
Electrical connection	2
For ventilation	3
Installation requirements	3
Tool and parts	3
Product dimensions	4
Installation instructions	5
Install microwave oven	5

Important safety information

For your safety


- This appliance complies with the EU regulations.
- The appliance should only be connected by a qualified technician.
- The microwave oven has been designed for domestic use.
- You should use it exclusively for cooking food.
- The appliance is hot during and after use.
- Bear this in mind if young children come anywhere near the appliance.
- Installation near to a conventional oven.
- Where a microwave oven is to be installed next to a conventional oven, sufficient space between them should be allowed to prevent overheating, as the surround can wrap with excessively high temperatures. Obviously, it is important to adhere strictly to the conventional oven manufacturer's installation instructions.
- A built-in microwave oven must not be installed above a conventional oven otherwise the microwave oven's cooling system may be adversely affected by hot air produced by the conventional oven.

Electrical connection

The house mains to which the appliance is connected should comply with national and local regulations.

If you wish to make a fixed connection, ensure that a multipolar switch with a minimum contact spacing of 3 mm is fitted in the supply line.

For ventilation



While installing microwave oven, the ventilation opening of 50 mm at minimum should be required between the rear wall and the floor of the installation cabinet. In addition, 4 sides of microwave should be located at least 3 mm from a cabinet.

IMPORTANT : If this manual is not observed, it can cause vapor inside the microwave oven, which prevents foods from being checked while cooking. Furthermore, it can trigger malfunction of the microwave oven.

Installation requirements

Tool and parts

Tools you will need



Pencil




Phillips Head Screwdriver



Ruler or Straightedge



Safety Glasses



3 mm Drill Bit & Electric or Hand Drill



6 mm Allen Wrench*



Adjustable Wrench*

NOTE

Use Allen wrench or adjustable wrench according to your needs.


Parts included



Silver Screw x 2 ea



Black Screw x 2 ea




Guide Install x 1 ea

Installation requirements


Product dimensions

Microwave Oven



Product		Size (mm)
A	Width	595
B	Height	380
C	Depth	320

Building-in dimensions




⚠ Caution


Need to secure room for ventilation. Install the microwave at a distance of about 850 mm or more from the floor and 50 mm or more from the rear wall. It is important to ensure that the installation of this product is in accordance with the instructions in this manual and with the installation instructions for the oven manufacturer.

Installation instructions

Install microwave oven




1. Hold the Guide Install into Outer panel side hole.
Fix screws into Guide Install.
(Use the Silver Screw : 2 ea)




2. Adjust the microwave oven height according to cabinet.
(Use the 6 mm allen wrench or the adjustable wrench)

NOTE

Make sure all four levelling legs are the same height.




3. Insert the microwave oven into the cabinet.



4. Open the door. And use the 3 mm drill to make holes. Fix screws into Guide Install.
(Use the Black Screw : 2 ea)

NOTE

- Depth of the holes should be about 5 mm.
- Fasten screws with a screwdriver hand-tight.
- Do not use an electric screw driver to fasten screws.



Memo

Memo

QUESTIONS OR COMMENTS?

COUNTRY	CALL	OR VISIT US ONLINE AT
AUSTRIA	0800-SAMSUNG (0800-7267864) [Only for Premium HA] 0800-366661 [Only for Dealers] 0810-112233	www.samsung.com/at/support
BELGIUM	02-201-24-18	www.samsung.com/be/support (Dutch) www.samsung.com/be_fr/support (French)
DENMARK	70 70 19 70	www.samsung.com/dk/support
FINLAND	030-6227 515	www.samsung.com/fi/support
FRANCE	01 48 63 00 00	www.samsung.com/fr/support
GERMANY	0180 6 SAMSUNG bzw. 0180 6 7267864* (*0,20 €/Anruf aus dem dt. Festnetz, aus dem Mobilfunk max. 0,60 €/Anruf)	www.samsung.com/de/support
ITALIA	800-SAMSUNG (800.7267864)	www.samsung.com/it/support
CYPRUS	8009 4000 only from landline, toll free	www.samsung.com/gr/support
GREECE	80111-SAMSUNG (80111 726 7864) only from land line (+30) 210 6897691 from mobile and land line	
LUXEMBURG	261 03 710	www.samsung.com/be_fr/support
NETHERLANDS	088 90 90 100	www.samsung.com/nl/support
NORWAY	815 56480	www.samsung.com/no/support
PORTUGAL	808 20 7267	www.samsung.com/pt/support
SPAIN	0034902172678	www.samsung.com/es/support
SWEDEN	0771 726 7864 (0771-SAMSUNG)	www.samsung.com/se/support
SWITZERLAND	0800 726 78 64 (0800-SAMSUNG)	www.samsung.com/ch/support (German) www.samsung.com/ch_fr/support (French)
UK	0330 SAMSUNG (7267864)	www.samsung.com/uk/support
EIRE	0818 717100	www.samsung.com/ie/support



DE68-04449A-00