

3 axes gimbal for smartphones with integrated power bank

- ▶ For smooth videos that are filmed by hand with your smartphone
- ▶ Portrait recordings for Instagram and Snapchat
- ▶ Integrated zoom slider for continuous smooth control
- ▶ Stabilizing on all 3 axes and 640° panning
- ▶ 4 working modes (pan, pan/pich, lock & all follow mode)
- ▶ Operation via integrated joystick – 4 functions (up, down, right and left)
- ▶ Light and compact structure

Smartphone app for iOS and Android with many functions

- ▶ Integrated shutter release for photo and video
- ▶ Panorama function
- ▶ Face detection and tracking
- ▶ Subject tracking
- ▶ Time Lapse | Motion Time Lapse | Track Time Lapse
- ▶ Automatic photo function

Integrated power bank with 4000 mAh

- ▶ Mobile charging for smartphones or actioncams



Technical Data

Axes	Pan axis: 640° Roll axis: 320° Pitch axis: 320°
Suitable for	iPhone* 5, 5s, SE, 6, 6s, 6 plus, 6s plus, 7, 7 plus, 8, 8 plus, X Samsung Galaxy, Huawei and further Android smartphones up to 6" screen diagonal (max. weight 75–200 g)
Operating Voltage	3.2 V – 4.0 V
Operating Time	Up to 12 hours
Power Supply	Rechargeable lithium ion battery with 4000 mAh
Material	Nylon composite with fiberglass
Size Weight	307 x 113 x 113 mm 472 g
Scope of Delivery	Gimbal, bag, tripod, USB cable and manual

Subject to technical changes.
Smartphones not included in delivery. "iPhone" is registered trademark of Apple Inc.