










Dell Pro P 24 USB-C Hub Webcam-Monitor  
P2426HEV  
Schnellstartanleitung









2




3





4




1

















1






2




3











Dell Display and Peripheral Manager  
[Dell.com/support/ddpm](https://Dell.com/support/ddpm)



KVM



Reihenschaltung



[Dell.com/support/P2426HEV](https://Dell.com/support/P2426HEV)