

Covers for switches/push-buttons
Switch rocker with marking
light



With key symbol.
For flush-mounted push switch.

Order Code : 2CKA001731A0959
Article No. : 2520 TR-214
EAN: 4011395113400