

Covers for switches/push-buttons
Switch rocker with marking
light



With symbol.

For flush-mounted switch 1g1w, 1g2w, intermediate, push switch.

Order Code : 2CKA001731A0272

Article No. : 2520 LI-212

EAN: 4011395107805