

Covers for switches/push-buttons  
Rocker  
screwable (fixing element)



For flush-mounted switch 1g1w, 1g2w, intermediate, push switch.

Order Code : 2CKA001434A0448

Article No. : 2546-212

EAN: 4011395051405