

S 4 TWIN

The Kärcher S 4 Twin sweeper makes light work of all your sweeping tasks, from petals in spring to autumn leaves and winter grit. It collects the sweepings in its 20-litre waste hopper.



Order no. 1.766-362.0

- Ideal for smaller outdoor areas
- 2 side brushes for extended working width
- Thermal handle at push handle

Technical data		
EAN code		4054278920511
Working Width With Side Brush	mm	680
Max. Area Performance	m²/h	2400
Housing/Frame		Plastic/Plastic
Waste Container	l	20
Weight without accessories	kg	10.2
Weight, ready to operate	kg	10.2
Weight incl. packaging	kg	11.9
Dimensions (L × W × H)	mm	760 × 668 × 940

Equipment		
Number of side brushes	Piece(s)	2
Stepless Adjustable Push Handle		■
Storage Position		■
Tread surface for space-saving storage		■
Tool-Free Side Brush Attachment		■
Stand-alone waste container		■

■ Included in delivery.




Practical cap for side brush

- Tool-free side brush attachment for rapid set-up and deployment.



Comfortable Footplate

- Collapse sweeper fully without stooping – for space-saving storage.



Infinitely variable push handle

- Back-friendly sweeping thanks to individual height adjustment.

EQUIPMENT FOR S 4 TWIN
1.766-362.0



		Order no.	Description	
SWEEPERS				
S4 side brushes for wet waste	1	2.644-032.0	These sweeper side brushes make light work of your sweeping tasks, from petals in spring to autumn leaves, winter grit and wet waste. Suitable for the S 4 Twin sweepers.	☐

■ Included in delivery. ☐ Available accessories. ☐ Detergent.