


STEP by STEP INSTALLATION GUIDE



 **HELIOS** GOLD **P1A**
90% EFFICIENCY POWER SUPPLY
650G 750G 850G

Package Contents

Model Name	HELIOS P1A-650G				
AC Input	100-240V~ , 10A , 50-60Hz				
DC Output	+3.3V	+5V	+12V	-12V	+5Vsb
Max. Output Current	22A	22A	54.2A	0.3A	3A
Max. Output Power	120W		650W	3.6W	15W
Total Power	650W				

Model Name	HELIOS P1A-750G				
AC Input	100-240V~ , 10A , 50-60Hz				
DC Output	+3.3V	+5V	+12V	-12V	+5Vsb
Max. Output Current	22A	22A	62.5A	0.3A	3A
Max. Output Power	120W		750W	3.6W	15W
Total Power	750W				


Model Name	HELIOS P1A-850G				
AC Input	100-240V~ , 12-8A , 50-60Hz				
DC Output	+3.3V	+5V	+12V	-12V	+5Vsb
Max. Output Current	22A	22A	70.8A	0.3A	3A
Max. Output Power	120W		850W	3.6W	15W
Total Power	850W				



The power supply should be powered by the source indicated on the rating label

Package Contents

A



X1





B




X4

Package Contents


HELIOS P1A-850G



1 Turn off the PSU before installing by pushing I/O switch to “O” position.




2




3 Motherboard

A




4 CPU




A

5 PCIE




6 SATA




7

Molex



8

Plug in the AC power cord.



9

Turn on the PSU after installing by pushing I/O switch to "I" position.

