


便携式折叠键盘 说明书

支持系统


Win/iOS/Android

注意：正确操作本产品，请仔细阅读用户手册。

产品概述



蓝牙连接（以蓝牙1模式键为例）




提示：可重复以上操作切换至 2 / 3 蓝牙模式。

Windows系统（蓝牙连接）



8 找到 "Bluetooth Keyboard"选项;



9 显示 "已连接"，配对成功后便可以在电脑端使用键盘输入功能了;



iOS系统（蓝牙连接）

通过 1、2、3 步骤打开键盘蓝牙进入配对后;

4 打开iOS系统设置并打开蓝牙;



5 蓝牙搜索到 "Bluetooth Keyboard" 点击连接;



6 显示 "已连接" 表示键盘已连接成功，可以正常使用了;




Android系统（蓝牙连接）

通过 1、2、3 步骤打开键盘蓝牙进入配对后;


4 打开Android系统设置并打开蓝牙;



5 蓝牙搜索到 "Bluetooth Keyboard" 点击连接;



6 键盘已连接成功，可以正常使用了;



产品功能

IOS/Android		Windows		Windows	
Fn+	对应功能	Fn+Shift+	对应功能	Fn+	对应功能
 Esc	返回桌面	 Esc	主页	 Esc	Esc
 F1	搜索	 F1	搜索	 F1	F1
 F2	全选	 F2	全选	 F2	F2
 F3	复制	 F3	复制	 F3	F3
 F4	粘贴	 F4	粘贴	 F4	F4
 F5	剪切	 F5	剪切	 F5	F5
 F6	上一曲	 F6	上一曲	 F6	F6
 F7	暂停/播放	 F7	暂停/播放	 F7	F7
 F8	下一曲	 F8	下一曲	 F8	F8
 F9	静音	 F9	静音	 F9	F9
 F10	音量减小	 F10	音量减小	 F10	F10
 F11	音量增大	 F11	音量增大	 F11	F11
 F12	锁屏	 F12	锁屏	 F12	F12

三系统切换语言：

iOS：control+空格键 Windows：Alt+Shift

Android：control+空格键 / Shift+空格键

三系统输入法切换：

iOS：control+ 空格键 Windows：control+ Shift

Android：control+ Shift

技术规格

键盘尺寸：295 X 101 X 17 mm (折叠)	使用按键工作电流：<1.5 mA
150 X 101 X 8 mm (打开)	待机电流：<0.5 mA
键盘重量：187 g	休眠电流：<100 μA
工作距离：10 m	休眠时间：10 分钟
锂电池容量：90 mAh	唤醒方式：按键唤醒
工作电压：3.7 V	
充电器规格：5V = 1A或2A	

状态显示LED

- 对码：按Fn+1 蓝牙键切换通道，蓝牙指示灯亮一下，即进入1 蓝牙模式。长按Fn+1 蓝牙键5秒即可进入蓝牙配对模式。
- 充电：指示灯红色，充满灯灭
- 低电压指示：当电压低于3.3V，红色指示灯闪烁

多通道连接

- 连接第1个设备前，先按Fn+1 切换通道，再长按Fn+1 对码，开始连接。
- 连接第2个设备前，先按Fn+2 切换通道，再长按Fn+2 对码，开始连接。
- 连接第3个设备前，先按Fn+3 切换通道，再长按Fn+3 对码，开始连接。
- 在多个设备同时使用，按Fn+1 / 2 / 3 切换，即可自由切换到已连接的设备。

故障分析

请与售后服务人员联系

知识产权信息

未经本司的许可，禁止复制本用户手册的内容。

安全提醒

请不要打开或修理该设备，请不要在潮湿环境中使用设备，请用干布擦拭该设备。

质保条款

本设备自购买之日起，提供1年保修服务。

键盘保养

- 请勿将设备暴露于液体和潮湿的环境中或使其淋雨，请勿在浴缸、水槽、桑拿房、游泳池或蒸汽房附近使用。
- 请勿将设备暴露于过高或过低的温度下。
- 请勿长时间放置在阳光直射的地方。
- 请勿靠近明火，如烹饪用火、蜡烛或者壁炉。
- 避免使用锋利器物刮擦产品，及时给产品进行充电以保证正常使用。

保修卡

用户填写资料

公司或个人全称 _____

通讯地址 _____

电话 _____ 邮编 _____

所购产品名称及型号 _____

购买日期 _____

本保修卡不适用于以下情况导致的故障或损坏：
(1) 自然灾害、火灾、盗窃、不当使用或未经授权的操作、改装或拆卸；
(2) 操作或使用不当，使用非指定配件或产品造成损坏或不适当的电话；
(3) 消费者自行或非本公司授权的修理人员（如维修店等），私自拆卸或
更改产品内部结构或零件。




Bluetooth Keyboard User Manual

Compatible System


Win /iOS /Android

Note: Please read the user manual carefully before you start using this product

Product Overview




Bluetooth Connection (Take BT1 for example)



Note: You can repeat above steps if you switch to 2 / 3 .

Windows System (Bluetooth Connection)



iOS System (Bluetooth Connection)

Please complete Bluetooth Connection steps 1 2 3 and switch your keyboard into Bluetooth Mode before pairing.


4 Go to Settings and turn Bluetooth on.



5 "Search for "Bluetooth Keyboard" and Click "Pair", pairing successfully.



6 The keyboard connected successfully.



Android System (Bluetooth Connection)

Please complete Bluetooth Connection steps 1 2 3 and switch your keyboard into Bluetooth Mode before pairing.


4 Click "Settings" and turn on "Bluetooth".



5 Find "Bluetooth Keyboard", click "pair"



6 "Bluetooth Keyboard" shows "connected", you can start using the keyboard.



Product Function

IOS/Android		Windows		Windows	
Fn+	Returning to	Fn+Shift	Corresponding	Fn+	Corresponding
	Return to Desk		Home Page		Esc
	Search		Search		F1
	Select		Select		F2
	Copy		Copy		F3
	Stick		Stick		F4
	Cut		Cut		F5
	Previous		Previous		F6
	Next Track		Next Track		F7
	Mute		Mute		F8
	Volume-		Volume-		F10
	Volume+		Volume+		F11
	lock		lock		F12

Three system switching languages

iOS：control+Space key

Windows：Alt+Shift

Android：control+Space key / Shift+Space key

Three system input method switch

iOS：control+ Space key Windows：control+ Shift

Android：control+ Shift

Technical Specifications

Keyboard size: 295 X 101 X 17 mm (folding)	
150 X 101 X 8 mm (open)	
Weight: 187 g	Key working current: <1.5 mA
Working distance: 10 m	Standby current: < 0.5 mA
Lithium battery capacity: 90 mAh	Sleep current: < 100 μA
Working voltage: 3.7 V	Sleep time: Ten minutes
Charger specifications: 5V = 1A or 2A	Awaken way: Press key

Status Display LED

- Connect：Press the Fn+1 Bluetooth key to switch channels. When the Bluetooth indicator lights on, indicates your channel has switched into 1. Press Fn+1 Bluetooth key for 5 seconds to enter into Bluetooth pairing mode.
- Charging：Red Indicator light will be on，after fully charging, the light crush out.
- Low Voltage Indication：When the voltage is below 3.3 V, red light twinkles.

Multi-channel connection

- Before connecting the first device, press Fn+1 to switch channels, and then hold down Fn+1 to start the connection.
- Before connecting the second device, press Fn+2 to switch channels, and then hold down Fn+2 to start the connection.
- Before connecting the third device, press Fn+3 to switch channels, and then hold down Fn+3 to start the connection.
- To use multiple devices at the same time, press Fn+1 / 2 / 3 to switch to the connected devices freely.

Troubleshooting

Please contact the after-sales service.

Copyright

It is forbidden to reproduce any part of this manual without the permission of seller.

Safety instructions

Do not open or repair this device. Do not use the device in a damp environment. Clean the device with a dry cloth.

Warranty

The device is provided with one-year limited hardware warranty from the purchase day.

Keyboard Maintenance

- Please keep the keyboard away from liquid or humid environment, saunas, swimming pool, steam room and don't let the keyboard get wet in the rain.
- Please don't expose the keyboard at too high or too low temperature condition.
- Please don't put keyboard under sun for a long time.
- Please don't put keyboard close to the flame, such as cooking stoves, candles or fireplace.
- Avoid sharp objects scratching products, timely to recharge products to ensure the normal use.

FAQ

- The tablet PC can't connect the BT keyboard?
 - At first check the BT keyboard is into match code state, then open the table PC Bluetooth searching.
- Checking the BT keyboard Battery is enough, the battery low is also lead to can't connect, you need charge.

Keyboard indication always flashing when use, is means the keyboard will be no power, please charge the power as soon as possible.

The Bluetooth keyboard is not used for a period of time, the device will automatically enter the sleep state in order to save power. Press any key on the keyboard to wake up, and the Bluetooth connection will be automatically restored.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warranty Card

User information

Company or personage full name _____

Contact address _____

TEL _____ Zip _____

The purchased product name and model NO. _____

Purchased date _____

This reason due to the product broken and damage is not include on the warranty.
(1) accident, misuse, improper operation, or any unauthorized maintenance, alteration, or disassembly.
(2) improper operation or maintenance, violation of product instructions or improper connection of power during use.
(3) Or user consumables (such as paper, batteries) that are not provided by the company but applicable here. Except where such restrictions are prohibited.

