


安装说明



TA120 EX TR4 Rev.4 Series

www.thermalright.com

配件清单



散热器主体安装



撕掉散热器底部保护膜，再将散热器固定在主板上CPU上,再用风扇螺钉将风扇固定在散热器上


，之字形折叠，118*118mm

INSTALLATION GUIDE



TA120 EX TR4 Rev.4 Series

www.thermalright.com

Parts list



Radiator main installation



Remove the bottom protective film of the heat sink, fix the heat sink to the CPU on the motherboard, and fix the fan to the heat sink with a cable tie