

材质：80克双胶纸，双面印刷 折页效果

The diagram illustrates the front and back views of the Logitech G502 mouse. The front view (left) shows the mouse's ergonomic shape with a scroll wheel and two side buttons. The back view (right) shows the underside with various ports and switches. Labels include:

- Type-c port
- Indicator Light
- Forward
- Backward
- DPI switch button
- 2.4GHz
- OFF
- Wireless
- USB receiver (Open the back cover to take out)

① Switch the toggle to [2.4G] to enter the 2.4GHz mode.

② Open the cover from the bottom of the mouse to take out the receiver.

③ Insert the USB dongle into the USB port on your computer. The mouse is now ready for use.

① Switch the toggle to **[B]** to enter wireless mode.

② Press the **[left]** **[middle]** **[right]** buttons at the same time for about 3 seconds until the indicator light flashes blue to enter the wireless pairing.

③ Search for the wireless device name **[MOCHOSE AX5 5.0]** on your device, and click to connect, the wireless indicator light will be off after successful pairing.

① Connect the cable to the Type-C port of the mouse.

② Connect the cable to the USB port of the computer. The mouse is ready to use.

The diagram shows the back of the mouse with a DPI switch button on the left and a DPI indicator light on the right. The DPI indicator light is a small circle located between the scroll wheel and the left button. A legend on the right lists the DPI values and their corresponding colors:

- 400 DPI: red
- 800 DPI: blue
- 1600 DPI: green
- 3200 DPI: yellow
- 6400 DPI: cyan
- 26000 DPI: purple

TEL / E-mail: _____

Postal Code: _____

Name: Gaming Mouse QC

Model: _____ PASS

Inspector: HT

FACTORY NO.

0	1	2	3	4	5	6	7	8	9
0	1	2	3	4	5	6	7	8	9

Executive standard: GB4943.1-2022